




SERVICE AND PARTS MANUAL

2591RT / 3391RT / 4191RT: CE Models



ART_2760

Serial Number Range

2591RT: 9401000 - Up
3391RT: 9501000 - Up
4191RT: 9601000 - Up

Part # 91803
September 2008



Aerial Platform Sales Corp.

1775 Park Street, Suite 77 • Selma, CA 93662 USA
Ph: 1-800-387-4575 • 559-891-2488 • Fax: 559-891-2448
E-mail: info@mecawp.com • Web: www.mecawp.com

Service Section Table of Contents

| | |
|---|-------------|
| Introduction I | Page |
| MEC Operator Policy | II |
| Safety Symbols | III |
| General Safety Tips | IV |
| Primary Machine Components | VI |
| Lubrication | VIII |
| Torque Specifications | 1-IX |
| Hydraulic Components Torque Table | 1-IX |
| Emergency Systems and Procedures | X |
| Lift and Support the Machine | XII |
| Machine Specifications | XIV |
| | |
| Section 1: Hydraulic System | Page |
| Hydraulic System – General | 1-2 |
| Hydraulic Fluid | 1-3 |
| Hydraulic Fluid Reservoir | 1-4 |
| Hydraulic Pump | 1-5 |
| Hydraulic Manifold | 1-8 |
| Drive and Brake System | 1-10 |
| Steering Circuit | 1-14 |
| Platform Lift Circuit | 1-16 |
| General Cylinder Repair | 1-18 |
| Optional Outriggers | 1-21 |
| Optional Generator | 1-22 |
| | |
| Section 2: Electrical System | Page |
| Electrical System – General | 2-2 |
| Deutsch Connectors | 2-3 |
| Battery | 2-4 |
| Alarms and Switches | 2-7 |
| | |
| Section 3: Overload Sensing System | Page |
| General Description | 3-2 |
| Troubleshooting | 3-4 |
| Calibration | 3-8 |
| Calibration Troubleshooting | 3-11 |



Service Section Table of Contents

| | |
|--|-------------|
| Section 4: Mechanical Components | Page |
| Mechanical Components | 4-3 |
| Scissor Beam Assembly | 4-19 |
| Engine Maintenance | 4-21 |
| Outrigger Function | 4-24 |
| Outrigger Calibration | 4-25 |
| GP106 Outrigger Control Module Troubleshooting | 4-27 |
| Section 5: Troubleshooting | Page |
| Troubleshooting | 5-3 |
| Hydraulic Pressure Adjustment Procedures | 5-8 |
| Proportional Speed Adjustment | 5-12 |
| Section 6: Schematics | Page |
| Hydraulic Schematics | 6-2 |
| Electric Schematics | 6-6 |

Parts Section

Table of Contents

| | |
|---|-------------|
| Section A: Controls | Page |
| Upper Control Box | A-3 |
| Upper Control Box Cover Assembly | A-5 |
| Upper Controls Joystick | A-7 |
| Base Control Box | A-9 |
| Section B: Platform and Rails | Page |
| Platform Assembly | B-3 |
| Roll-out Deck Lock Pin Assembly | B-5 |
| Roll-out Deck Roller Assembly | B-7 |
| Entry Gate | B-9 |
| Control Cable and Horn Installation | B-11 |
| Power to Platform and Airline to Platform | B-13 |
| Lanyard Anchorage Points | B-15 |
| Section C: Scissors | Page |
| Scissor Assembly, 2591RT | C-3 |
| Scissor Assembly, 3391RT | C-5 |
| Scissor Assembly, 4191RT | C-7 |
| Cable Routing, Scissor Assembly | C-9 |
| Limit Switch Installation | C-11 |
| Scissor Guards | C-13 |
| Section D: Axles | Page |
| Rear Axle Assembly | D-3 |
| Front Axle Assembly | D-5 |
| Drive Hub with Brake, Rear | D-7 |
| Drive Hub, Front | D-9 |

Parts Section

Table of Contents

| Section E: Hydraulics | Page |
|---|-------------|
| Manifold Assembly | E-3 |
| Manifold Assembly – Hardware | E-5 |
| Manifold – Outrigger Option | E-7 |
| Hydraulic Hoses – Drive – Lift | E-9 |
| Hydraulic Hoses – Brake and Oscillating Axle – Pump and Tank Return | E-11 |
| Hydraulic Hoses – Steering –Wheek Motor Case Drain | E-13 |
| Hydraulic Hoses – Outrigger Option | E-15 |
| Hydraulic Hoses – Generator Option | E-17 |
| Cylinder, Lift – 2591RT and 3391RT | E-19 |
| Cylinder, Lift – 4191RT (Lower) | E-21 |
| Cylinder, Lift – 4191RT (Upper) | E-23 |
| Cylinder, Steering | E-25 |
| Cylinder, Floating Axle Lock | E-27 |
| Cylinder, Outrigger (option) | E-29 |

| Section F: Base | Page |
|---------------------------------------|-------------|
| Base Assembly | F-3 |
| Control Module | F-5 |
| Power Module | F-7 |
| Power Module: Engine Mount | F-9 |
| Diesel Engine | F-11 |
| Outrigger Installation (option) | F-13 |
| Generator (option) | F-15 |
| Wire Harness | F-17 |

| Section G: Decals | Page |
|--------------------------------|-------------|
| Decals, Controls | G-3 |
| Decals, Base | G-5 |
| Decals, Scissor Assembly | G-7 |
| Decals, Platform | G-9 |
| Decals, Options | G-11 |

INTRODUCTION

This manual consists of Service and Parts illustrations sections.

The Service Section of this manual is designed to provide you, the customer, with the instructions needed to properly maintain the MEC self-propelled scissors lift. When used in conjunction with the illustrated parts section and the Operators Manual (provided separately), this manual will assist you in making necessary adjustments, repairs, identifying, and ordering the correct replacement parts.

All parts represented here are manufactured and supplied in accordance with MEC's quality standards.

We recommend that you use Genuine MEC parts to insure proper operation and reliable performance.

To obtain maximum benefits from your MEC scissors lift, always follow the proper operating and maintenance procedures. Only trained authorized personnel should be allowed to operate or service this machine. Service personnel should read and study the Operator's, Service and Parts Manuals in order to gain a thorough understanding of the unit prior to making any repairs.

| CONTENTS | PAGE |
|--|-------------|
| MEC Operator Policy | II |
| Safety Symbols | III |
| General Safety Tips | IV |
| Hydraulic System | V |
| Electrical System | V |
| Total System | V |
| Primary Machine Components | VI |
| Lubrication | VIII |
| Emergency Systems and Procedures | X |
| Emergency Lowering - 2591RT and 3391RT | X |
| Emergency Lowering - 4191RT | X |
| Parking Brake and Towing Circuit | XI |
| Lift and Support the Machine | XII |
| Machine Specifications | XIV |

| FIGURES | PAGE |
|--|-------------|
| Figure 1-1: Maintenance Lock | IV |
| Figure 1-2: Component Locations | VI |
| Figure 1-3: Component Locations, Modules | VII |
| Figure 1-4: Lubrication Points | VIII |
| Figure 1-5: Emergency Lowering Handle, 2591RT - 3391RT | X |
| Figure 1-6: Emergency Lowering Switch, 4191RT | X |
| Figure 1-7: Torque Hub Disengage | XI |



MEC OPERATOR POLICY

NOTE: The best method to protect yourself and others from injury or death is to use common sense. If you are unsure of any operation, don't start until you are satisfied that it is safe to proceed and have discussed the situation with your supervisor.

Service personnel and machine operators must understand and comply with all warnings and instructional decals on the body of the machine, at the ground controls, and platform control console.



MODIFICATIONS OF THIS MACHINE FROM THE ORIGINAL DESIGN AND SPECIFICATIONS WITHOUT WRITTEN PERMISSION FROM MEC ARE STRICTLY FORBIDDEN. A MODIFICATION MAY COMPROMISE THE SAFETY OF THE MACHINE, SUBJECTING OPERATOR(S) TO SERIOUS INJURY OR DEATH.

MEC's policies and procedures demonstrate our commitment to Quality and our relentless ongoing efforts towards Continuous Improvement, due to which product specifications are subject to change without notice.

Any procedures not found within this manual must be evaluated by the individual to assure oneself that they are "proper and safe."

Your MEC Scissors Lift has been designed, built, and tested to provide many years of safe, dependable service. Only trained, authorized personnel should be allowed to operate or service the machine.

MEC, as manufacturer, has no direct control over machine application and operation. Proper safety practices are the responsibility of the user and all operating personnel.

If there is a question on application and/or operation contact:



MEC Aerial Platform Sales Corp.

1775 Park Street, Suite 77
Selma, CA 93662 USA

Ph: 1-800-387-4575
559-891-2488

Fax: 559-891-2448

www.mecawp.com



SAFETY SYMBOLS

To help you recognize important safety information, we have identified warnings and instructions that directly impact on safety with the following signals:



“DANGER” INDICATES AN IMMINENTLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, WILL RESULT IN DEATH OR SERIOUS INJURY. THIS SIGNAL WORD IS LIMITED TO THE MOST EXTREME SITUATIONS.



“WARNING” INDICATES A POTENTIALLY HAZARDOUS SITUATION WHICH, IF NOT AVOIDED, COULD RESULT IN DEATH OR SERIOUS INJURY.



“CAUTION” indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against unsafe practices.



“Caution” without alert symbol indicates a situation which, if not avoided, may result in property damage.

GENERAL SAFETY TIPS

Regular inspection and conscientious maintenance is the key to efficient economical operation of your aerial work platform. It will help to assure that your equipment will perform satisfactorily with a minimum of service and repair.


The actual operating environment of the machine governs the inspection schedule. Correct lubrication is an essential part of the preventative maintenance to minimize wear on working parts and ensure against premature failure. By maintaining correct lubrication, the possibility of mechanical failure and resulting downtime is reduced to a minimum.



NEVER PERFORM SERVICE ON THE MACHINE WITH THE PLATFORM ELEVATED WITHOUT FIRST BLOCKING THE SCISSOR ASSEMBLY (BEAMS) IN PLACE USING THE MAINTENANCE LOCK!

- Block scissors assembly using Maintenance Lock if machine is in the elevated/extended position.
- Never leave hydraulic components or hoses open. They must be protected from contamination (including rain) at all times.
- Never open a hydraulic system when there are contaminants in the air.
- Always clean the surrounding area before opening hydraulic systems.
- Use only recommended lubricants. Improper lubricants or incompatible lubricants may be as harmful as no lubrication.
- Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.

Figure 1-1: Maintenance Lock



HYDRAULIC SYSTEM



HYDRAULIC FLUID UNDER PRESSURE CAN PENETRATE AND BURN SKIN, DAMAGE EYES, AND MAY CAUSE SERIOUS INJURY, BLINDNESS, AND EVEN DEATH. CORRECT LEAKS IMMEDIATELY.



Hydraulic fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.

ELECTRICAL SYSTEM



Prevent damage to battery and/or electrical system;

- **Always disconnect the negative battery cable first.**
- **Always connect the positive battery cable first.**

If contact is made between the positive side of the battery and a metal surface on the machine when the negative cable is installed a spark will occur. This can cause damage to the electrical system, battery explosion, and personal injury.

TOTAL SYSTEM



Engine coolant level must be checked only after engine has cooled. If radiator cap is removed while the coolant is at normal operating temperature, pressure within the coolant system will force hot liquid out through the filler opening and possibly cause severe scalding.

Failure to perform preventive maintenance at recommended intervals may result in the unit being operated with a defect that could result in injury or death of the operator.

Immediately report to your supervisor any Defect or malfunction. Any defect shall be repaired prior to continued use of the scissors lift.

Inspection and maintenance should be performed by qualified personnel familiar with the equipment.

PRIMARY MACHINE COMPONENTS

Figure 1-2: Component Locations





ILLUSTRATION No.
ART_2761

Figure 1-3: Component Locations, Modules



LUBRICATION

Figure 1-4: Lubrication Points










Table 1-1: Lubrication

| No. | ITEM | SPECIFICATIONS | FREQUENCY |
|-----|---------------------|--|--|
| 1 | Hydraulic Reservoir | Fill to the middle of the sight gauge with platform in the stowed position – Mobile Fluid 424 – <i>Do not substitute with lower grade fluids as pump damage may result</i> | Check daily. Change yearly or every 1,000 hours, whichever occurs first. |
| 2 | Hydraulic Filter | Filter Element | Normal Usage Change every six months or 500 hours, whichever occurs first Severe Usage Change every three months or 300 hours, whichever occurs first |
| 3 | Hubs | SAE 90 Multipurpose Hypoid Gear Oil. API Service Classification GL5 | Check Every Three Months or 250 Hours, whichever occurs first for Normal Usage Change Yearly or every 1000 Hours, whichever occurs first for Severe Usage. |

TORQUE SPECIFICATIONS

FASTENERS

Use the following values to apply torque unless a specific torque value is called out for the part being used.

| AMERICAN STANDARD CAP SCREWS | | | | | | | | METRIC CAP SCREWS | | | | | | | | | |
|------------------------------|---|------|------|------|---|-----|------|-------------------|-----------------------------------|---|------|------|------|---|------|------|------|
| SAE GRADE | 5 | | | | 8 | | | | METRIC GRADE | 8.8 | | | | 10.9 | | | |
| CAP SCREW SIZE - inches - |  | | | |  | | | | CAP SCREW SIZE - millimeters - |   | | | |   | | | |
| | TORQUE | | | | TORQUE | | | | | TORQUE | | | | TORQUE | | | |
| | FT. LBS | | Nm | | FT. LBS | | Nm | | | FT. LBS | | Nm | | FT. LBS | | Nm | |
| | MIN | MAX | MIN | MAX | MIN | MAX | MIN | MAX | | MIN | MAX | MIN | MAX | MIN | MAX | MIN | MAX |
| 1/4 - 20 | 6.25 | 7.25 | 8.5 | 10 | 8.25 | 9.5 | 11 | 13 | M6 X 1.00 | 6 | 8 | 8 | 11 | 9 | 11 | 12 | 15 |
| 1/4 - 28 | 8 | 9 | 11 | 12 | 10.5 | 12 | 14 | 16 | M8 X 1.25 | 16 | 20 | 21.5 | 27 | 23 | 27 | 31 | 36.5 |
| 5/16 - 18 | 14 | 15 | 19 | 20 | 18.5 | 20 | 25 | 27 | M10 X 1.50 | 29 | 35 | 39 | 47 | 42 | 52 | 57 | 70 |
| 5/16 - 24 | 17.5 | 19 | 23 | 26 | 23 | 25 | 31 | 34 | M12 X 1.75 | 52 | 62 | 70 | 84 | 75 | 91 | 102 | 123 |
| 3/8 - 16 | 26 | 28 | 35 | 38 | 35 | 37 | 47.5 | 50 | M14 X 2.00 | 85 | 103 | 115 | 139 | 120 | 146 | 163 | 198 |
| 3/8 - 24 | 31 | 34 | 42 | 46 | 41 | 45 | 55.5 | 61 | M16 X 2.50 | 130 | 158 | 176 | 214 | 176 | 216 | 238 | 293 |
| 7/16 - 14 | 41 | 45 | 55.5 | 61 | 55 | 60 | 74.5 | 81 | M18 X 2.50 | 172 | 210 | 233 | 284 | 240 | 294 | 325 | 398 |
| 7/16 - 20 | 51 | 55 | 69 | 74.5 | 68 | 75 | 92 | 102 | M20 X 2.50 | 247 | 301 | 335 | 408 | 343 | 426 | 465 | 577 |
| 1/2 - 13 | 65 | 72 | 88 | 97.5 | 86 | 96 | 116 | 130 | M22 X 2.50 | 332 | 404 | 450 | 547 | 472 | 576 | 639 | 780 |
| 1/2 - 20 | 76 | 84 | 103 | 114 | 102 | 112 | 138 | 152 | M24 X 3.00 | 423 | 517 | 573 | 700 | 599 | 732 | 812 | 992 |
| 9/16 - 12 | 95 | 105 | 129 | 142 | 127 | 140 | 172 | 190 | M27 X 3.00 | 637 | 779 | 863 | 1055 | 898 | 1098 | 1217 | 1488 |
| 9/16 - 18 | 111 | 123 | 150 | 167 | 148 | 164 | 200 | 222 | M3 X 3.00 | 872 | 1066 | 1181 | 1444 | 1224 | 1496 | 1658 | 2027 |
| 5/8 - 11 | 126 | 139 | 171 | 188 | 168 | 185 | 228 | 251 | | | | | | | | | |
| 5/8 - 18 | 152 | 168 | 206 | 228 | 203 | 224 | 275 | 304 | | | | | | | | | |
| 3/4 - 10 | 238 | 262 | 322 | 255 | 318 | 350 | 431 | 474 | | | | | | | | | |
| 3/4 - 16 | 274 | 302 | 371 | 409 | 365 | 402 | 495 | 544 | | | | | | | | | |
| 7/8 - 9 | 350 | 386 | 474 | 523 | 466 | 515 | 631 | 698 | | | | | | | | | |
| 7/8 - 14 | 407 | 448 | 551 | 607 | 543 | 597 | 736 | 809 | | | | | | | | | |
| 1 - 8 | 537 | 592 | 728 | 802 | 716 | 790 | 970 | 1070 | | | | | | | | | |
| 1 - 14 | 670 | 740 | 908 | 1003 | 894 | 987 | 1211 | 1137 | | | | | | | | | |

Torque values apply to fasteners as received from the supplier, dry or when lubricated with normal engine oil. If special graphite grease, molydisulphide grease, or other extreme pressure lubricants are used, these torque values *do not apply*.

HYDRAULIC COMPONENTS TORQUE TABLE

NOTE: Always lubricate threads with clean hydraulic fluid prior to installation.

Use the following values to torque hydraulic components when a specific value is not available. Always check for torque values in the following places before relying on the Hydraulic Components Torque Table;

- parts drawings and service instructions in this manual.
- packaging and instruction sheets provided with new parts.
- instruction manuals provided by the manufacturer of the component being serviced.

| TYPE: SAE PORT SERIES | CARTRIDGE POPPET | | FITTINGS | | HOSES | |
|-----------------------|------------------|-----------|-----------|-----------|-------------|-----------|
| | FT. LBS | Nm | FT. LBS | Nm | FT. LBS | Nm |
| #4 | N/A | N/A | N/A | N/A | 135 - 145 | 15 - 16 |
| #6 | N/A | N/A | 10 - 20 | 14 - 27 | 215 - 245 | 24 - 28 |
| #8 | 25 - 30 | 31 - 41 | 25 - 30 | 34 - 41 | 430 - 470 | 49 - 53 |
| #10 | 35 - 40 | 47 - 54 | 35 - 40 | 47 - 54 | 680 - 750 | 77 - 85 |
| #12 | 85 - 90 | 115 - 122 | 85 - 90 | 115 - 122 | 950 - 1050 | 107 - 119 |
| #16 | 130 - 140 | 176 - 190 | 130 - 140 | 176 - 190 | 1300 - 1368 | 147 - 155 |



EMERGENCY SYSTEMS AND PROCEDURES



IF THE CONTROL SYSTEM FAILS WHILE THE PLATFORM IS ELEVATED, HAVE AN EXPERIENCED OPERATOR USE THE EMERGENCY LOWERING PROCEDURE TO SAFELY LOWER THE PLATFORM.

DO NOT ATTEMPT TO CLIMB DOWN SCISSOR ASSEMBLY (BEAMS). BEFORE LOWERING PLATFORM, RETRACT THE DECK EXTENSION.

Figure 1-5: Emergency Lowering Handle, 2591RT - 3391RT

EMERGENCY LOWERING - 2591RT AND 3391RT

Emergency Down system is used to lower the platform in case of power or valve failure. To lower the platform, pull the red "T" handle located at the rear of the machine. Lowering stops when you release the "T" handle.





Figure 1-6: Emergency Lowering Switch, 4191RT

EMERGENCY LOWERING - 4191RT

The Emergency Down System is used to lower the platform in case of power or valve failure. To lower the platform, perform the following steps:

1. Push and hold the toggle switch down to lower the platform.
2. Once the platform is fully lowered, release the toggle switch to close the valve.



PARKING BRAKE AND TOWING CIRCUIT

Machine can be winched or moved short distances in case of power failure at speeds not to exceed 5 MPH (8.05 kph).

TOWING/ WINCHING THE MACHINE

Your machine is equipped with a hub disengage mechanism.



Prior to manually releasing brakes, insure wheels are chocked to prevent machine from moving.

DISENGAGE BRAKES BEFORE TOWING:

- Chock the wheels.
- Remove the Torque Engage Cap and reinstall with the bump facing *inward* on all four hubs (see illustration).
- Machine is now ready for towing.




**AFTER DISENGAGING HUBS
THERE IS NOTHING TO STOP
THE MACHINE'S TRAVEL.
MACHINE WILL ROLL FREELY
ON SLOPES. BE ON GUARD
AGAINST RUNAWAY.**

ENGAGE HUBS BEFORE DRIVING:

- Remove the Torque Engage Cap and reinstall with the bump facing *outward* on all four hubs.
- Machine is now ready for driving.

Figure 1-7: Torque Hub Disengage



LIFT AND SUPPORT THE MACHINE



THE USE OF SUBSTANDARD LIFTING DEVICES AND/OR JACK STANDS MAY CAUSE THE MACHINE TO FALL RESULTING IN DEATH OR SERIOUS PERSONAL INJURY.

The following are needed to safely lift and support the machine;

- a jack with a lifting capacity of two (2) tons or more.
- jack stands with a rating of one (1) ton or more.

TO RAISE THE MACHINE

1. Move machine to a firm level surface capable of supporting the weight of the machine.
2. Chock tires on one end of machine and raise the other end of machine.
3. If wheel is to be removed, loosen but **do not remove** lugs before raising the machine.
4. Position a jack at the end of the machine to be lifted, under a solid lifting point in the center of the frame.
5. Raise the machine and place two (2) suitable jack stands under solid support points at the outer ends of the frame.
6. Lower the machine to rest on the jack stands and inspect for stability.

TO LOWER THE MACHINE

1. Tighten lugs to proper torque (refer to machine specifications).
2. Raise machine slightly and remove jack stands.
3. Lower the machine and remove the jack.
4. Remove chocks.

NOTES:



MACHINE SPECIFICATIONS

| | | 2591RT | | 3391RT | | 4191RT | |
|---------------------------------------|---------------------------------|--|-------------------------|-------------------------|-------------------------|---|-------------------------|
| Working Height* | | 31.6 ft* | 9.62 m* | 39.6 ft* | 12.06 m* | 47.6 ft* | 14.5 m* |
| Platform Height | | 25.0 ft | 7.62 m | 33.0 ft | 10.06 m | 41.0 ft | 12.5 m |
| | Platform Entry Height | 5.6 ft | 1.7 m | 5.6 ft | 1.7 m | 6.2 ft | 1.9 m |
| Stowed Height | Rails Up | 8.5 ft | 2.6 m | 9.2 ft | 2.8 m | 9.8 ft | 3 m |
| | Rails Folded Down | 5.9 ft | 1.8 m | 6.6 ft | 2 m | 7.3 ft | 2.24 m |
| Maximum Number of Occupants | 0 m/s Wind (indoors) | 5 | | 4 | | 4 | |
| | 12 m/s Wind (outdoors) | 5 | | 4 | | 4 | |
| Lift Capacity | Evenly Distributed | 2000 lb | 907 kg | 1499 lb | 680 kg | 1000 lb | 454 kg |
| | Rollout Deck Capacity | 500 lb | 227 kg | 500 lb | 227 kg | 500 lb | 227 kg |
| Maximum Operating Inclination | | 3° | | 3° | | 3° up to 9.1 m (30 ft) 1.5° up to 12.5 m (41 ft) | |
| Platform Dimensions | Roll-Out Deck Extended | 181.1 in | 4.6 m | 181.1 in | 4.6 m | 181.1 in | 4.6 m |
| | Roll-Out Deck Retracted | 131.9 in | 3.35 m | 131.9 in | 3.35 m | 131.9 in | 3.35 m |
| | Deck Width | 72.0 in | 1.83 m | 72.0 in | 1.83 m | 72.0 in | 1.83 m |
| | Guard Rail Height | 44.5 in | 1.13 m | 44.5 in | 1.13 m | 44.5 in | 1.13 m |
| | Toe Board Height | 7.1 in | 18 cm | 7.1 in | 18 cm | 7.1 in | 18 cm |
| | Rollout Deck Length | 48.0 | 1.22 m | 48.0 | 1.22 m | 48.0 | 1.22 m |
| Overall Length | | 144.1 in | 3.66 m | 144.1 in | 3.66 m | 144.1 in | 3.66 m |
| | With Outriggers | 181.1 in | 4.6 m | 181.1 in | 4.6 m | 181.1 in | 4.6 m |
| Overall Width | | 90.1 in | 2.3 m | 90.1 in | 2.3 m | 90.1 in | 2.3 m |
| Wheel Base | | 102.4 in | 2.6 m | 102.4 in | 2.6 m | 102.4 in | 2.6 m |
| Wheel Track | | 78.7 in | 2.0 m | 78.7 in | 2.0 m | 78.7 in | 2.0 m |
| Turning Radius | Inside | 76.0 in | 1.93 m | 76.0 in | 1.93 m | 76.0 in | 1.93 m |
| | Outside | 194.9 in | 4.95 m | 194.9 in | 4.95 m | 194.9 in | 4.95 m |
| Ground Clearance | | 12.0 in | 30.5 cm | 12.0 in | 30.5 cm | 12.0 in | 30.5 cm |
| Machine Weight** (Unloaded) (Approx.) | | 8000 lb** | 3629 kg** | 8699 lb** | 3946 kg** | 9700 lb** | 4400 kg** |
| Drive System (Proportional) | | 2 Wheel Drive Standard, 4 Wheel Drive Option | | | | | |
| | Drive Speed (Platform Elevated) | 0 – 0.8 mph | 0 – 1.3 km/h | 0 – 0.8 mph | 0 – 1.3 km/h | 0 – 0.8 mph | 0 – 1.3 km/h |
| | Drive Speed (Platform Lowered) | 0 – 3.8 mph | 0 – 6.1 km/hr | 0 – 3.8 mph | 0 – 6.1 km/hr | 0 – 3.8 mph | 0 – 6.1 km/hr |
| Brakes | | Multi disc | | Multi disc | | Multi disc | |
| Lift/Lower Speed (Approx.) | | 25 sec / 30 sec | | 33 sec / 35 sec | | 40 sec / 50 sec | |
| Gradeability | | 45% / 24.2° | | 45% / 24.2° | | 45% / 24.2° | |
| Ground Pressure/Wheel (Maximum) | | 121 psi | 8.50 kg/cm ² | 137 psi | 9.63 kg/cm ² | 140 psi | 9.84 kg/cm ² |
| Wind Speed | | 28 mph | 12.5 m/sec | 28 mph | 12.5 m/sec | 28 mph | 12.5 m/sec |
| Noise Level | | 86 dB | | 86 dB | | 86 dB | |
| Vibration*** | | < 2.5m/s ² | | < 2.5m/s ² | | < 2.5m/s ² | |
| Tire Size-Standard | | 12-16.5 NHS "Outrigger" | | 12-16.5 NHS "Outrigger" | | 12-16.5 NHS "Outrigger" | |
| | 12 PLY Foam Filled | Foam Filled | | Foam Filled | | Foam Filled | |
| Wheel Load | | 2,998 lb | 1360 kg | 3,060 lb | 1388 kg | 3,210 lb | 1456 kg |
| Wheel Lug Nut Torque | | 150-166 ft/lb | 204-225 Nm | 150-166 ft/lb | 204-225 Nm | 150-166 ft/lb | 204-225 Nm |
| Hydraulic Pressure | Main System | 3000 psi | 207 bar | 3000 psi | 207 bar | 3000 psi | 207 bar |
| | Lift System | 2500 psi | 172 bar | 2500 psi | 172 bar | 2500 psi | 172 bar |
| | Steer | 1500 psi | 103 bar | 1500 psi | 103 bar | 1500 psi | 103 bar |
| Hydraulic Fluid Capacity | | 23 GAL | 87 liters | 23 GAL | 87 liters | 23 GAL | 87 liters |
| Fuel Capacity | | 15 GAL | 57 liters | 15 GAL | 57 liters | 15 GAL | 57 liters |
| Power System – Voltage | | 12 Volts DC | | 12 Volts DC | | 12 Volts DC | |
| Alternator (Lighting Coil) | | 40 Amp | | 40 Amp | | 40 Amp | |
| Engine Availability | | Kubota D1105, 25 HP (8.7kW), Diesel, Liquid Cooled | | | | | |
| Meets requirements of CE | | *Metric equivalent of working height adds 2 m (6.6 ft.) to platform height. **Weight may increase with certain options or country standards. ***Vibration is not significant | | | | | |



Section 1

HYDRAULIC SYSTEM

| CONTENTS | PAGE |
|----------------------------------|-------------|
| Hydraulic System – General | 1-2 |
| Hydraulic Fluid | 1-3 |
| Hydraulic Fluid Reservoir | 1-4 |
| Hydraulic Pump | 1-5 |
| Hydraulic Manifold | 1-8 |
| Drive and Brake System | 1-10 |
| Steering Circuit | 1-14 |
| Platform Lift Circuit | 1-16 |
| General Cylinder Repair | 1-18 |
| Optional Outriggers | 1-21 |
| Optional Generator | 1-22 |

| FIGURES | PAGE |
|---|-------------|
| Figure 1-1: Hydraulic Fluid Reservoir | 1-4 |
| Figure 1-2: Hydraulic Pump | 1-5 |
| Figure 1-3: Hydraulic Pump Seals | 1-7 |
| Figure 1-4: Hydraulic Manifold | 1-9 |
| Figure 1-5: Drive Shaft Seal | 1-10 |
| Figure 1-6: Drive Motor, Exploded View | 1-11 |
| Figure 1-7: Gear Reduction Hub | 1-12 |
| Figure 1-8: Rear Wheel Motor | 1-13 |
| Figure 1-9: Steering Ports, Main Hydraulic Manifold | 1-14 |
| Figure 1-10: Steering Cylinders | 1-15 |
| Figure 1-11: Platform Lift, Main Hydraulic Manifold | 1-16 |
| Figure 1-12: Lift Cylinders | 1-17 |
| Figure 1-13: Typical Cylinders, Exploded View | 1-18 |
| Figure 1-14: Outrigger Hydraulic Connections | 1-21 |
| Figure 1-15: Optional Generator Connections | 1-22 |



HYDRAULIC SYSTEM – GENERAL

The hydraulic system is an open center, open-loop type. Generally in this type of system, hydraulic fluid is provided by a variable displacement, pressure compensated, piston type pump which is directly coupled to the engine. As the engine turns, the hydraulic pump drains fluid from the reservoir and pumps this fluid to the valve packages.

If no function is selected to perform, the pump remains on standby and no fluid is pumped through the manifold. Each function has a maximum pressure control limit set by pressure relief valve.

Hydraulic integrated circuit, generally known as the manifold system (valve type) is designed to control all or part of machine functions by integrating various hydraulic cartridge valves into a manifold to provide directional, pressure, flow, and load control.

HYDRAULIC ROADMAP

HYDRAULIC RESERVOIR

Hydraulic fluid is held in the reservoir for delivery to the various components and then returned to the reservoir. Returning hydraulic fluid is routed through a filter before entering the reservoir.

PUMP

When required, the variable displacement pump delivers hydraulic fluid under pressure to the main hydraulic manifold. Pump volume is controlled by a load sense system.

HYDRAULIC MANIFOLD

The main manifold directs the hydraulic fluid to the hydraulically operated components and returns fluid to the reservoir through the use of electronically operated solenoid valves.

DRIVE AND BRAKE SYSTEM

2 Wheel Drive machines are equipped with two (2) hydraulically operated drive motors. 4 Wheel Drive machines are equipped with four (4) hydraulically operated drive motors. Each motor is connected to a gear reduction hub. The hubs on the rear drive motors are equipped with spring applied - hydraulically released brakes.

FLOATING AXLE LOCK CYLINDERS

Two (2) hydraulic cylinders control the floating axle on the rear of the machine. When platform is elevated, the cylinders lock into place to increase machine stability.

STEERING SYSTEM

Two (2) hydraulic cylinders control steering.

LIFT SYSTEM

The 2591RT and 3391RT are equipped with one (1) hydraulic lift cylinder. The 4191RT is equipped with two (2) hydraulic lift cylinders.

OPTIONAL OUTRIGGER SYSTEM

If equipped, the *main hydraulic manifold* delivers fluid to the *outrigger hydraulic manifold*. Hydraulic fluid is then directed to four (4) hydraulic cylinders, one at each corner of the machine.

OPTIONAL GENERATOR SYSTEM

If equipped, the generator is driven by a hydraulic motor which receives hydraulic fluid directly from the pressure port of the pump.

HYDRAULIC FLUID

HANDLING PRECAUTIONS



PERSONS IN REGULAR CONTACT WITH MINERAL-BASED HYDRAULIC FLUID NEED TO BE AWARE OF THE IMPORTANCE OF THOROUGH HYGIENE, AND THE PROPER METHODS FOR HANDLING MINERAL OILS, IN ORDER TO AVOID POTENTIAL HAZARDS TO HEALTH.

If mineral-based hydraulic fluid is **SPLASHED INTO THE EYES**, it must be **WASHED OUT THOROUGHLY** using abundant quantities of water. If irritation persists, medical advice should be sought.



HYDRAULIC FLUID UNDER PRESSURE CAN PENETRATE AND BURN SKIN, DAMAGE EYES, AND MAY CAUSE SERIOUS INJURY OR BLINDNESS.

FULID LEAKS UNDER PRESSURE MAY NOT ALWAYS BE VISIBLE.

FLUID RECOMMENDATIONS

MEC recommends the use of **Mobil Fluid 424** hydraulic fluid. Do not substitute with lower grade fluids as pump damage may result.

SYSTEM FLUSHING PROCEDURE

1. With platform fully down, drain hydraulic fluid from hydraulic reservoir into a clean, empty container.
2. When the hydraulic reservoir is empty, remove suction strainer and hoses.
3. Remove the bypass filter and hose.
4. Flush the hoses with clean hydraulic fluid.
5. Discard old bypass filter element and replace.
6. Flush out the reservoir with hoses removed from the hydraulic reservoir.
7. Reinstall all hoses removed in the previous steps.
8. Fill hydraulic reservoir with filtered, fresh hydraulic fluid (refer to Lubrication Chart).
9. Loosen output hose fittings at pump to flood with hydraulic fluid. Tighten fittings.
10. Start up the machine. Briefly operate all functions. Two or three lift cycles may be necessary to purge all air from lift cylinder(s).
11. When the above procedures have been completed, fill hydraulic reservoir to full mark on sight gauge.
12. Check all leaks and correct as necessary. Machine is now ready to be placed back in operation.

NOTE: Avoid mixing petroleum and synthetic base fluids. It is not advisable to mix fluids of different brands or types, except as recommended.

HYDRAULIC FLUID RESERVOIR

Consists of the reservoir, a filler cap with breather, a drain plug, a sight gauge, and a bypass filter with a 10 micron filter element.

- Check reservoir for signs of leakage, every week.


HYDRAULIC RESERVOIR ASSEMBLY

All machines are produced with a spin-on, bypassing filter. When the filter is clogged, hydraulic flow bypasses the filter element. The filter element must be changed every six (6) months or 500 hours. Extremely dirty conditions may require that the filter be replaced more often.



Beware of hot fluid. Contact with hot fluid may cause severe burns.

Figure 1-1: Hydraulic Fluid Reservoir



HYDRAULIC PUMP

NOTE: Refer to *Section 4 – Hydraulic Pressure Adjustment Procedures.*
Refer to *Parts Section F.*

An internal combustion engine drives a variable displacement axial piston pump. Flow is proportional to drive speed and displacement.


REMOVE

1. Turn the Battery Disconnect Switch (inside Control Module) to the OFF position.
2. Tag and disconnect hydraulic hoses, and IMMEDIATELY cap or cover the openings to prevent contamination.
3. Remove the two (2) bolts that hold the pump to the housing.
4. Remove the pump.

INSTALL

1. Install drive hub onto pump shaft. Torque bolt to 45 Ft. Lbs. (61 Nm).
2. Position the pump to the housing. Turn the pump until the splines on the hub align allowing the pump to become flush with the housing.
3. Turn the pump until the bolt holes align with the mounting holes on the housing and install the bolts. Torque to 25-28 Ft. Lbs. (35-38 Nm).
4. Install the hydraulic hoses.
5. Turn the Battery Disconnect Switch to the ON position.
6. Check for leaks and check all hydraulic pressures (refer to *Section 4*).

Figure 1-2: Hydraulic Pump



Hydraulic Pump Seals

DRIVE SHAFT SEAL REPLACEMENT


Caution: Be careful not to damage the drive shaft when removing the old seal.

1. Remove the shaft key.
2. Remove the snap ring.
3. Remove the shaft seal.
 - Check the surface of the shaft and the housing for imperfections.
4. Install new shaft seal.
 - Cover the drive shaft with tape to prevent damage to the seal during installation.
 - Coat the shaft seal with grease.
 - Seat the shaft seal with a seal setting tool.
5. Install the snap ring.
6. Install the shaft key.

HYDRAULIC PUMP REBUILD

Pump rebuild should only be performed by a qualified mechanic. Contact MEC Technical Support before attempting to rebuild the pump.

Figure 1-3: Hydraulic Pump Seals



MEC
ILLUSTRATION No.
ART_2027



HYDRAULIC MANIFOLD

NOTE: Refer to *Parts Section E*.

Tag all components as they are removed to aid in reassembly.

HYDRAULIC MANIFOLD REMOVAL

1. Disconnect the negative battery terminal.
2. Tag and disconnect the solenoid valve leads.
3. Tag and disconnect hydraulic hoses, and IMMEDIATELY cap the openings to prevent contamination.
4. Remove the bolts that hold the manifold to the mounting bracket.
5. Remove the manifold block.

DISASSEMBLY

1. Remove coils from solenoid valves.
2. Remove valves.
3. Remove fittings, plugs, springs, balls, and orifices.

CLEANING AND INSPECTION

1. Wash the manifold in cleaning solvent to remove built-up contaminants, then blow out all passages with clean compressed air.
2. Inspect the manifold for cracks, thread damage and scoring where O-rings seal against internal and external surfaces.
3. Wash and dry each component and check for thread damage, torn or cracked O-rings, and proper operation.
4. Replace defective parts and O-rings.

ASSEMBLY


NOTE: Lubricate all O-rings before installation to prevent damage to the O-ring. Seat balls in manifold block by lightly tapping on the ball with a brass drift punch.

1. Install fittings, plugs, springs, balls, and orifices. Use one drop of Loctite #424 or equivalent thread locker on each screw-in orifice.
2. Install valves.

INSTALLATION

1. Attach manifold assembly to mounting plate with mounting bolts.
2. Connect solenoid leads (as previously tagged).
3. Connect hydraulic hoses (as previously tagged). Be certain to tighten hoses.
4. Connect the battery.
5. Operate each hydraulic function and check for proper operation and leaks.
6. Adjust valve pressures.

Figure 1-4: Hydraulic Manifold



DRIVE AND BRAKE SYSTEM

WHEEL DRIVE

NOTE: Refer to *Section 3* for Remove and Install instructions.
Refer to *Parts Section D*.

Drive motors are axial piston hydraulically operated. Each motor is connected to a gear reduction hub. Braking is a function of the gear reduction hub.

2-Wheel Drive machines are equipped with two (2) drive motors.

4-Wheel Drive machines are equipped with four (4) drive motors.

DRIVE SHAFT SEAL REPLACEMENT

Caution: Be careful not to damage the drive shaft when removing the old seal.


1. Remove the snap ring.
2. Remove the shaft seal.
 - Check the surface of the shaft and the housing for imperfections.
3. Install new shaft seal.

Cover the drive shaft splines with tape to prevent damage to the seal during installation.

Coat the shaft seal with grease.

- Seat the shaft seal with a seal setting tool.
4. Install the snap ring.


Figure 1-5: Drive Shaft Seal



Hydraulic Motor Rebuild –

Motor rebuild should only be performed by a qualified mechanic. Contact MEC Technical Support before attempting to rebuild the pump.

Figure 1-6: Drive Motor, Exploded View



GEAR REDUCTION HUBS WITH BRAKES

NOTE: Refer to *Section 3* for Remove, Replace, and Service instructions.
Refer to *Parts Section E*.


All machines are equipped with two (2) gear reduction hubs with spring applied - hydraulically released brakes.

4 Wheel Drive machines are equipped with four (4) gear reduction hubs. Only the rear hubs are equipped with spring applied - hydraulically released brakes.

SERVICE AND REPAIR

Refer to *Section 3* for brake repair and all other service for the Gear Reduction Hubs.

Figure 1-7: Gear Reduction Hub



FLOATING AXLE LOCK CYLINDER


NOTE: Refer to *Cylinder Repair*.

Refer to *Section 3* for Remove and Replace instructions.

Refer to the *Parts Manual, Section E* for parts list.

There are two (2) cylinders utilized in the floating axle system. These cylinders allow fluid to transfer from one side to the other while the platform is in the stowed position. When the platform is elevated, the electrically operated valve closes, preventing fluid flow and thereby locking the cylinders.

Figure 1-8: Rear Wheel Motor




STEERING CIRCUIT

NOTE: Refer to *Hydraulic Manifold and Relief Pressure Adjustment Procedure*.
Refer to *Section 3* for Remove and Replace instructions.
Refer to *Parts Section E* for hose routing.

The steering system consists of the following components:

- The wheel motor housings have pivots on the top and bottom, and are mechanically linked together via a tie-rod.
- Steering is accomplished hydraulically by using two (2) double-acting cylinders, and a 4-way 3-position solenoid-operated, hydraulic directional control cartridge valve.
- Maximum steering pressure is limited by the steering relief valve (refer to *Relief Pressure Adjustment Procedure*).

Figure 1-9: Steering Ports, Main Hydraulic Manifold



STEERING CYLINDER

NOTE: Refer to *Cylinder Repair*.


Refer to *Section 3* for Remove and Replace instructions.

Refer to the *Parts Manual, Section E* for parts list.

There are two (2) cylinders utilized in the steering system. These cylinders are a double acting type which requires fluid flow to operate the cylinder rod in both directions.

Directing fluid forces the piston to travel towards the rod end of the barrel, extending the cylinder rod. By directing fluid to the rod side of the cylinder the piston will be forced in the opposite direction and the cylinder rod will retract.

Figure 1-10: Steering Cylinders



PLATFORM LIFT CIRCUIT

NOTE: Refer to *Hydraulic Manifold and Relief Pressure Adjustment Procedure*.
Refer to *Section 3* for Remove and Replace instructions.

- The lift system uses the hydraulic pump to obtain proportional lifting function controlled by the lift valve and proportional valve.
- Lowering is single speed. When lowering, the holding valves on the lift cylinder(s) open allowing gravity to lower the platform. Lowering speed is regulated by a fixed orifice located on the lift cylinder(s) as fluid is returned to the reservoir.
- Platform capacity is limited by a hydraulic relief valve in the lift circuit. (Refer to Machine Specifications or the Hydraulic Schematic for proper setting).

LIFT CYLINDER

NOTE: Refer to *Cylinder Repair*.

2591RT AND 3391RT

One (1) single acting type hydraulic cylinder.

The cylinder has an integrated 2-position, 2-way solenoid operated platform lower valve for holding the platform in position. The valve is also externally actuated via a cable for manually lowering the platform.

4191RT

Two (2) single acting type hydraulic cylinders.

Each cylinder has an integrated 2-position, 2-way solenoid operated platform lower valve for holding the platform in position. The valves are also electrically actuated via a toggle switch for manually lowering the platform.

The normally closed holding valve prevents retraction of the cylinder rod should a hydraulic line rupture or a leak develop between the cylinder and its related control valve.

Figure 1-11: Platform Lift, Main Hydraulic Manifold





Figure 1-12: Lift Cylinders




GENERAL CYLINDER REPAIR



CYLINDERS ARE HEAVY. SUPPORT CYLINDERS BEFORE REMOVING HARDWARE THAT SECURES THE CYLINDER TO THE MACHINE.

Figure 1-13: Typical Cylinders, Exploded View



REMOVAL

NOTE: Refer to *Section 3* for Remove and Replace instructions, and the *Parts Manual* for a list of hardware specific to the cylinder being repaired.

1. Tag hoses for proper reassembly.
2. Disconnect hoses and **IMMEDIATELY** cap the openings to prevent contamination.
3. Remove cylinder from the machine as described in *Section 3*.

PREPARATION



Take care not to damage rod surface and guard against dirt or other foreign objects entering system.

1. Drain all fluid from cylinder.
2. Clean all dirt and grit from outside of cylinder.
3. Insert cylinder into vise.

CYLINDER DISASSEMBLY

1. Remove the head from the cylinder body.
2. Remove the shaft assembly from the barrel, pulling in a straight line, so as not to scar the internal parts.
3. Insert shaft into a **soft jawed** vise so that the head and piston can be removed. Be sure the shaft and vise are both clean before using.
4. Remove nut at the end of the shaft and pull head and piston off of the rod.
5. Remove all seals from the head and piston using a non-sharp seal tool. These tools are available from various seal suppliers.
6. Clean all fluid and debris off of the head, piston, shaft, collar and barrel using solvent, rags, and an air hose.
7. Inspect parts for scratches, pits or polishing. Check seal groves and sealing surfaces.
 - a. Scratches or pits deep enough to catch the fingernail are unacceptable; replace the cylinder.
 - b. Polishing is a sign of uneven loading. Check for roundness. If a polished surface is not round within .007 in. (0.18 mm) replace the cylinder.

CYLINDER ASSEMBLY

CAUTION:

- To insure a quality repair, cylinder parts must be thoroughly cleaned, dry, and free of solvents, and assembly must be performed in a clean area free of dust and contamination.
- To avoid cutting the seals, do not use sharp edged tools during seal replacement. After installing seals allow at least one hour for the seals to restore to their original shape before assembling the cylinder.
- Torque all hardware according to the Hydraulic Components Torque Table unless otherwise specified.

1. Lubricate all components with clean hydraulic fluid.
2. Install new seal kit components. Install all seals on the head and piston using the non-sharp seal tool.
3. Place a small amount of fluid on the inside seals of the head and reinstall it on the shaft, by slipping head over the piston end of the shaft being very careful not to damage the inside seals.
4. Place a small amount of fluid on the inside seals of the piston and reinstall it on the shaft by slowly twisting the piston on over the threads of the shaft being very careful not to damage the inside seals.
5. Reinstall the shaft nut; torque 1 ½" nut to 160 ft. lbs. (216 Nm).
6. Grease the outside seals of the head and piston.
7. Reinstall the shaft into the barrel of the cylinder and push in until groove of the head lines up with the slot in the barrel.
8. Reinstall the cylinder retainer. Installation is reverse of removal.
9. Cycle the cylinder using air to check for proper operation.

NOTE: It is very important to keep all parts clean when working with hydraulic cylinders, even one small piece of dirt or grit can damage the cylinder.

OPTIONAL OUTRIGGERS

NOTE: Refer to *Section 3* for detailed description and troubleshooting.
Refer to *Cylinder Repair*.


OUTRIGGER HYDRAULIC MANIFOLD

The Optional outrigger manifold is located in the Control Module behind the Lower Control Box.

CYLINDERS

Four (4) double acting type hydraulic cylinders.


Figure 1-14: Outrigger Hydraulic Connections



OPTIONAL GENERATOR

NOTE: Refer to Section 6,
Refer to Parts Sections E and F

Figure 1-15: Optional Generator Connections





Section 2

ELECTRICAL SYSTEM

| CONTENTS | PAGE |
|---|-------------|
| Electrical System – General | 2-2 |
| Deutsch Connectors | 2-3 |
| Battery | 2-4 |
| Battery Maintenance (in storage) | 2-4 |
| Battery Maintenance (in use) | 2-5 |
| Battery Replacement | 2-6 |
| Alarms and Switches | 2-7 |
| Emergency Stop Button | 2-7 |
| Master Disconnect Switch | 2-7 |
| Movement Alarm - Light (optional) | 2-7 |
| Platform / Base Selector key Switch | 2-8 |
| Diagnostic LEDs | 2-8 |
| Relays | 2-9 |
| Limit Switch | 2-10 |
| Height Sensor | 2-10 |
| Optional Outriggers Switches | 2-11 |
| Continuity Checks | 2-12 |

| FIGURES | PAGE |
|---|-------------|
| Figure 2-1: Deutsch Connectors | 2-3 |
| Figure 2-2: Upper Controls | 2-7 |
| Figure 2-3: Lower Controls | 2-8 |
| Figure 2-4: Diagnostic LEDs | 2-8 |
| Figure 2-5: Relay Locations | 2-9 |
| Figure 2-6: Limit Switch | 2-10 |
| Figure 2-7: Height Sensor | 2-10 |
| Figure 2-8: Outrigger Cylinder Switches | 2-11 |
| Figure 2-9: Relay Operation | 2-12 |
| Figure 2-10: Limit Switch Operation | 2-12 |



ELECTRICAL SYSTEM – GENERAL

The electrical control system consists of a base control station and a platform control station.

BASE CONTROL STATION

The base control station, when enabled via the Base/Platform Selector Switch, disables the platform station and provides control for a fixed speed Lift UP/DOWN functionality.

PLATFORM CONTROL STATION

The platform control station will operate all functions including drive/steer and lift/lower. Momentary bidirectional rocker switch on the drive controller handle (joystick) provides the steering function. The control system for operation of drive/steer and lift/lower are electric-over-hydraulic type. The drive and lift system is a proportional system controlled by position and direction of the upper control box controller handle (joystick).

DEUTSCH CONNECTORS

Deutsch connectors used on MEC equipment is designed so that individual parts may be replaced without replacing the entire component. Special tools and detailed instructions are provided in Deutsch Connector field kits, MEC part no. 84091.

Figure 2-1: Deutsch Connectors

MALE PLUG CONNECTOR

- Use the flat end of the Removal Tool or a flat blade screwdriver to pry the locking wedge from the connector, taking care not to damage the Sealing Gasket.
- Inspect and replace damaged parts.
- Replace or re-crimp wires and contacts.

FEMALE RECEPTACLE CONNECTOR

- Use the notched end of the removal tool or a wire hook to pull the locking wedge from the connector
- Replace worn or damaged parts
- Replace or re-crimp wires and contacts.

LOCKING FINGERS


- Remove the locking wedge as outlined above.
- Using the removal tool or a flat blade screwdriver, push the Locking Fingers aside to release the contact.
- Pull the wire and contact out of the connector.

HEAVY DUTY PLUG

- Slide the removal tool along the wire to be replaced and push into the connector to release the contact.
- Pull the wire and contact out of the plug.

CRIMPING

- Strip 1/4 in. (6 mm) insulation from the wire.
- Insert the contact into the crimping tool and insert the stripped wire into the contact making sure no wires are outside the contact barrel.
- Close the handles of the crimping tool, then release the handles to remove the crimped contact.



BATTERY



CHARGING BATTERIES CREATE EXPLOSIVE HYDROGEN GAS. KEEP SPARKS, FLAMES AND SMOKING MATERIALS AWAY FROM BATTERIES. ALWAYS WEAR SAFETY GLASSES WHEN WORKING WITH BATTERIES.

BATTERY FLUID IS CORROSIVE. THOROUGHLY RINSE SPILLED FLUID WITH CLEAN WATER.

REPLACE WITH MANUFACTURER APPROVED BATTERIES.

BEFORE DISCONNECTING THE BATTERY NEGATIVE (-) LEAD, MAKE SURE THAT ALL SWITCHES ARE OFF. IF ON, A SPARK WILL OCCUR AT THE GROUND TERMINAL THAT COULD IGNITE HYDROGEN GAS OR FUEL VAPORS.

A 12 volt battery supplies the electrical power required to start the engine and operate the electrical circuits.

BATTERY MAINTENANCE (IN STORAGE)

Follow these procedures for maintenance of battery on a machine not in use:

- Keep battery clean. Electrolyte of batteries should be checked regularly and kept at proper level.
- Never stack one battery directly on top of another because post or container damage can result. If batteries are stored individually, place supporting boards between layers. Rotate stock so that the oldest batteries are used first.
- Batteries should be kept fully charged. A battery, while in storage, should be recharged to full charge at recommended intervals.

A BATTERY FULLY (100%) CHARGED AT 80°F (26.6°C)

- drops to 65% at 32°F (0°C)
- drops to 40% at 0°F (-32°C)

Table 2-1: Recommended Battery Charge Intervals

| If Stored At | Recharge |
|---------------------|-----------------|
| Below 40°F (4°C) | None required |
| Above 60°F (15°C) | Every month |
| 40°-60°F (4°-15°C) | Every 2 months |

BATTERY MAINTENANCE (IN USE)

Check battery and surrounding area for signs of damage or corrosion.

Check battery terminals for:

- **Corrosion:** Regularly clean connections and apply a nonmetallic grease or protective spray to retard corrosion.
- **Loose connections:** Be sure all cable connections are tightly secured, and that good contact is made with terminals.
- **Broken or frayed cables:** Be sure all connections are good and that no loose or broken wires are exposed. Replace as necessary.

Check battery electrolyte level. Replenish the electrolyte, if necessary. Remove vent caps before filling, and **USE ONLY DISTILLED WATER. DO NOT OVERFILL.** Fill to level indicator (or ½ inch over the top of separators, if there is no level indicator). Fill after charging to prevent overflow of acid due to expansion. Do not use a hose to add water to batteries.

Allowing the electrolyte level to drop below the top of the separators will lead to shortened battery life.

Excessive water usage can indicate that a battery has been overcharged, has been subjected to excessively high temperatures, or is nearing the end of its service life.

BATTERY PREVENTATIVE MAINTENANCE:

Every 15 hours (after battery has been charged), spot-check the specific gravity of two or more cells. A fully charged battery should indicate 1.28 specific gravity. If low readings are noted, check the following:

- Check terminals for corrosion, loose connections and broken or frayed cables.
- Check all cells with a hydrometer for variance in specific gravity. A variation of 0.03 points or more between cells is a cause for concern. Mark the low cells.

Recheck specific gravity of all cells after recharging. Wash the top of the battery, making sure all vents are in place. Do not allow cleaning water or other foreign matter to enter the cells. Use a solution of bicarbonate soda (5 tsp. of baking soda per quart of warm water) and water to wash the battery if there is an accumulation of acid.

Table 2-2: Battery Specific Gravity and Voltage

| | Specific Gravity | Volts DC | |
|------------------|------------------|----------|-------------|
| | Each Cell | Per Cell | 12V Battery |
| Fully Charged | 1.280 | 2.10 | 12.60 |
| Fully Discharged | 1.130 | 1.75 | 10.50 |

BATTERY REPLACEMENT



BEFORE REMOVING THE BATTERY FROM THE MACHINE, TURN OFF THE MAIN POWER SWITCH.



Prevent damage to the battery and/or electrical system;

- **Always disconnect the negative battery cable first.**
- **Always connect the positive battery cable first.**


Always disconnect the negative battery cable first.

Remove bolts holding battery. Lift the battery from the compartment. Put the battery to the side and dispose of properly.

To install battery, reverse the process by positioning the battery in the compartment securely with hold down bolts. Connect battery cables. Always connect the positive cable first.

ALARMS AND SWITCHES

Figure 2-2: Upper Controls



EMERGENCY STOP BUTTON

There are two red emergency stop buttons: one located on the platform control console and the other on the base control panel. This stop button, when in the “OUT” (ON) position, provides power to the desired control station. Also, the stop button, in the event of an emergency can be used to turn off the power by pushing “IN” (OFF). All functions stop immediately when button is depressed.

Turn the button clockwise to reset.

NOTE: As a safety feature, selecting and operating the base controls will override all platform controls, except for the platform emergency stop button.

The base control emergency stop button will stop all machine operations, even if the selector switch is switched to platform controls.

MASTER DISCONNECT SWITCH

Battery disconnect is provided in the Control Module to facilitate servicing and also to prevent unauthorized use of vehicle by using a padlock (to provide security).

MOVEMENT ALARM - LIGHT (OPTIONAL)


This light is activated as soon as the platform control console joystick (controller) lever is moved off the center “Neutral” position.



THE MOVEMENT ALARM IS PROVIDED FOR YOUR PROTECTION, AND PROTECTION OF PERSONS WORKING IN THE IMMEDIATE AREA. DISABLING THIS IMPORTANT SAFETY DEVICE MAY RESULT IN SERIOUS INJURY OR DEATH.

PLATFORM / BASE SELECTOR KEY SWITCH

Figure 2-3: Lower Controls




Machine can be operated from the base/ground or platform controls. Activation of one or the other is achieved with this switch.

With the platform controls selected, from the base control panel, if the platform up/lower function is operated there should be NO movement. Similarly with the base controls selected, from the platform control console if any machine function is operated, there should be NO movement.

DIAGNOSTIC LEDS

Figure 2-4: Diagnostic LEDs

There are Diagnostic LED's located on the Printed Circuit Board inside the Base Control box. Each LED represents a function. When the LED is ON the function is ENERGIZED. Refer to the *DIAGNOSTIC LED'S* label to identify the LED function.



RELAYS

There are relays located inside the control module and inside the Upper Controls. (Refer to the Section 5 for relay functions and interconnect).

TORQUE/SPEED RELAY

Purpose – Disperses power to Torque Solenoid Valve when high speed or low speed is selected.

OUTRIGGER RELAY (OPTION)

Purpose – Cuts power to Lift circuits until Outriggers are fully deployed and in firm contact with the ground.

THROTTLE RELAY

Purpose – The electric throttle solenoid receives its power through the Throttle Relay.


GLOW PLUG RELAY

Purpose – The diesel engine glow plug receives its power through the Glow Plug Relay.

UPPER CONTROL POWER RELAY

Purpose – Cuts power to Upper Controls when Lower Controls are selected.

Figure 2-5: Relay Locations



LIMIT SWITCH

The Limit Switch indicates Platform Height above approximately 10 feet (3 m). The switch operates in conjunction with the circuit board located in the lower control box and the proportional circuit board located in the upper control box.

LOWER CONTROLS CIRCUIT BOARD FUNCTION

When the platform is elevated above 10 feet (3 m). The limit switch is depressed and opened, causing the circuit board to;

- enable tilt sensor cutout operation.
- lock-out high torque and high speed.
- lockout outrigger operation.
- prevent drive when axle is not centered.

UPPER CONTROLS PROPORTIONAL CIRCUIT BOARD FUNCTION

When the platform is elevated above 10 feet (3 m). The limit switch is depressed and opened, causing the proportional circuit board to;

- limit proportional output to approximately 25% in drive (elevated drive speed).

HEIGHT SENSOR

The Height Sensor works in conjunction with the Load Sense Control Module to prevent operation when the platform is overloaded.

Figure 2-6: Limit Switch





Figure 2-7: Height Sensor



OPTIONAL OUTRIGGERS SWITCHES

If the machine is equipped with outriggers, each of the four (4) outriggers has a Stowed Switch and a Pressure Switch.


OUTRIGGER STOWED SWITCH

- Indicates full retraction of the outrigger cylinder.
- **Drive Function:** The machine will drive when the Outrigger Stowed Switch on all four (4) outriggers is engaged. If one (1) or more Outrigger Stowed Switch is open (not engaged) the machine *will not drive*.
- **Lift Function:** If one (1) or more Outrigger Stowed Switch is open (not engaged) the machine *will not lift* unless all four (4) outriggers are fully deployed.

OUTRIGGER PRESSURE SWITCH

- Indicates full deployment of the outrigger.
- **Lift Function:** When deployment begins the Outrigger Stowed Switches open and lift function is disabled. When all four (4) outriggers reach full deployment the Outrigger Pressure Switches close (engage) and lift function is restored.

Figure 2-8: Outrigger Cylinder Switches



CONTINUITY CHECKS

CHECK TOGGLE SWITCH:

- Disconnect wires and connect one probe of ohm meter to the connection on toggle switch and other probe on other connection.
- When toggle is open, there should be no reading, and when closed there should be a low reading.

CHECK SELECTOR SWITCH

- Disconnect wires and connect one probe to common of switch and the other to normally open terminal.
- With the switch flipped, there should be a low resistance.

CHECK EMERGENCY STOP BUTTON

- Disconnect wires and connect one probe of ohm meter to connection on button and other probe on other connection.
- There should be no reading with the button pressed and a low resistance with it reset.

CHECK RELAY OPERATION

- With the #85 terminal grounded, apply voltage to #86 terminal connection.
- Confirm normally closed (#87A) contacts are opening. Continuity with #30 will be broken.
- Confirm normally open (#87) contacts are closing. Continuity with #30 will be made.

CHECK LIMIT SWITCH OPERATION

- Loosen cover screw and lift cover from switch.
- Mark and disconnect wires.
- With one probe of ohm meter to “A” and other probe to “B”, release the plunger.
 - Low resistance should be seen. Same result should be seen between “C” and “D”.
- With one probe of ohm meter to “A” and other probe to “B”, depress the plunger.
 - High resistance should be seen. Same result should be seen between “C” and “D”.
- “E” and “F” should show opposite results as seen on previous tests though there may not be any circuits on these terminals.

Figure 2-9: Relay Operation





Figure 2-10: Limit Switch Operation





Section 3

OVERLOAD SENSING SYSTEM

| CONTENTS | PAGE |
|-----------------------------------|-------------|
| General Description | 3-2 |
| Troubleshooting | 3-4 |
| GP102 - EZcal Help Messages | 3-4 |
| GP102 LED Flash Codes | 3-7 |
| Calibration | 3-8 |
| Calibration Troubleshooting | 3-11 |
| Failure Messages | 3-11 |
| Information Messages | 3-16 |

| FIGURES | PAGE |
|------------------------------------|-------------|
| Figure 3-1: EZcal Connection | 3-2 |

GENERAL DESCRIPTION

In combination with a height sensor to measure platform height and a pressure sensor to measure lift cylinder load, the GP102 control module calculates an estimate of load and prevents scissor vehicle operation when its platform is overloaded. The system also includes an integrated tilt sensor provides a warning alarm for tilted condition. In addition the automatic armguard cutout and descent alarm are controlled by this system. To access the control module for troubleshooting and calibration, the **EZcal** hand held device is required. These are available from MEC Aerial Platform Sales Corp.



ONLY TRAINED AND AUTHORIZED PERSONNEL SHALL BE PERMITTED TO CALIBRATE THE PLATFORM OVERLOAD SENSING SYSTEM. READ ALL INSTRUCTIONS CLOSELY BEFORE ATTEMPTING EACH STEP OF THE CALIBRATION PROCEDURE.

Figure 3-1: EZcal Connection





ILLUSTRATION No.
ART_2780



Table 3-1: Electrical Connections

| | | |
|--|---|--|
| P1 | Connects to EZcal hand-held device for diagnostics and calibration. | |
| P2 (J17) | Connects to power supply and function switches | |
| | (J) P2-1 | no connect |
| | (J) P2-2 | no connect |
| RED/BLU 304 | (J) P2-3 | “UP” valve (B+ when UP requested) |
| YEL/BLU 105 | (J) P2-4 | “DOWN” valve (B+ when DOWN requested) |
| | (J) P2-5 | no connect |
| | (J) P2-6 | no connect |
| GRY/RED 111 | (J) P2-7 | “FWD” Valve (B+ when Forward commanded) |
| GRY/BLK 110 | (J) P2-8 | “REV” Valve (B+ when Reverse commanded) |
| | (J) P2-9 | no connect |
| TAN/ORG 2 | (J) P2-10 | “PLATFORM ELEVATED” indication (B+ when platform stowed) |
| BLK 15 | (J) P2-11 | SUPPLY NEGATIVE (connected to B-) |
| RED/WHT 201 | (J) P2-12 | SUPPLY POSITIVE (connected to B+) |
| P3 (J16) | Provides outputs for cutout alarms, lamp, and relay | |
| TAN 12 | (J) P3-1 | Tilt Sensor to Lower Control Box (B+ when not tilted) |
| BLU/WHT 72 | (J) P3-2 | Platform and Base Alarm |
| BLK/RED 74 | (J) P3-3 | OVERLOAD LAMP output (off normally, turns on to indicate overload) |
| RED/BLK 44 | (J) P3-4 | Cutout Relay output (B+ when not overloaded) |
| BLK 15 | (J) P3-5 | Cutout Relay B- (internally linked to P2-11) |
| | (J) P3-6 | no connect |
| P4 | Connects to lift cylinder pressure sensor and height sensor | |
| | (J) P4-1 | no connect |
| ORG/GRN 42 | (J) P4-2 | pressure sensor (0.5V...4.5V analog) |
| ORG/RED 43 | (J) P4-3 | height sensor (1V...4V analog) |
| | (J) P4-4 | no connect |
| | (J) P4-5 | no connect |
| GRY 46 | (J) P4-6 | B+ protected supplies for pressure sensor |
| BLK 15 | (J) P4-7 | B- for pressure sensor |
| BLK 15 | (J) P4-8 | B- protected supplies for height sensor |
| BRN/YEL 49 | (J) P4-9 | B+ for height sensor |
| <i>(J)= plug identification as it corresponds to the electrical schematic diagram.</i> | | |
| J18 | Cutout Relay Connections | |
| BLK 15 | 30 | |
| RED/BLK 44 | 85 | |
| BLK 15 | 86 | |
| BLK/BLU 158 | 87 | |

TROUBLESHOOTING

GP102 - EZCAL HELP MESSAGES

When the **EZcal** hand-held device is connected to the **GP102** control module, the first menu available is "HELP" - just press the **ENTER** button to see a message describing the current status of the **GP102**; this This will provide the best information when troubleshooting the load sense system.

When an **EZcal** is unavailable, an LED on the **GP102** flashes to provide limited diagnostics. Refer to **GP102 LED Flash Codes** in this section.

The following messages may be displayed on the Ezcal display.

EVERYTHING OK

The **GP102** detects no problems.

If problems are being experienced with the system, use the **DIAGNOSTICS** menus to check for faulty sensors and/or switches. LED on steady.

ARMGUARD ACTIVE!

The **GP102** has stopped descent at the Armguard height, and is delaying for 5 seconds to "give the operator the opportunity to see whether persons ... could be injured" (per EN 280 5.4.4). Vehicle movement will continue to be stopped after the delay until all functions are released. LED flash code 4.

B+ SUPPLY TOO LOW

The **GP102** is designed for use on 12V and 24V battery powered vehicles; it cannot operate with a supply below about 9V. The "BATTERY" voltage can be checked in the "SENSORS" menu (available in the "DIAGNOSTICS" menu). LED flash code 7.

DRIVE/LIFT SELECT INPUTS FAULTY!

Neither the drive select (P2-7) nor the lift select (P2-8) input is active, or both are active – the **GP102** cannot determine the vehicle use.

All vehicle operation will be prevented until the problem is corrected. LED flash code 2.

ELEVATION SWITCH SHIFTED?

The **GP102** uses the elevation switch in combination with the height sensor to ensure correct functionality of both; any of the following faults may be detected:

- The elevation switch should change state near the point at which it did during load calibration All vehicle operation will be prevented until the problem is corrected. LED flash code 4.

ELEVATION SWITCH STUCK?

The **GP102** uses the elevation switch in combination with the height sensor to ensure correct functionality of both; any of the following faults may be detected:

- When the platform is elevated, the measured height should be above that stored during load calibration
- When the platform is not elevated, the measured height should be below that stored during load calibration

All vehicle operation will be prevented until the problem is corrected. LED flash code 4.

FACTORY OVERRIDE

To allow vehicle movement during manufacture, the **GP102** is delivered in a "FACTORY OVERRIDE" state which disables all functionality. The first load calibration (even if not completed) will terminate this state. LED flash code 15.

FAULT: BAD TILT SENSOR

The **GP102** has detected that its integral tilt sensor is faulty - the module may need to be replaced. **IMPORTANT:** If the **GP102** is installed incorrectly, this fault may occur erroneously. LED flash code 8.

HEIGHT NOT CALIBRATED

During the first phase of load calibration ("DYNAMIC"), the **GP102** calibrates the minimum and maximum output of the height sensor so that platform height can be determined. This calibration must be successfully completed! LED flash code 1.

IDLE TIMEOUT ACTIVE!

If configured, the **GP102** will turn off all its outputs after a set time with no vehicle functions operated; this saves battery power and silences any alarm still sounding when the vehicle was left. Any vehicle function will end the idle timeout and restore normal operation of the **GP102** outputs. LED stays off.

INVALID HEIGHT - CHECK SENSORS

There is a problem that prevents the vehicle height being determined; there may be a fault with the height sensor, or the vehicle may have been modified or damaged since the last calibration occurred. All vehicle operation will be prevented until the problem is corrected. LED flash code 9.

INVALID LOAD - CHECK SENSORS

There is a problem which prevents the estimated load being determined; there may be a fault with the height sensor or the load sensor, or the vehicle may have been modified or damaged since the last calibration occurred. All vehicle operation will be prevented until the problem is corrected. LED flash code 6.

LOAD NOT CALIBRATED

During the second and third phases of load calibration ("LOADED" and "EMPTY"), the **GP102** calibrates the lift cylinder pressure at various heights corresponding to a fully loaded and unloaded platform. This calibration must be successfully completed! LED flash code 1.

NO LAST CALDATE!

At the end of load calibration, the **GP102** prompts for entry of the current date to aid in vehicle maintenance. A non-zero date must be entered! When load (re)calibration is begun, the last CALDATE is erased and cannot be re-entered until calibration is completed; this ensures that a partly calibrated vehicle cannot be operated. LED flash code 1.

P3-4 SHORT TO 0V?

The **GP102** startup tests detected that something is overloading the output on P3-4. All vehicle operation will be prevented until the problem is corrected. LED flash code 5.

P3-4 SHORT TO SUPPLY?

The **GP102** startup tests (or the continuous monitoring during any prevention of vehicle movement) detected that something is providing a permanent supply on P3-4 (defeating the internal cutout). All vehicle operation will be prevented until the problem is corrected. LED flash code 3.

TESTING HWFS

When the **GP102** is powered up, it carries out various tests to ensure that it is functioning safely.

TOO HIGH - DRIVE PREVENTED

A drive function has been selected but the platform is raised above the "MAX DRIVE" setting. (if enabled) The drive function will be prevented until the platform is lowered. LED flash code 8.

TOO HIGH - LIFT UP PREVENTED

The lift/up function has been selected but the platform is raised above the "MAX LIFT" setting. (if enabled) The lift/up function will be prevented until the platform is lowered. LED flash code 8.

UP/DOWN SELECT INPUTS ACTIVE TOGETHER!

The up select (P2-3 and/or P2-5) and the down select (P2-4 and/or P2-6) are active together - the **GP102** cannot determine the vehicle use. All vehicle operation will be prevented until the problem is corrected. LED flash code 2.

VEHICLE OVERLOADED

The estimated load in the platform exceeds the "OVERLOAD AT" setting in the "ADJUSTMENTS" "LOAD" menu. The **GP102** will activate the cutout to prevent vehicle operation until the platform load is reduced. LED flash code 8.

VEHICLE TILTED

Either the "X" or "Y" tilt (measured by the **GP102** integral tilt sensor) exceeds the "X TRIP" or "Y TRIP" setting in the "ADJUSTMENTS" "TILT" menu. LED flash code 8.

WAITING FOR B+ ON P2-12

The supply on P2-12 provides power for the outputs P3-1/2/3/4. The **GP102** cannot function if the supply is not present. Since the supply on P2-12 is switched to P3-4, vehicle operation will be prevented. LED flash code 7.

WAITING FOR NEUTRAL

When the **GP102** is powered up, all controls must be in neutral to allow safe testing of the failsafe output; no functions are allowed until testing is complete. LED flash code 2.

GP102 LED FLASH CODES

The **GP102** has a built-in LED to provide simple diagnostics when no **EZcal** is available. Please note that the use of an **EZcal** provides significantly better diagnostics through the HELP messages. An **EZcal** is also necessary to calibrate a **GP102**.

LED ON STEADY

This indicates no fault with the **GP102**

LED OFF ALWAYS

This indicates no power to the **GP102**, or idle timeout (if enabled - activate a lift or drive function to cancel the idle timeout)

LED FLASH CODE 1

This indicates the **GP102** has not been properly calibrated.

LED FLASH CODE 2

This indicates a fault with the switch inputs to the **GP102**. Check wiring to connector P2.

LED FLASH CODE 3

This indicates a fault with the shutdown outputs of the **GP102** - a short to the supply has been detected. Check wiring from pins P3-4.

LED FLASH CODE 4

This indicates that armguard is active, or that there is a fault with the elevation switch - the **GP102** verifies correct opening and closing of the elevation switch against the height sensor. Checking the elevation switch on P2-10. If the height sensor has been adjusted or replaced, repeat the CALIBRATE HEIGHT procedure.

LED FLASH CODE 5

This indicates a fault with the shutdown outputs of the **GP102** - a short to 0V (ground) has been detected. Check wiring from pins P3-4.

LED FLASH CODE 6

This indicates a fault with the load measurement - check the pressure sensor and wiring from it to connector P4.

LED FLASH CODE 7

This indicates a fault with the supply to the **GP102** - check battery supply at least 8V on pin P2-12; also check that there is not a short to 0V (ground) on pin P4-1.

LED FLASH CODE 8

This is not a fault - it indicates the **GP102** has prevented a function; functions can be prevented if the platform is overloaded, if the machine is tilted too far, or if the platform is too high.

LED FLASH CODE 9

This indicates a fault with the height measurement - check the height sensor and wiring from it to connector P4.

LED FLASH CODE 10

This indicates the **GP102** is carrying out startup tests.

LED FLASH CODE 15

This indicates the **GP102** is in "FACTORY OVERRIDE" and overload functions are disabled - this aids manufacture by allowing vehicle movement before the machine is built sufficiently to be calibrated. 15 flash will be present whenever a *new* circuit board is installed previous to calibration.

CALIBRATION

Before attempting the calibration procedure, the batteries must be fully charged and battery terminals clean and tight. Move machine to an area that is perfectly level as measured by a spirit level or other leveling device. An Ezcal hand-held device (MEC part # 90888) is required to carry out all calibration procedures on the **GP102** Load sense control module.

TILT SENSOR CALIBRATION

The integral tilt sensor of the **GP102** control module must be leveled to compensate for variations due to installation and vehicle construction. This procedure must be done if the lower control box is ever removed or repositioned, or if the **GP102** module is ever repositioned or replaced.

- a. Drive machine to level ground.
- b. Plug **EZcal** into connector P1 on load sense control module.
 - Display reads HELP: PRESS ENTER.
- c. Press right arrow to ACCESS LEVEL 3, Press Enter.
 - Display reads CODE 0000.
- d. Press up and right arrow to enter code 1775, Press Enter.
 - Display reads ACCESS LEVEL 2.
- e. Right arrow to SETUPS, Press Enter.
 - Display reads CHANGE DEFAULTS.
- f. Right arrow to TILT SETUPS, Press Enter.
 - Display reads CALIBRATE LEVEL.
- g. Press Enter.
 - Display reads CALIBRATE LEVEL: YES:ENTER,NO:ESC.
- h. Press Enter.
 - Display reads TILT 0.0',0.0' i. Press ESC, ESC, ESC j. Disconnect **EZcal** from the load sense module.

PLATFORM LOAD CALIBRATION

Platform load calibration must be done if there are ever any significant repairs to the scissor assembly or if the lift cylinder is removed and serviced or replaced. Also, if any of the components of the Platform Load Sense System are replaced, the system will need recalibration. During the calibration procedure the vehicle platform is fully raised and lowered three times:

1. DYNAMIC" calibration – fully loaded platform raised & lowered in one continuous movement. DYNAMIC measurements are taken.
2. LOADED" calibration – fully loaded platform raised & lowered with stops to take measurements. STATIC measurements are taken.
3. EMPTY" calibration – unloaded platform raised & lowered with stops to take measurements. STATIC measurements are taken.

The following procedure must be followed COMPLETELY to calibrate the **GP102**; throughout the procedure various checks are made – if any problem is detected the procedure stops and displays a FLASHING failure message. Explanations of each message and suggested corrections can be found in the section of this manual following the calibration procedure.

NOTE: If the calibration procedure is interrupted, completed phases do not need to be repeated. A "REDO" prompt will appear – answer "NO" if there is no reason to repeat the phase, or "YES" if the phase must be repeated (for example because the wrong platform load was used on the previous phase).

- a. Drive machine to level ground, in area where it can reach full elevation.
- b. Place rated load in platform.
- c. Turn selector switch to Base controls.
- d. Remove top cover off of lower control station box, and plug **EZcal** into connector P1 on load sense control module.

EZcal display reads HELP: PRESS ENTER

- e. Press right arrow to ACCESS LEVEL 3, Press Enter.
 - Display reads CODE 0000
- f. Press up and right arrow to enter code 1775, Press Enter.
 - Display reads ACCESS LEVEL 2.
- g. Press Right Arrow to SETUPS, Press Enter.
 - Display reads CHANGE DEFAULTS
- h. Press Enter to verify machine type. Press up and down arrows to change if necessary.
 - Display reads 1=1532, 2=1932, 3=2033 ...etc. Select appropriate model.
- i. Press Enter. Press Esc. Press Right Arrow to LOAD SETUPS. Press Enter.
 - Display reads CALIBRATE LOAD
- j. Press Enter.
 - Display reads PLATFORM DOWN? Verify that platform is fully lowered.
- k. Press Enter.
 - Display reads PLATFORM LOADED? Verify that rated load is in platform.
- l. Press Enter.
 - Display reads PLEASE LIFT. Hold lower controls switch in the up position until machine is fully elevated, then release switch.
 - Display reads PLEASE LOWER. Hold switch in down position until platform is in the fully lowered position. Release switch. Display reads PLATFORM LOADED?
- m. Press Enter.
 - Display reads PLEASE LIFT. Hold lower controls switch in the up position until machine is fully elevated, then release switch.

NOTE: The platform will lift incrementally during this phase of the calibration. Every third lift cycle the platform will fail to lift even though the circuit is initiated. When this occurs, release the lift switch for 1 second (or more) then reapply. The platform should then rise normally for another two cycles.

- Display reads TOTAL DATA #XX, then PLEASE LOWER. Hold switch in down position until platform is in the fully lowered position. Note: The platform will lower incrementally during this phase on the calibration. Do not release the switch until fully lowered. Release switch.
- Display reads TOTAL DATA #XX, then PLATFORM EMPTY?

NOTE: At this time the load in the platform must be removed. It is best to remove it without moving the machine. If you must switch to platform controls to move the machine, steps a.] through g.] must be repeated. Steps j.] through m.] will generate the REDO prompt. Answer NO. If machine was not moved, proceed to step n.]

- n. Press Enter.
 - Display reads PLEASE LIFT. Hold lower controls switch in the up position until machine is fully elevated, then release switch.

NOTE: The platform will lift incrementally during this phase of the calibration. Every third lift cycle the platform will fail to lift even though the circuit is initiated. When this occurs, release the lift switch for 1 second (or more) then reapply. The platform should then rise normally for two cycles.

- Display reads TOTAL DATA #XX, then PLEASE LOWER. Hold switch in down position until platform is in the fully lowered position.

NOTE: The platform will lower incrementally during this phase on the calibration. Do not release the switch until fully lowered. Once fully lowered, release switch.

- Display reads TOTAL DATA #XX, then BUILDING TABLES, then CALDATE mm/dd/yy.
- o. Enter current date using Up, Down and Right Arrows.
- Display reads FINISHED.
- p. Disconnect **EZcal** from the load sense control module. The Platform Overload Sensing System is now calibrated.

HEIGHT CALIBRATION

The height sensor must be calibrated if the height limit switch (LS-1 on electrical schematic) is ever replaced or adjusted. It is not necessary to redo the load calibration if the limit switch is all that was serviced. For this procedure it is not necessary to place any load in the platform.

- a. Drive machine to level ground, in area where it can reach full elevation.
- b. Turn selector switch to Base controls.
- c. Remove top cover off of lower control station box, and plug **EZcal** into connector P1 on load sense control module. **EZcal** display reads HELP: PRESS ENTER
- d. Press right arrow to ACCESS LEVEL 3, Press Enter.
 - Display reads CODE 0000
- e. Press Up and Right Arrow to enter code 1775, Press Enter.
 - Display reads ACCESS LEVEL 2.
- f. Press Right Arrow to SETUPS, Press Enter.
 - Display reads CHANGE DEFAULTS
- g. Press Right Arrow to HEIGHT SETUPS, Press Enter.
 - Display reads CALIBRATE HEIGHT
- h. Press Enter.
 - Display reads PLATFORM DOWN? Verify that platform is fully lowered.
- i. Press Enter.
 - Display reads PLEASE LIFT. Hold lower controls switch in the up position until machine is fully elevated, then release switch. Display reads PLEASE LOWER. Hold switch in down position until platform is in the fully lowered position. Release switch. Display reads FINISHED.

CALIBRATION TROUBLESHOOTING

FAILURE MESSAGES

During calibration, various problems can be detected by the that prevent successful calibration. These problems are reported with a flashing message including an “F” code. The following descriptions are helpful in solving the problem:

F01:CHECK HWFS

This message is given if the startup tests have not completed.
Check HELP message for more information.

F02:NOT GROUND MODE

This message is given if the machine is not in ground mode (P2-2 must be high). Calibration can only be carried out in ground mode.

F03:NOT STOPPED

This message is given if any function switch is closed. Check DIAGNOSTICS / SWITCHES to see which function switch is closed.

F04:TILTED

This message is given if the machine is tilted. Calibration must be carried out with the machine level. If the machine is level, perform the Tilt Calibration procedure above.

F05:BAD HEIGHT

This message is given if the height sensor output (P4-3) is out of range at the start of calibration. The height sensor output must be between 1.0V and 4.0V. Check DIAGNOSTICS / SENSORS to see the output. A reading of 0V or 5V is probably due to a wiring problem.

F06:CHECK ELEV

This message is given if the elevation switch (P2-10) is open at the start of calibration, when the operator has confirmed the “PLATFORM DOWN?” question.
If the platform is down, check the elevation switch wiring.

F08:CHECK ELEV

This message is given if the elevation switch (P2-10) is closed at the end of the DYNAMIC lift, when the platform should be fully raised.

This message would occur if the UP switch was accidentally opened near the start of the DYNAMIC lift.

If the platform is fully raised, check the elevation switch wiring.

F09:BAD HEIGHT

This message is given if the height sensor output (P4-3) is out of range at the start of the DYNAMIC lift. The height sensor output must be between 1.0V and 4.0V. Check DIAGNOSTICS / SENSORS to see the output. This is usually due to a wiring problem.

F10:BAD HEIGHT

This message is given if the height sensor output (P4-3) is out of range at the end of the DYNAMIC lift. The height sensor output must be between 1.0V and 4.0V. Check DIAGNOSTICS / SENSORS to see the output. A reading of 0V or 5V is probably due to a wiring problem.

F11:NOT UP

This message occurs at the start of the DYNAMIC lift if the operator selects a function other than UP.

F12:TOO MANY

This message occurs if the DYNAMIC lift takes too long.

This message could occur if the UP switch was not released at the end of the dynamic lift.

F13:LOW HEIGHT RANGE

This message occurs at the end of the DYNAMIC lift if the height sensor output did not change sufficiently to give a reasonably accurate platform height estimate. DIAGNOSTICS / SENSORS can be used to check the height sensor output (P4-3) when the platform is fully lowered and fully raised; a difference of at least 1V is to be expected.

This message could occur if the UP switch was accidentally opened too early (when the platform is not fully raised).

F14:BAD HEIGHT

This message occurs if the height sensor output (P4-3) is out of range during the DYNAMIC lift. The height sensor output must be between 1.0V and 4.0V. Check DIAGNOSTICS / SENSORS to see the output. A reading of 0V or 5V is probably due to a wiring problem.

F15:CHECK ELEV

This message is given if the elevation switch (P2-10) is open when the platform has been fully lowered after the DYNAMIC lift.

This message would occur if the DOWN switch was accidentally opened before the platform was fully lowered.

If the platform is fully lowered, check the elevation switch.

F16:LOW ELEV.OPEN

This message is given if the elevation switch (P2-10) opened during lift at a too low height (below 5%). Check CALIBRATIONS / HEIGHT CALS; the "ElevUp" value shows the recorded height where the switch opened.

F17:HIGH ELEV.OPEN

This message is given if the elevation switch (P2-10) opened during lift at a too high height (above 25%).

Check CALIBRATIONS / HEIGHT CALS; the "ElevUp" value shows the recorded height where the switch opened.

F18:LOW ELEV.CLOSE

This message is given if the elevation switch (P2-10) closed during lower at a too low height (below 5%).

Check CALIBRATIONS / HEIGHT CALS; the "ElevDown" value shows the recorded height where the switch opened.

F19:HIGH ELEV.CLOSE

This message is given if the elevation switch (P2-10) closed during lower at a too high height (above 25%).

Check CALIBRATIONS / HEIGHT CALS; the "ElevUp" value shows the recorded height where the switch opened.

F20:HEIGHT<>0%

F21:HEIGHT<>0%

This message occurs if the platform height is not 0% after the platform has been fully lowered at the end of a calibration step. The platform must return to the same height each time it is fully lowered.

Check DIAGNOSTICS / SYSTEM to check the height.

F22:HEIGHT<>100%
F23:HEIGHT<>100%

This message occurs if the platform height is not 100% after the platform has been fully raised during a calibration step. The platform must return to the same height each time it is fully raised. Check DIAGNOSTICS / SYSTEM to check the height.

F24:TOO MANY

This message occurs if too many static measurements are taken during a calibration step. In the rare event that this occurs, please call MEC for assistance.

F25:CHECK ELEV
F26:CHECK ELEV

This message indicates a problem with the elevation switch (P2-10) during the STATIC phases.

The switch is either staying closed to a higher height, or staying open to a lower height, than that recorded during the DYNAMIC phase.

F27:BAD HEIGHT

This message indicates a problem with the height sensor output (P4-3) during the STATIC calibration phases.

The height sensor output must be between 1.0V and 4.0V at all times.

Check DIAGNOSTICS / SENSORS to see the output. A reading of 0V or 5V is probably due to a wiring problem.

F30:BAD HEIGHTS

This message indicates that the recorded heights are not increasing during either STATIC lift, or are not decreasing during either STATIC lower.

It may be possible to cause this problem by repeatedly opening and closing the UP or DOWN switch during the STATIC phases.

F31:REJECT CURVE

The DYNAMIC pressure curve is unacceptable.

An initial pressure peak when the platform lifted cannot be found between 0% and 15% height.

Check the pressure sensor and lift cylinder hydraulics.

F32:REJECT CURVE

The DYNAMIC pressure curve is unacceptable.

There should be a lowest pressure about halfway through the lift (ie: near 50% height); the lowest pressure measured is at too low a height.

Check the pressure sensor and lift cylinder hydraulics.

F33:REJECT CURVE

The DYNAMIC pressure curve is unacceptable.

There should be a lowest pressure about halfway through the lift (ie: near 50% height); the lowest pressure measured is at too high a height.

Check the pressure sensor and lift cylinder hydraulics.

F34:REJECT CURVE

The DYNAMIC pressure curve is unacceptable.

There is not enough difference between the initial pressure peak and the minimum pressure.

Check the pressure sensor and lift cylinder hydraulics.

F40:REJECT DELTA

This message indicates that there is not enough difference between the loaded & empty pressure.

This message could occur if the platform were not properly loaded during the STATIC LOADED phase, or if the platform were not properly empty during the STATIC EMPTY phase.

This message could also occur if the wrong pressure sensor was fitted (eg: a 5000psi sensor when a 2000psi one is needed).

Check CALIBRATIONS / HEIGHT CALS; the "Height" indicates the first height at which there was insufficient difference and the "Up" and "Down" values show the loaded pressure (first) and the difference between loaded and empty pressure (second).

F42:LOW PRESSURE

This message indicates that the pressure is too low (0.5V or less) when the elevation switch opens during the DYNAMIC lift.

This message would occur if the pressure sensor was disconnected, or if there were some other wiring error.

Check DIAGNOSTICS / SENSORS to check the pressure.

F43:HIGH PRESSURE

This message indicates that the pressure is too high (4.5V or more) when the elevation switch opens during the DYNAMIC lift.

This message would occur if the wrong pressure sensor was fitted, or if there were some other wiring error.

Check DIAGNOSTICS / SENSORS to check the pressure.

F44:LOW PRESSURE

This message indicates that the pressure is too low (0.5V or less) at a STATIC measurement point.

This message would occur if the pressure sensor was disconnected, or if there were some other wiring error.

Check DIAGNOSTICS / SENSORS to check the pressure.

F45:HIGH PRESSURE

This message indicates that the pressure is too high (4.5V or more) at a STATIC measurement point.

This message would occur if the wrong pressure sensor was fitted, or if there were some other wiring error.

Check DIAGNOSTICS / SENSORS to check the pressure.

F46:CHECK ELEV

This message indicates that the elevation switch opened more than once during the DYNAMIC lift.

F47:CHECK ELEV

This message indicates that the elevation switch closed more than once during the DYNAMIC lower.

F48:BAD PRESSURE

This message is given if the pressure sensor output (P4-2) is out of range at the start of calibration.

The height sensor output must be between 0.5V and 4.5V.

Check DIAGNOSTICS / SENSORS to see the output. A reading of 0V or 5V is probably due to a wiring problem.

INFORMATION MESSAGES

During calibration the following messages may be displayed:

BUILDING TABLES

This message indicates that the STATIC measurements are being used to build calibration data - the process should take no more than 5s.

CALDATE:

This message is prompting for the date to be entered; it is stored to identify when the machine was calibrated.

The last calibrate date can be viewed in DIAGNOSTICS / LOG.

Press LEFT & RIGHT to select the flashing digits.

Press UP & DOWN to change the flashing digits.

Press ENTER when the entry is complete.

IMPORTANT: The date 00/00/00 is not allowed!

FINISHED

This message confirms that calibration is complete and successful.

GO DOWN MORE!

This message occurs if the DOWN switch is released during either STATIC lowering phase, when more measurements are needed (before the platform is fully lowered).

GO UP MORE!

This message occurs if the UP switch is released during either STATIC lifting phase, when more measurements are needed (before the platform is fully raised).

LIFT EMPTY

This message is displayed during the STATIC empty phase while the platform is being raised to the next measurement height.

LIFT LOADED

This message is displayed during the STATIC loaded phase while the platform is being raised to the next measurement height.

LIFTING

This message is displayed during the DYNAMIC phase while the platform is being raised.

LOWER EMPTY

This message is displayed during the STATIC empty phase while the platform is being lowered to the next measurement height.

LOWER LOADED

This message is displayed during the STATIC loaded phase while the platform is being lowered to the next measurement height.

LOWERING

This message is displayed during the DYNAMIC phase while the platform is being lowered.

MEASURING #

This message is displayed when the platform is stopped during either STATIC phase, when it takes a measurement.

There will be a short delay while the machine is allowed to stabilize after movement is stopped.

MUST GO DOWN!

This message occurs if the wrong switch is closed when the is waiting for the platform to be lowered.

MUST GO UP!

This message occurs if the wrong switch is closed when the is waiting for the platform to be raised.

PLATFORM DOWN?

This message is prompting for confirmation that the platform is fully lowered. If necessary the DOWN switch can be activated to lower the platform.

Press ENTER to confirm when the platform is fully lowered.

PLATFORM EMPTY?

This message is prompting for confirmation that the platform is completely empty.

Press ENTER to confirm when the platform is empty.

PLATFORM LOADED?

This message is prompting for confirmation that the platform is loaded to rated load (this will be 100% for the).

Press ENTER to confirm when the platform is loaded.

PLEASE LIFT ...

This message is prompting for the platform to be raised.

The UP switch should be closed.

PLEASE LOWER ...

This message is prompting for the platform to be lowered.

The DOWN switch should be closed.

PLEASE WAIT

This message indicates that the is busy; the delay will be short (no more than 5s).

REDO DYNAMIC:

This message is displayed if the DYNAMIC phase of load calibration has previously been completed.

Press ENTER when "NO" is displayed if there is no need to redo the DYNAMIC phase.

Press UP or DOWN to display "YES" then press ENTER if it is necessary to redo the DYNAMIC phase.

If the previous DYNAMIC calibration was in error, or if the height or pressure sensor is replaced, it will be necessary to redo the DYNAMIC phase.

REDO EMPTY:

This message is displayed if the EMPTY phase of load calibration has previously been completed.

Press ENTER when "NO" is displayed if there is no need to redo the EMPTY phase.

Press UP or DOWN to display "YES" then press ENTER if it is necessary to redo the EMPTY phase.

If the previous EMPTY calibration was in error, or if the pressure sensor is replaced, it will be necessary to redo the EMPTY phase.

REDO LOADED:

This message is displayed if the LOADED phase of load calibration has previously been completed.

Press ENTER when "NO" is displayed if there is no need to redo the LOADED phase.

Press UP or DOWN to display "YES" then press ENTER if it is necessary to redo the LOADED phase.

If the previous LOADED calibration was in error, or if the pressure sensor is replaced, it will be necessary to redo the LOADED phase.

TOTAL DATA:

This message is displayed at the end of each phase, to confirm the number of measurements recorded by the .



Section 4

MECHANICAL COMPONENTS

| CONTENTS | PAGE |
|--|-------------|
| Mechanical Components | 4-3 |
| Base | 4-3 |
| Tires and Wheels | 4-3 |
| Drive Motors | 4-4 |
| Gear Reduction Torque Hubs | 4-6 |
| Steer Cylinder | 4-15 |
| Floating Axle Lock Cylinder | 4-16 |
| Hoses and Cables | 4-17 |
| Platform Removal | 4-17 |
| Lift Cylinder Removal and Installation | 4-18 |
| Scissor Beam Assembly | 4-19 |
| Engine Maintenance | 4-21 |
| Oil and Oil Filter | 4-21 |
| Air Filter Element | 4-21 |
| Fuel Filter | 4-22 |
| Idle Speed Adjustment | 4-22 |
| High Speed Adjustment | 4-22 |
| Throttle Solenoid Adjustment | 4-23 |
| Outrigger Function | 4-24 |
| Operational Characteristics | 4-24 |
| Outrigger Calibration | 4-25 |
| Outrigger Tilt Sensor Calibration | 4-26 |
| GP106 Outrigger Control Module Troubleshooting | 4-27 |
| Outrigger Module GP106 LED Flash Codes | 4-28 |



FIGURES**PAGE**

| | |
|--|------|
| Figure 4-1: Front Drive Motor | 4-4 |
| Figure 4-2: Rear Drive Motor | 4-5 |
| Figure 4-3: Brake Bleed | 4-6 |
| Figure 4-4: Torque Hub Torque Sequence | 4-6 |
| Figure 4-5: Torque Hub Brake | 4-7 |
| Figure 4-6: Torque Hub Brake Test | 4-8 |
| Figure 4-7: Torque Hub Brake and Seal Kit | 4-10 |
| Figure 4-8: Torque Hub End Cover | 4-11 |
| Figure 4-9: Torque Hub Disassembly | 4-12 |
| Figure 4-10: Torque Hub Bearings | 4-13 |
| Figure 4-11: Steering Cylinder Installation | 4-15 |
| Figure 4-12: Floating Axle Lock Cylinder | 4-16 |
| Figure 4-13: Platform Removal | 4-17 |
| Figure 4-14: Lift Cylinder Removal | 4-18 |
| Figure 4-15: Scissor Assembly Removal | 4-19 |
| Figure 4-16: Cable Routing | 4-20 |
| Figure 4-17: Diesel Engine – Oil Filter and Air Filter | 4-21 |
| Figure 4-18: Fuel Filter | 4-22 |
| Figure 4-19: Throttle Adjustments | 4-23 |
| Figure 4-20: Outrigger Calibration Setup | 4-25 |

MECHANICAL COMPONENTS

This section describes the major components of the machine and the steps required to service them.

BASE



When steam cleaning the base/undercarriage, cover electrical components to prevent water penetration.

Steam clean the base as necessary, and inspect all welds and brackets. Check for cylinder pins that turn in their mounting , which will indicate sheared retaining pins.

TIRES AND WHEELS

Inspect for cuts, chunking, side-wall damage, or abnormal wear. Any tire faults **MUST BE CORRECTED** before further machine operation. Refer to Parts sections for replacement tires.



FAILURE TO USE APPROVED PARTS MAY CAUSE DEATH OR SERIOUS PERSONAL INJURY.

NOTE: Replace tires with the correct tires to maintain the rating of the equipment.

CHANGING TIRES

Lift and support the machine – Refer to *Introduction* section for instructions and safety precautions.



FOAM FILLED TIRES ARE EXTREMELY HEAVY. CARE MUST BE TAKEN TO AVOID PERSONAL INJURY.



Always block the wheels before lifting the machine.

1. Chock tires on the opposite end of machine.
2. Before lifting the machine, break loose the lug nuts and leave them tight.
3. Lift and support the end of machine requiring a wheel change.
4. Remove lug nuts and pull the wheel off.
5. Install the replacement wheel, install lug nuts and tighten.
6. Lower the machine.
7. Tighten lug nuts to proper torque (Refer to machine specifications).
8. Remove the chocks.

DRIVE MOTORS

Refer to *Section 1* for repair information.

There are two (2) hydraulic drive motors on the front axle and two (2) hydraulic drive motors on the rear drive axle. These can be damaged or leaks may occur; repair or replace as necessary.



- Clean all fittings before disconnecting hoses.
- Tag hoses for proper reassembly.
- Plug all openings to prevent contamination.

FRONT DRIVE MOTORS


Remove Front Drive Motor

1. Lift and support the front end of machine.
2. Disconnect the cylinder end and tie-rod from the motor housing.
3. Turn the motor housing to gain access to the motor and hose assemblies.
4. Disconnect hose assemblies from drive motor.
5. Remove the cap screws and remove the drive motor.
6. Be careful not to damage or misplace O-ring.

Replace

Installation is reverse of removal.

Figure 4-1: Front Drive Motor



REAR DRIVE MOTOR

Remove Rear Drive Motor


1. Lift and support the rear end of machine.
2. Remove the wheel and remove cover on top of axle.
3. Disconnect hose assemblies from drive motor.
4. Remove the mounting bolts.
5. Rotate the motor until parts face up. Remove the motor.
6. Be careful not to damage or misplace O-ring.

Replace

Installation is reverse of removal.

NOTE: Use Loctite® on mounting bolts.

Figure 4-2: Rear Drive Motor



GEAR REDUCTION TORQUE HUBS

There are two (2) gear reduction hubs on the front axle and two (2) gear reduction hubs with brakes on the rear axle.

BLEED BRAKE ON MACHINE

1. Loosen the brake hose approximately one (1) turn.
2. Start the machine and operate drive very slowly until all air is purged from the hose.
3. Tighten the hose fitting and check for leaks.
4. Repeat on opposite side.

TORQUE HUB REPAIR

Remove torque hubs from machine and move to a clean work surface.

Remove

1. Remove the drive motor (see *Drive Motors* earlier in this section).
2. Support the torque hub and remove the six (6) mounting bolts.

Replace

Installation is reverse of removal. Use Loctite® on mounting bolts. Torque in steps.

1. Hand tighten mounting bolts in sequence.
2. Apply torque in sequence: 20 Ft. Lbs. (81 Nm).
3. Apply torque in sequence: 60 Ft. Lbs. (81 Nm).
4. Apply final torque in sequence: 95 Ft. Lbs. (130 Nm).

Figure 4-3: Brake Bleed





Figure 4-4: Torque Hub Torque Sequence



BENCH TEST TORQUE HUBS

Torque Hubs should be roll and leak tested before and after repair to ensure that the gears, bearings and seals are working properly.

NOTE: Release brake before performing the roll test.

RELEASE BRAKE

Brake can be released with hydraulic pressure or by compression.

Hydraulic Release

NOTE: Refer to *Brake Test* later in this section.

Compression Release

1. Install two (2) $\frac{1}{4}$ -20 x $\frac{5}{8}$ " flat head cap screws through the pressure plate and into the piston.
2. Tighten one screw, then the other, a little at a time. Alternate screws until the springs compress and there is no pressure on the retaining ring.

NOTE: Remove bolts before performing brake release test.

ROLL TEST

1. Release brake as previously described.
2. Apply constant force to roll the gears and check for smooth operation.

NOTE: It may be difficult to roll the motor. This is acceptable as long as operation is smooth and consistent.


3. If inconsistency or drag is detected, the gears are not rolling freely and should be examined.

LEAK TEST

The unit must be air tight. Leaks usually occur at pipe plugs, the main seal, or around O-rings.

1. Attach an air pressure gauge at the brake port.
2. Pressurize the unit to 10 psi (.69 bar) and allow it to equalize. Let it stand for 20 minutes. If the pressure drops a leak is present.
3. With the unit pressurized, brush a soap and water solution around fittings, O-rings and seals and watch for bubbles.
4. Replace faulty components.


Figure 4-5: Torque Hub Brake



BRAKE TEST

1. Connect hydraulic line from a hand pump to the brake port.
2. Ensure that the brake is set by trying to rotate the input shaft. It should not rotate.
 - To rotate the input shaft, insert a splined shaft or other tool that will engage the splines of the input coupling.
3. Bleed Brake.
 - Gradually increase hydraulic pressure while trying to rotate the input shaft (tire/housing) until the brake just starts to release. The pressure should be from 200 to 260 psi (13.8 to 17.9 bar).
 - Full release should occur at 280 psi (19.3 bar).
4. Check for leaks
 - Increase and maintain pressure to 1,000 psi (69 bar) for 30 seconds.
 - Leaks must be repaired.
5. Center the input coupling in the spindle, then release pressure.
 - This will make it possible to install the motor without releasing the brake.
6. Ensure that brake engages when pressure is released.

Figure 4-6: Torque Hub Brake Test



BRAKE REPAIR

Only the rear hubs have brakes. Remove torque hub and move to a clean work surface.



Wear eye protection.

Disassembly


NOTE: Refer to Figure 4-5: "Torque Hub Brake," on page 4-7

1. Compress the brake piston compression springs;
 - Install two (2) ¼–20 × 5/8" flat head cap screws (provided in brake kit) through the pressure plate and into the piston.
 - Tighten one screw, then the other, a little at a time. Alternate screws until the springs compress and there is no pressure on the retaining ring.
2. Use retaining ring pliers to remove the retaining ring.
3. Remove pressure plate;
 - Loosen one screw, then the other, a little at a time.
 - Alternate screws until the springs are loose.
 - Remove the cap screws and pressure plate.
 - Remove the compression springs.
4. Use air pressure to remove the brake piston;
 - Using an air hose, slowly and carefully pressurize the brake port until the piston is partially out of the piston bore.
 - Pull the piston the rest of the way out by hand.
5. Remove the backup rings and O-rings from the grooves in the piston.
6. Remove the reaction discs (rotors) and the friction discs (stators) from the brake cavity.

Assembly

1. Install brake kit;
 - Place a stator (friction disc) then a rotor (reaction disc) into the brake cavity, until there are nine (9) stators and eight (8) rotors (refer to illustration).
2. Install the brake piston seals;
 - Place the piston on a clean surface with the small opening facing upward.
 - Apply grease to the O-rings and backup rings.
 - Install the large diameter backup ring into the large diameter groove on the piston.
 - Install the large diameter O-ring on top of the backup ring.
 - Install and fully seat the small diameter O-ring into the small diameter groove on the piston.
 - Install the small diameter backup ring on top of the O-ring.
3. Insert the piston into the piston bore until it contacts the stator (friction disc).
4. Place the ten (10) springs into the piston.
5. Place the pressure plate on top of the springs and compress the springs (see *Step 1 of Disassembly*).
6. Install the retaining ring, making sure it is fully seated.
7. Remove the two (2) cap screws or the brake will not function.

Figure 4-7: Torque Hub Brake and Seal Kit



END COVER

Disassembly

Remove torque hub and move to a clean work surface.




Wear eye protection.

1. Drain fluid from torque hub. Note the condition and volume of the fluid.
2. Remove the retaining ring.
 - Pry the open end of the retaining ring out of the groove with a screwdriver.
 - Use pliers to pull the retaining ring completely out of the groove.
3. Remove the cover subassembly.
 - The unit can be carefully pressurized with air to pop the cover out of the unit.
4. Remove the large diameter O-ring from the groove in the cover.
5. Remove the two (2) bolts from the disengage cap and remove the disengage cap.
6. Pull the disengage rod out from the cover.
7. Use appropriate tool to remove the disengage O-ring from the internal groove in the cover.
8. Remove the O-ring plugs from the cover.

Figure 4-8: Torque Hub End Cover

Assembly

1. Grease the disengage O-ring and insert into the internal groove in the cover.
2. Install the disengage cap and torque bolts to 70–80 in. lbs (8–9 Nm).
3. Insert the disengage rod, either end first, into the hole in the cover until it touches the disengage cover.
4. Grease the face of the thrust washer and place in the cover making sure the tangs on the washer seat into the pockets on the cover.
5. Install the O-ring plugs into the cover. Hand tighten only.
6. Grease the cover O-ring and insert it into the groove in the cover.
7. Install the cover and the retaining ring, making sure that the retaining ring is fully seated.



REPLACE BEARINGS

Disassembly

Remove torque hub and move to a clean work surface.




Wear eye protection.

1. Remove the Ring Gear Subassembly;
 - Remove the three (3) flathead bolts that secure the ring gear subassembly to the housing.
 - Lift the ring gear subassembly off of the housing.
 - Remove the O-ring from between the housing and ring gear subassembly.
2. Remove the planet gears;
 - Use a 1/8" diameter punch to drive the roll pin into the planet shaft until it bottoms against the spindle.
 - Using needle nosed pliers or a hooked tool, reach into the end of the planet shaft to grasp the roll pin and pull the planet shaft out of the spindle.
 - Drive the roll pin out of the planet shaft.

NOTE: Use new roll pins when reassembling the unit.

- Slide the planet gear subassembly out of the spindle being careful not to drop the needle bearings.
- Repeat for the two (2) remaining planet gears.

Figure 4-9: Torque Hub Disassembly



3. Remove the bearing nut;

- Place the housing and spindle assembly on a clean surface with the spindle end down.
- Remove the two (2) set screws and the bearing nut.

NOTE: The set screw holes in the bearing nut were staked to prevent the set screws from backing out. It will be necessary to clean up the holes prior to removing the set screws.

4. Remove the bearing cones;

- Remove the outer bearing cone.
- Turn the unit on its side and press the spindle out of the housing.
- Remove the inner bearing cone.

5. Remove the seal boot.


6. Remove the lip seal from the housing.

NOTE: Use a new seal when reassembling.

7. Remove the bearing cones;

- Use a soft steel rod to knock both bearing cones out of the housing.

Figure 4-10: Torque Hub Bearings



Assembly

NOTE: Spray a light film of oil on all component parts during assembly. Spray a generous amount of oil on bearings during installation.

1. Use a pressing tool to press both bearing cups into the housing.
2. Place the inner bearing cone into the inner bearing cup.
3. Grease the seal lip and use an appropriate tool to press the seal into the housing until it is flush with the end of the housing.
4. Place the spindle on the work surface, flange side down, and install the seal boot.
5. Lower the housing onto the spindle.
6. Place the outer bearing cone into the outer bearing cup.
7. Install the bearing nut;
 - Apply Loctite 243 on bearing nut thread and install the bearing nut.
 - Leave .003–.005 inches (.076–.127mm) end play to check the initial rolling torque with the unit tied down.
 - Torque the bearing nut until the rolling torque is 40–50 In. Lbs. (4–5 Nm) greater than initial rolling torque.

NOTE: Final torque is initial rolling torque plus 40–50 in. lbs. (4–5 Nm). E.g., if the initial rolling torque is 30 in. lbs. (3.5 Nm), the final rolling torque is 70–80 in. lbs. (8–9 Nm). Be sure the torque wrench is tangent to the housing OD.

8. Install the set screws into the bearing nut threaded holes.
 - Make sure set screw is driven into the spindle thread.
 - Tighten the set screws to damage the thread.
 - Stake the edge of the nut around the set screws so the nut will not loosen.
9. Place thrust washer into the counter-bore of the spindle.
10. Install planet gear subassemblies;
 - Place a planet gear subassembly into the spindle and align the planet gear bore with a planet shaft hole.
 - Insert a planet shaft (roll pin hole *up*) into the planet shaft hole and through the planet gear subassembly with.
 - Use a punch or similar tool to align the roll pin holes on the shaft and spindle.
 - Being careful not to strike the planet gears, drive the roll pin into the roll pin holes until the pin is flush with the OD of the spindle.
 - Repeat for the remaining planet gear subassemblies.
11. Grease the O-ring and place it into the groove on the housing.
12. Place the ring gear subassembly onto the housing and spindle assembly.
 - Align the three (3) cap screw holes.
 - Install the cap screws and torque to 15–20 ft. lbs. (20–27 Nm).

STEER CYLINDER

There are two (2) double acting type steer cylinders on this machine. During operation, cylinder(s) should not leak, but a slight damping at the rod seal is acceptable. The pins should be checked for wear.


TO REPLACE STEER CYLINDER:



- Clean all fittings before disconnecting hoses.
 - Tag hoses for proper reassembly.
 - Plug all openings to prevent contamination.
1. Raise and support the front end of machine (see *Intro Section - Raising the Machine*).
 2. Disconnect hydraulic hoses and cap them.
 3. Remove the nut and bolt holding the steer cylinder to the motor mounting bracket.
 4. Remove the pin and cotter pin holding the steer cylinder to the front axle.
 5. Carefully lift off the steer cylinder.
 6. Position the new steer cylinder and install pin and cotter pin to hold cylinder to the front axle.
 7. Install nut and bolt to hold cylinder to motor mounting bracket.
 8. Connect hydraulic hoses.
 9. To purge air from cylinder;
 - place a suitable container beneath the hose connections to catch spilled fluid,
 - loosen hose fittings slightly,
 - actuate steer function,
 - when all air is purged, tighten hose connections.

NOTE: Refer to *Section 1* for seal replacement instructions.

Figure 4-11: Steering Cylinder Installation



FLOATING AXLE LOCK CYLINDER

There are two Floating Axle Lock Cylinders located at the rear of the machine.

Remove

1. Raise and support the front end of machine.
2. Remove the bolt that secures the long clevis pin to the frame and remove the clevis pin.
3. Remove the bolt that secures the short clevis pin to the floating axle and remove the clevis pin.

Replace

Installation is reverse of removal. Apply one (1) drop of Loctite® to the bolts that secure clevis pins.


Bleed Procedure

1. Relocate the upper control box from the platform to a ground access point.
2. Loosen the bleed valve located on the top of the cylinder.
3. Operate drive very slowly while watching air escape from valve.
 - Once a steady stream of fluid runs from the valve, release drive and tighten the valve.
4. Repeat on opposite side.

Test Locking and Center Position

1. Place a block approximately 4 inches (10 cm) high behind one of the rear tires.
2. Elevate the platform to 10 feet (3 m).
3. Slowly drive the tire onto the block.
 - The axle lock cylinders should be locked (no movement).
 - The opposite tire should be off the ground.
4. Lower the platform.
 - The axle lock cylinders should release.
 - The suspended tire should lower to the ground.

Figure 4-12: Floating Axle Lock Cylinder



HOSES AND CABLES

NOTE: Refer to *Parts Section E* for detailed hydraulic hose diagrams.

Inspect all hoses and electrical cables for security and damage. Hoses and cables should be examined for rubbing and chafing.

Check for leaks at fittings. Replace any damaged hose or cable.

1. Tag hoses for proper reassembly.
2. Disconnect hoses and IMMEDIATELY cap the openings to prevent contamination.
3. Torque hose fittings according to the Hydraulic Torque Specification Table.


PLATFORM REMOVAL

Figure 4-13: Platform Removal

1. Raise platform and set the maintenance lock.
2. Connect overhead crane by appropriate lifting device to platform.
3. Disconnect all platform wires.
4. Remove the bolts from both platform scissor mounts at the rear of the machine, and remove the scissor mounts.
5. Slide platform and roll out deck off the machine.

Installation is reverse of removal.

NOTE: Apply one (1) drop of Loctite® to all bolts.



LIFT CYLINDER REMOVAL AND INSTALLATION

NOTE: Refer to *Section 1* for seal replacement instructions.

Refer to *Parts Section C* for detailed parts list and illustration.

CAUTION:


- Clean all fittings before disconnecting hoses.
- Tag hoses for proper reassembly.
- Plug all openings to prevent contamination.
- **Cylinders are heavy.** Provide proper support *before* removing pins.
- **Attach the lifting device to the cylinder body.**
Lifting by either end will cause the cylinder to extend.

1. Raise the scissor arm assembly and support using the maintenance lock.
2. Disconnect hoses and wires and cables to the lift cylinder(s).
3. Use a suitable device to support the lift cylinder.
4. Remove lock plates and cylinder pins.
5. Guide the cylinder through the end of the scissor assembly and lift by the body using a suitable lifting device.

Installation is reverse of removal.

NOTE: Apply one (1) drop of Loctite® to all bolts.

Figure 4-14: Lift Cylinder Removal



SCISSOR BEAM ASSEMBLY

NOTE: Refer to *Parts Section C* for detailed parts list and illustration.

Clean the beams once a year or as necessary and inspect along the beam's surface, especially welds and brackets.

Scissor Beam Removal

1. Remove the platform and lift cylinder(s).
2. Attach a suitable lifting device to the scissor assembly.
3. Remove the Limit Switch cover and Limit Switch.
4. Remove the bolts from both fixed blocks at the rear of the machine.
5. Slide and lift the scissor assembly

Installation is reverse of removal.

NOTE: Apply one (1) drop of Loctite® to all bolts.

Figure 4-15: Scissor Assembly Removal





Figure 4-16: Cable Routing



ENGINE MAINTENANCE



**Always wear protective eye-wear when working with fuel and oil.
Engine should be OFF when replacing filter elements.**

For complete service information consult the engine manual that came with the machine.

OIL AND OIL FILTER


Dispose of used oil and filters properly.

1. Use a suitable container to catch drained oil. Remove the drain plug. After oil has drained, replace the drain plug.
2. Remove the old filter and wipe the filter seal contact surface with a clean towel. Coat the seal on the new filter with clean oil, then install and tighten by hand.
3. Fill engine with 10w-30 motor oil until the dipstick indicates FULL. Capacity is 5.4 US quarts (5,1 l).
4. Recheck dipstick after running engine. Fill as necessary.

AIR FILTER ELEMENT

1. Remove the hoses from the canister.
2. Loosen the bracket and remove the canister.
3. Remove the wing-bolt, remove old filter and replace with a new filter. Replace and tighten the wing-bolt. **Do not run the engine with the air filter element removed.**
4. Replace the canister and attach the hoses. Tighten the canister bracket and hose clamps.

Figure 4-17: Diesel Engine – Oil Filter and Air Filter




FUEL FILTER

1. Turn OFF valve on bottom of fuel tank.
2. Place a suitable container beneath the fuel filter assembly to catch spilled fuel. Clean the filter area.
3. Turn filter cartridge $\frac{1}{4}$ counterclockwise remove. Wipe the filter seal contact surface with a clean towel and install a new filter.
4. Open valve at fuel tank and check for leaks.
5. Purge the air from the fuel system as follows;
 - Fill fuel tank to the fullest extent. Open valve on bottom of fuel tank.
 - Loosen bleed screw on top of fuel filter housing a few turns.
 - Close the bleed screw when there are no more bubbles.
 - Open the bleed screw on the fuel injector pump. Use the lift pump hand lever to pump fuel to the injectors. Close the bleed screw when there are no more bubbles.

NOTE: Do not attempt to start the engine until Step 5 has been performed.

6. If fuel becomes contaminated with water, use the Water Separator Valve at the bottom of the fuel cartridge to drain water.

Figure 4-18: Fuel Filter



IDLE SPEED ADJUSTMENT

1. Bring engine to operating temperature.
2. Slow engine to complete idle.
3. Adjust the Idle Stop Screw until the RPM is 950. Adjust slightly up or down to avoid vibrations.
4. Hold the Idle Stop Screw while tightening the jam nut to prevent change in adjustment.

HIGH SPEED ADJUSTMENT

IMPORTANT: – In order to prevent electrical system damage, check the Throttle Solenoid Adjustment after this procedure.

1. Bring engine to operating temperature.
2. Disconnect the Throttle Solenoid linkage at the clevis.
3. Manually pull the Throttle Lever until it contacts the High Speed Stop Screw.
4. Adjust the High Speed Stop Screw until the RPM is 3200 with the Throttle Lever against the High Speed Stop Screw.
5. Turn off the engine and reconnect the Throttle Solenoid linkage at the clevis.
6. Hold the High Speed Stop Screw while tightening the jam nut to prevent change in adjustment.

THROTTLE SOLENOID ADJUSTMENT


IMPORTANT: – This final adjustment must be made after all other throttle speed adjustments. The solenoid must be free to retract fully in order to turn OFF the High Amperage Pull Circuit. Improper adjustment will result in solenoid failure and may damage the electrical system.

1. With the engine OFF, manually retract the solenoid by grasping the piston, just ahead of the boot, and pull to the fully retracted position.
2. With the solenoid piston fully retracted measure the distance between the High Speed Stop Screw and the Throttle linkage using a .020 feeler gauge.
3. Adjust clearance at the Throttle Solenoid linkage only.

Do not adjust the High Speed Stop Screw.

- Disconnect the linkage at the clevis and turn the clevis to lengthen or shorten as necessary.
- Reconnect the clevis and measure again. Repeat until the measurement is correct.

Figure 4-19: Throttle Adjustments



OUTRIGGER FUNCTION

The outriggers on the RT series MEC Scissor Lifts are a One-Touch Activation system. To deploy the outriggers, simply push the outrigger toggle switch down until the outriggers level the unit and the engine returns to idle. You are now ready to lift the platform. The outrigger control module is a “smart” unit, which will level the unit in all but extreme terrain so you don’t have to attempt to level it yourself.


OPERATIONAL CHARACTERISTICS

- To deploy the outriggers, push the Outrigger Switch down and hold until the engine returns to idle. The unit will self-level.
- The outrigger legs can not be operated individually.
- The outriggers system will not operate when the platform is elevated above approximately 10 feet (3 m).
- Travel is locked out when the outriggers are deployed. A Drive Indicator Light, above the outrigger switch, will illuminate when the outriggers are fully retracted.
- The engine will not return to idle when the outriggers are fully retracted. The drive indicator light is your signal that the outriggers are fully retracted.
- If the slope of the terrain is in excess of the outrigger’s leveling capabilities, the outrigger control system will continue to attempt to level and the engine will not return to idle. In this case, if the platform remains outside of the pre-described tilt sensor parameters, the unit will not elevate above 6 feet 2 m) and the alarm will sound, indicating the out-of-level situation.
- The outrigger system uses a Top-out limit switch and a Pressure switch on each leg to monitor their respective positions.
- Each outrigger leg uses a Retract valve and an Extend valve to control cylinder stroke. These are located under the protective cover atop the outrigger leg.
- A 4-way, 3-position valve, on the outrigger hydraulic manifold controls the direction of oil flow to the outrigger legs.
- The GP106 Outrigger Control Module controls all outrigger valve and interlock duties as well as sensing unit level.
- Diagnosis of the GP106 Outrigger Control Module is possible by counting the number of flashes from the red LED and referring to *Outrigger Module GP106 LED Flash Codes* at the end of this section. Diagnosis and calibration of the outrigger module can also be done through the use of the EZ-Cal scan tool MEC part # 90888. (See GP106 troubleshooting in this section)
- If the GP106 Outrigger Control Module is ever replaced or removed or if you suspect that it requires calibration, you must use the EZ-Cal scan tool and the following directions to calibrate the outrigger module.

OUTRIGGER CALIBRATION

Before attempting the calibration procedure, move the machine to an area that is level as measured by a spirit level or other leveling device. An EZ-Cal hand-held device (MEC part # 90888) is required to carry out all calibration procedures on the GP106 Outrigger Control Module.

Figure 4-20: Outrigger Calibration Setup



OUTRIGGER TILT SENSOR CALIBRATION

The integral tilt sensor of the GP106 Outrigger Control Module must be calibrated to compensate for variations due to installation and vehicle construction. This procedure must be done if the control module is ever repositioned or replaced.

- a. Drive machine to level ground.
- b. Plug EZ-Cal into connector P1 on the control module.
Display reads HELP: PRESS ENTER.
- c. Press right arrow to ACCESS LEVEL 3, Press Enter.
Display reads CODE 0000.
- d. Press up and right arrows to enter code 1775, Press Enter.
Display reads ACCESS LEVEL 2.
- e. Right arrow to MACHINE SETUP, Press Enter.
Display reads CHANGE DEFAULTS.
- f. Right arrow to CALIBRATE LEVEL, Press Enter.
Display reads CALIBRATE LEVEL: YES:ENTER,NO:ESC.
- g. Press Enter. Display reads TILT 0.0',0.0'
- h. Press ESC, ESC
- i. Disconnect EZ-Cal from the outrigger control module.

OUTRIGGER CALIBRATION IS NOW COMPLETE.

GP106 OUTRIGGER CONTROL MODULE TROUBLESHOOTING

When the **EZ-Cal** hand-held device is connected to the **GP106** control module, the first menu available is “HELP” – just press the **ENTER** button to see a message describing the current status of the **GP106**; this can be very helpful in diagnosing problems with the system.

When an **EZ-Cal** is unavailable, an LED on the **GP106** flashes to provide limited diagnostics

The following messages might be displayed:

EVERYTHING OK

The **GP106** detects no problems.

If problems are being experienced with the system, use the **DIAGNOSTICS** menus to check for wiring problems.

B+ SUPPLY TOO LOW

The **GP106** is designed for use on 12V and 24V battery powered vehicles; it cannot operate with a supply below about 9V.

The “BATTERY” voltage can be checked in the “SYSTEM” menu (available in the “DIAGNOSTICS” menu).

CANNOT LEVEL: BAD TILT SENSOR

Ensure that the **GP106** is correctly installed – if it is wrongly oriented, its integral tilt sensor will be unable to measure vehicle tilt correctly.

CHECK OUTRIGGERS SUPPLY (P4-9)

An auto-level or auto-retract signal has been detected by the **GP106** (on P2-5 or P2-6) but there is no supply on P4-9 to power the outrigger legs.

OUTRIGGERS MANUALLY CONTROLLED

The outrigger system cannot be manually controlled, but this message may appear. It indicates a wiring problem to terminal P2-2.

OUTRIGGERS CANNOT BE MOVED

The outrigger system will be unable to operate if the machine is on a steep slope greater than ten (10) degrees.

RELEASE OUTRIGGER DEMAND!

The **GP106** is waiting for an active signal on P2-5 or P2-6 to be released (due to activating a switch when power is applied, or in conjunction with manual use of the outriggers, or activating both switches together).

VEHICLE TILTED

Either the “X” or “Y” tilt (measured by the **GP106** integral tilt sensor) exceeds three degrees. This does not affect operation of outriggers.

OUTRIGGER WIRING FAULT

The system has detected voltage on P2-2 but voltage is not present on P2-5 or P2-6. Check wiring to P2-5/6.

OUTRIGGER MODULE GP106 LED FLASH CODES

The **GP106** has a built-in LED to provide simple diagnostics when no **EZ-Cal** is available. Please note that the use of an EZ-Cal provides significantly better diagnostics through the HELP messages listed previously.

LED ON STEADY

This indicates power to, and no fault with, the **GP106**

LED OFF ALWAYS

This indicates no power to the **GP106**

LED FLASH CODE 1

Wiring Fault. Check connection to P2-2.

LED FLASH CODE 2

This indicates a fault with the switch inputs to the **GP106**. Check wiring to connector P2.

LED FLASH CODE 3

This indicates a fault with the “stable” output of the **GP106** – a short to the supply has been detected. Check wiring from pin P2-8

LED FLASH CODE 4

This indicates that the outriggers cannot be operated because the machine is on a slope greater than ten (10) degrees. Move machine to a different location.

LED FLASH CODE 5

This indicates a fault with the “stable” output of the **GP106** – a short to 0V (ground) has been detected. Check wiring from pin P2-8

LED FLASH CODE 6

This indicates a fault with the “auto” inputs of the **GP106** – check the wiring to pins P2-5 & P2-6

LED FLASH CODE 7

This indicates a fault with the supply to the **GP106** – check battery supply at least 8V on pins P2-12 & P4-9

LED FLASH CODE 8

This indicates that the machine is not level. It is not a fault and will not affect operation of outriggers.

LED FLASH CODE 9

This indicates that the **GP106** is performing start-up tests.



Section 5


TROUBLESHOOTING

| CONTENTS | PAGE |
|--|-------------|
| Troubleshooting | 5-3 |
| General Troubleshooting Tips | 5-3 |
| Common Causes of Hydraulic System Malfunctions | 5-3 |
| Hydraulic Pressure Adjustment Procedures | 5-8 |
| Pump Adjustment | 5-9 |
| Lift Relief (RV1) | 5-9 |
| Steering Relief (RV2) | 5-9 |
| Lift Cylinder Overpressure Valves (RV4) 4191RT Only | 5-10 |
| Proportional Speed Adjustment | 5-12 |
| Circuit Board Setting Test Procedure | 5-12 |
| Adjustment Procedure | 5-13 |


| FIGURES | PAGE |
|--|-------------|
| Figure 5-1: Hydraulic Manifold | 5-2 |
| Figure 5-2: Hydraulic Pressure Adjustment | 5-8 |
| Figure 5-3: Counterbalance Valves | 5-10 |
| Figure 5-4: Proportional Speed Adjustment Course | 5-12 |
| Figure 5-5: Trim Pots | 5-13 |
| Figure 5-6: Controls and Switches | 5-14 |

Figure 5-1: Hydraulic Manifold

HYDRAULIC MANIFOLD



DIAGNOSTIC LEDs



mec
ILLUSTRATION No.
ART_2070

TROUBLESHOOTING

The 2591RT, 3391RT and 4191RT are designed for ease of diagnostics. There is a terminal strip located under the work platform for checking signals to and from Upper Controls. There are also LED's located in the Lower Controls box to indicate outputs from the circuit board.

Diagnostic Example: – if the lift LED does not illuminate when attempting to lift, either the main power is not on, or board is not receiving a signal for lift. If LED is illuminated but machine does not lift, there would be an electrical problem between the Circuit board and the valve, or a hydraulic problem. The main valve block is equipped with a quick disconnect gauge port to help diagnose the hydraulic system.

GENERAL TROUBLESHOOTING TIPS

Before investigating a malfunction, check the following items:

- Check that battery switch is turned on.
- Check that battery connections are secure and battery is fully charged.
- Check that the emergency stop button is released (UP/OUT position).
- Check that the hydraulic fluid is at the correct level.
- Check that the circuit breaker is in the "ON" position (not tripped).

COMMON CAUSES OF HYDRAULIC SYSTEM MALFUNCTIONS

- Incompatible hydraulic fluids mixed, destroying the additives and causing varnish build up, resulting in the valves sticking.
- Water in the hydraulic fluid due to a damp climate.
- Improper hydraulic fluid used. Viscosity too high in cold climates. Viscosity too low in warm climates.
- Hydraulic fluid contaminated with debris - filter change interval neglected.

NOTE: Mobil Fluid 424 Hydraulic Fluid, is a multiple viscosity fluid that is light enough for cold climates and resists thinning in warm climates. Only Mobil Fluid 424 or equivalent must be used. Substituting with a lower grade fluid will result in pump failure.

Following is a step by step basic troubleshooting guide.

NOTE: Contamination always causes failure in any hydraulic system. It is very important to be careful not to introduce any contamination into hydraulic system during the assembly procedures. Please make sure all ports and cavities of the manifold and cylinders are properly covered/plugged during maintenance activities.

Table 5-1: Troubleshooting

| Problem | Probable Cause | Remedy / Solution |
|---|---|--|
| General Power Issue | | |
| No operation from upper or Upper Control station | Main battery switch turned off | Located left of Lower Controls box |
| | Emergency switch pushed in or Ignition switch turned off | Upper or lower Emergency Stop switch will cut all power as will the Ignition switch in the Platform Controls box |
| | Dead Battery | Charge battery |
| | Blown fuse | Sealed unit just below Lower Controls box |
| | Circuit breaker tripped | Reset - Located in Lower Controls box panel |
| | Damaged Upper Controls box harness | Inspect from harness plug to terminal strip under platform |
| | Failed 25 AMP diode | Test/replace. Located inside Lower Controls box |
| | Failed Power Relay on Circuit board | Replace circuit board in Lower Controls box |
| Functions from Upper Controls but not from Upper Controls | Faulty relay, located in Upper Controls box | Check power on wire 101 from Key switch Check power on wire 101A from relay to Joystick plug |
| | Interlock switch (Joystick) | Check power to RED wire (power to switch) and power to PURPLE wire (power out of switch) at Joystick plug |
| Lift/Lower | | |
| Platform will not Raise | Excessive weight on Platform | Reduce weight to within platform capacity |
| | Lift Relief valve out of adjustment | Adjust relief valve to rated capacity |
| | Lift Valve SV-1 not energized | Check lift circuit from Upper Controls box to SV-1 valve |
| | Lowering valve SV-5 stuck open (located at base of lift cylinder CYL-1) | Check and remove contamination, E-Down cable damaged or replace valve |
| | Level Sensor out of level (platform elevated above 6 feet) | Reposition machine to firm level surface, Check Level Sensor function |
| | Main system pressure inadequate | Check pump output pressure (see <i>Hydraulic Pump Adjustment</i> in this section) |
| | Proportional control out of adjustment (High Range Adjustment) | See <i>Proportional Speed Adjustment</i> in this section |
| Platform will not Raise (with outriggers option) | All outrigger feet deployed but not firmly on ground. | Redeploy outriggers by pushing the outrigger switch down. |
| | Outrigger pressure switch inoperative | Inspect all four outrigger pressure switches located on top of the outrigger legs. |
| Platform will not lower or lowers slowly | Maintenance Lock in maintenance position | Return Maintenance Lock to the stowed position |
| | Lowering valve not energized | Check lowering circuit from Upper Controls box to Lowering valve SV-5 |
| | Lowering valve not shifting | Clean debris, replace |
| | Lowering orifice (ORF-3) plugged | Clean orifice |
| Lowers but not completely (4191RT only) | Down valve on one cylinder inoperative | Check valve coils |
| Emergency lowering not working | E-Down cable broken or frayed (2591RT/3391RT) | Replace E-Down cable |
| | Lowering valve not shifting | Clean debris, replace |
| | Lowering orifice (ORF-3) plugged | Clean orifice |
| 4191RT ONLY | E-Down battery discharged | Charge, check charge diode & connections |
| | Valve coil failed on either cylinder | Test, replace |
| Lowers but not completely | Down valve on one cylinder inoperative | Check valve coils, wiring |
| | | |

continued...



Table 5-1: Troubleshooting (Continued)

| Problem | Probable Cause | Remedy / Solution |
|---------------------------------|--|--|
| Drive | | |
| No drive function | Valve SVD1 not energizing | Check forward/reverse LEDs lighting up at circuit board inside Lower Controls box Check connections at valve Check voltage at valve Check ground to valve Check valve for proper functioning |
| | Brakes not releasing | Check OPL5 brake orifice for contamination |
| | Proportional Control out of adjustment (High Speed adjustment) | See <i>Proportional Controller Adjustment</i> in this section |
| (with outriggers option) | Outriggers lowered | Check Drive Enable light - raise outriggers |
| | Outrigger Retracted switch/s inoperative | Check enable light on Platform Controls box Check outrigger switches located on top of each outrigger jack for continuity |
| No drive elevated | Proportional Control out of adjustment (Low Range adjustment) | See <i>Proportional Controller Adjustment</i> in this section |
| | Axle out of center or Axle Center switch inoperative | Lower platform and reposition o level ground. Inspect switch on level ground. |
| | Unit out of level | Lower and reposition the machine. Check Level Sensor malfunction |
| (with outriggers option) | Outriggers lowered | Check Drive Enable light - raise outriggers |
| Slow drive with Platform stowed | High torque enabled | Check Speed/Torque switch in Platform Controls Box |
| | Limit switch not functioning | Limit switch at rear center of base Check continuity between wire 2 TAN/ORG and wire 20 RED/WHT. Continuity = platform stowed. |
| | Upper Controls circuit board running in slow speed mode | 12 volts to "R" terminal on circuit board in Platform Controls box = High Range |
| | Proportional Control out of adjustment (Low Range adjustment) | See <i>Proportional Controller Adjustment</i> in this section |
| | Engine not running to full potential | Check engine operation as per engine manufacturer guidelines |
| | Wheel motor/s not functioning correctly | Inspect wheel motors for excessive bypass |
| | RV3 or RV4 not adjusted correctly | Check and adjust relief valves |
| Drive in one direction only | Rev-Up or FWD-Down micro-switch failure | Check micro-switches on Joystick controller for function or adjustment |
| | Drive valve SVD1 not energizing in one direction | Check 12 volts to appropriate coil, check coil, check valve function |
| | Counterbalance valve CBV1 or CBV2 not functioning correctly | Swap Counterbalance valves to see if functioning direction changes. |
| No low speed (high torque mode) | Speed/Torque selector switch inoperative | Check for 12 volts on terminals 2 & 3 of Speed/Torque switch in Platform Controls box with drive enabled |
| | Valve SV3 not functioning | Check for 12 volts and ground to valve Check for faulty valve spool |
| | | |

continued...



Table 5-1: Troubleshooting (Continued)

| Problem | Probable Cause | Remedy / Solution |
|--|--|--|
| Drive | | |
| No Mid Speed | SV3 or SV4 powered and/or shifted | These valves should not have 12 volts, in mid-speed, check valve function |
| | Speed/Torque selector switch malfunction | Should not have power at terminals 1 & 3 of Speed/Torque switch in Platform Controls box with drive enabled |
| No High Speed | Speed/Torque selector switch inoperative | Check for 12 volts on all terminals of Speed/Torque switch in Platform Controls box with drive enabled |
| | Faulty diode block DB1 | Test DB-1 in Platform Controls box. |
| | Valve SV4 not functioning | Check voltage and ground to valve. Check for faulty valve spool. Should provide pressure to 2SP Port |
| Multi-Function | | |
| No drive or Lift function from Upper Controls with steer operational | PWM circuit board in Platform Controls box not functioning correctly | Check battery + and - terminals at board. Check PWM output at A terminal. Check connections between A terminal and Proportional valve. |
| | Proportional valve malfunction | Check, for 1 AMP at valve during full Joystick stroke. Replace Proportional valve SP-1 |
| | EC1 pressure compensation valve not functioning | Check, replace valve EC1 |
| No steering With Drive operational | SV2 not functioning | Check voltage and ground to valve Check for faulty SV2 valve |
| | Faulty lift/drive selector switch | Check power on wire #25A on switch |
| | Faulty steer switch | Check switch in Joystick handle |
| | Steering Cylinder/s internal leakage | Check for internal leakage - repair |
| | RV1 steer relief valve not functioning | Check adjustment or replace |
| Diesel Engine | | |
| Starter inoperative | Battery Cables loose or corroded | Clean, tighten cables |
| | Key switch not functioning | Check power to wire #20 at Key switch while cranking |
| | Starter not functioning | Check power to YEL/RED #220 wire at starter, Check ground cable to engine bell housing |
| | Circuit board relay failed | Check input on plug A pin-17, ORG/RED wire #20 on Lower Controls circuit board Check output on plug B pin-1, YEL/RED wire #220 on Lower Controls circuit board. <i>12 volts in - 0 volts out = replace circuit board</i> |
| No Engine start: Starter operates | Low diesel fuel level | Fill diesel tank, (see <i>Section 3</i> for Fuel Priming instructions) |
| | Fuel valve closed - located at fuel tank | Open valve |
| | Air in injector lines | See <i>Section 4</i> for Fuel Priming instructions |
| | Fuel filter clogged | Replace fuel filter |
| | Run solenoid not activating | Check power at WHT/BLK wire #320 from starter to run solenoid while cranking (WHT/BLK pull in, GRN/WHT hold wire) |
| | Glow plugs inoperative | See " <i>Glow Plugs Inoperative</i> " in this section |
| Engine starts but dies when starter disengaged | Faulty oil pressure switch | Check switch and wiring |
| | Faulty Fuel solenoid | Check 12 volts on GRN/WHT wire #116 - Replace Fuel Solenoid |
| | | <i>continued...</i> |



Table 5-1: Troubleshooting (Continued)

| Problem | Probable Cause | Remedy / Solution |
|------------------------------------|--|---|
| Throttle & Glow Plugs | | |
| Throttle does not operate | Maladjusted Throttle Solenoid (maladjusted throttle solenoid will result in the failure of the solenoid) | Adjust throttle linkage NOTE: throttle linkage adjustment is critical on diesel engine) |
| | Throttle Solenoid failure | Check + and - to solenoid while operating Throttle |
| | Throttle Relay (located on side of engine) | Test for 12 volts on RED wire #00 and ORG wire # 225 while throttle is requested <i>Power on these wires should = 12 volts on ORG/BLK wire 325</i> |
| | Failed diode block (Large) located in Upper Controls box | Test and/or replace diode block Check for Throttle LED on Upper Control board |
| Throttle does not remain energized | Failed Throttle solenoid | Replace Throttle Solenoid |
| Glow Plugs inoperative | Failed Glow Plug Switch | Try Glow Plug switch on opposite control panel, Check for LED on Lower Controls circuit board. |
| | Failed Glow Plug Relay - located on side of engine | Test for 12 volts on RED #00 wire and on ORG/WHT wire #124 while operating glow plugs. <i>Power on these wires should = 12 volts on ORG/BLU wire 224</i> |
| | Failed glow plugs | Check for 12 volts at glow plugs while operating glow plugs. |
| | | <i>...end table</i> |


HYDRAULIC PRESSURE ADJUSTMENT PROCEDURES

- Before attempting to check and/or adjust pressure relief valves, operate the machine for 15 minutes or long enough to sufficiently warm the hydraulic fluid.
- Insert a 0-5000 psi gauge onto the pressure test port on the valve manifold using gauge adapter fitting MEC part no. 8434

Table 5-2: Pressure Adjustment

| Model | Main | | Lift | | Steer | | Stand-by | |
|--------|----------|---------|----------|---------|----------|---------|-------------|-----------|
| 2591RT | 3000 PSI | 207 bar | 2500 PSI | 172 bar | 1500 PSI | 103 bar | 500-550 PSI | 35-38 bar |
| 3391RT | 3000 PSI | 207 bar | 2650 PSI | 183 bar | 1500 PSI | 103 bar | 500-550 PSI | 35-38 bar |
| 4191RT | 3000 PSI | 207 bar | 2500 PSI | 172 bar | 1500 PSI | 103 bar | 500-550 PSI | 35-38 bar |

Figure 5-2: Hydraulic Pressure Adjustment



PUMP ADJUSTMENT

The Hydraulic Pump used in this model is a Variable Displacement, Pressure Compensated, Piston type pump. Proper adjustment is critical for normal operation of the machine. The following paragraphs will guide you through the various steps however, you must perform all steps, in their listed sequence, in order to achieve proper adjustment and machine performance.

Main Relief and Standby Pressure Adjustments

1. Start engine and operate the unit for 15 minutes or until the hydraulic fluid is warm.
2. Insert a 0 – 5000 PSI (0-345 bar) gauge onto the manifold pressure gauge port.
3. Remove the acorn nut from the Main Relief adjustment screw. Loosen the jam nut and turn the screw counterclockwise 3 turns. Tighten the jam nut and install the acorn nut.
4. Remove the acorn nut from the Standby adjustment screw and loosen the jam nut. Turn the screw clockwise 3 turns or until the needle on the gauge stops climbing. At this point the gauge is reading full main relief pressure.
5. Access the Main Relief screw again and adjust it until the gauge settles at 2800 PSI (193.5 bar). Tighten the jam nut and install the acorn nut.
6. Check the gauge reading again to ensure the setting did not change.
7. Turn the Standby adjustment screw counterclockwise until the gauge reads 550 PSI (38 bar). Tighten the jamb nut and install the acorn nut.
8. Check the gauge reading again to ensure the setting did not change.

Pump Displacement Adjustment

This adjustment is set at the factory and should not be tampered with. The Displacement adjustment controls the maximum amount of fluid flow that the pump will produce per revolution. Excessive flow will result in severe engine loading and stalling. Reduced flow will result in slower functions with no engine loading. If you suspect that the setting is incorrect, please call MEC Product Support at (800) 387-4575 for assistance.

LIFT RELIEF (RV1)

The Lift Relief valve is located on the left-side, center of the valve manifold. It will be necessary to remove the cap from the relief valve if adjustment is necessary.

REMOVING THE CAP WHILE THE ENGINE IS RUNNING WILL RESULT IN FLUID LEAKAGE.

To check Lift Relief valve setting, park the machine on a firm level surface free from overhead obstructions. Using the lift switch on the lower panel, elevate the platform to full elevation. While maintaining the lift command, record the reading on the gauge.

STEERING RELIEF (RV2)

The steering Relief valve is located on the left side, lower of the valve manifold. It will be necessary to remove the cap from the relief valve if adjustment is necessary.

REMOVING THE CAP WHILE THE ENGINE IS RUNNING WILL RESULT IN FLUID LEAKAGE.

To check Steering Relief valve setting, operate steer in one direction. While maintaining the steer command, record the reading on the gauge.

LIFT CYLINDER OVERPRESSURE VALVES (RV4) 4191RT ONLY


The Lift Cylinder Overpressure valves are located on each of the lift cylinder valve blocks on the 4191RT model only.

Proper valve adjustment is not possible by the consumer. Considering their importance to the safe operation of the machine, they must not be tampered with. If the valve is suspected to be out of adjustment or tampered with, it must be replaced.

SETTING COUNTERBALANCE VALVES

1. Loosen the locknut on one of the valves.
2. Turn the adjustment screw clockwise (to the right) until it reaches the internal stop and the screw will turn no further.
3. Tighten the locknut while holding the adjustment screw in position to prevent it from rotating.
4. Repeat steps 1 through 4 on the other Counterbalance valve.
5. Adjustment is complete.

Figure 5-3: Counterbalance Valves



NOTES:



PROPORTIONAL SPEED ADJUSTMENT




Proportional Circuit Board Adjustment should only be performed after all other components are deemed to be in proper working order.

There are many factors that may contribute to excessively fast or slow drive speeds. Proportional Circuit Board Adjustment should only be performed after all other components are deemed to be in proper working order and not contributing to abnormal driving speeds. Failure to do so may result in incorrect speeds once the offending component has been repaired.

CIRCUIT BOARD SETTING TEST PROCEDURE

Before you begin, ensure there are no overhead obstructions preventing lift to full height. Lay out a course measured at 20 feet (6 meters) long. Ensure there are no obstructions preventing a straight travel over the distance of the course including leading up to and away from the course. Try not to steer while driving the timed course.

Figure 5-4: Proportional Speed Adjustment Course



High Speed Drive Test:

With the platform fully lowered, drive the machine over the course, crossing the start line at full speed. Record the time it takes for a (predetermined) point on the machine to cross both lines and compare with the chart below using the 'High Range' column figure.

Elevated Speed Drive Test:

Elevate the platform above 12 feet (3.6 meters). Drive the machine over the course, crossing the start line at full speed. Record the time it takes for a (predetermined) point on the machine to cross both lines and compare with the chart below using the 'Low Range' column figure.

Table 5-1: Speed Adjustment Table: 20 FT (6 m) Course

| TRIM POT | Travel Time in Seconds |
|------------|------------------------|
| HIGH Range | 3.5 to 4.0 |
| LOW Range | 27 to 33 |

ADJUSTMENT PROCEDURE

NOTE: Proportional Controller adjustments should only be made when the possibility of unauthorized tampering exists or after the Proportioning Valve or Proportional Circuit board was replaced. Though testing the proportional output should be part of routine maintenance, adjustments should not be necessary as a routine maintenance procedure.

The Trim Pots are located in the Platform Controls box (see illustration).

1. Turn the RAMP trim pot counterclockwise until a clicking noise is heard.
2. Ensure there are no overhead obstructions preventing lift to full height. Select LIFT mode, pull the enable and move the Joystick in reverse slowly to the point that the engine accelerates and hold it at that point. While holding the Joystick in that position, adjust the THRESH trim pot until the platform does NOT lift. Once adjusted, slight additional reverse motion of the Joystick should result in very slow and controlled lift action.
 - Counterclockwise trim pot adjustment increases the amount of Joystick travel before platform movement.
 - Clockwise trim pot adjustment will allow platform movement sooner in the Joystick travel.
3. If the machine was slow in the High Speed portion of the test, turn the HI RANGE trim pot clockwise until a clicking noise is heard.
4. If the Elevated Speed Drive Test resulted in speeds other than those listed, turn the LO RANGE trim pot clockwise to increase elevated drive speed or counterclockwise to decrease elevated drive speed to the proper speed. Repeat the Elevated Speed Drive Test.
5. The RAMP trim pot controls the smoothness of the motion start-up and linear ramp-up response. Turn the RAMP trim pot clockwise until the slowest machine start-up can be achieved while maintaining good proportional ramp-up through the travel of the Joystick.

Figure 5-5: Trim Pots





Figure 5-6: Controls and Switches



mecc
ILLUSTRATION No.
ART_2075



Section 6

SCHEMATICS

| CONTENTS | PAGE |
|----------------------------|-------------|
| Hydraulic Schematics | 6-2 |
| Electric Schematics | 6-6 |


| FIGURES | PAGE |
|---|-------------|
| Figure 6-1: Hydraulic Schematic | 6-3 |
| Figure 6-2: Hydraulic Manifold | 6-4 |
| Figure 6-3: Hydraulic Components | 6-5 |
| Figure 6-4: Main Wiring Harness | 6-7 |
| Figure 6-5: Circuit Board Schematic, Part 1 | 6-8 |
| Figure 6-6: Circuit Board Schematic, Part 2 | 6-9 |
| Figure 6-7: Upper Control Box Schematic | 6-10 |
| Figure 6-8: Upper Control Box with Outrigger Controls | 6-11 |
| Figure 6-9: Lower Control Box | 6-12 |
| Figure 6-10: Engine Schematic | 6-13 |
| Figure 6-11: Outriggers Schematic (option) | 6-14 |
| Figure 6-12: Generator Schematic (option) | 6-15 |

HYDRAULIC SCHEMATICS

| Callout | Description |
|---|--|
| Lift Cylinder Components (2591RT/3391RT) | |
| CYL2 | Cylinder |
| MA3 | Manifold, Lift Cylinder |
| SV5 | Solenoid Valve - 12V Cable Attach |
| ORF3 | Orifice - 0.093 |
| Lift Cylinder Components (4191RT) | |
| CYL3 | Cylinder, Upper |
| MA5 | Manifold, Lift Cylinder, Upper |
| SV6 | Solenoid Valve - 12V Dual Coil |
| RV4 | Relief Valve - 3200 PSI |
| ORF4 | Orifice - 0.093 |
| CYL4 | Cylinder, Lower |
| MA4 | Manifold, Lift Cylinder, Lower |
| SV6 | Solenoid Valve - 12V Dual Coil |
| RV4 | Relief Valve - 3200 PSI |
| ORF6 | Orifice - 0.047 |
| Wheel Motor Components | |
| LF | Wheel Motor - Dual Displacement (Left Front) |
| LR | Wheel Motor - Dual Displacement (Left Rear) |
| RF | Wheel Motor - Dual Displacement (Right Front) |
| RR | Wheel Motor - Dual Displacement (Right Rear) |
| P1 | Pump - Variable Displacement Pressure Compensated |
| FL1 | Return Filter - 10 Micron |
| CYL1 | Cylinder, Steering |
| Oscillating Axle Components | |
| CYL6 | Axle Lock Cylinder |
| SV10 | Solenoid Valve, Poppet N.C. |
| Optional Outriggers Components | |
| MA6 | Manifold, Outriggers |
| CV1 - CV2 | Check Valve |
| CYL5 | Outrigger Cylinder |
| SV7 | Solenoid Valve, Poppet N.C. |
| SV8 | Solenoid Valve, Poppet N.C. |
| SV9 | Spool Valve, 4-way - 3-Position |

| Callout | Description |
|---------------------------------|--|
| Main Manifold Components | |
| MA1 | Manifold, Main Valve Block |
| SVD1 | Spool Valve, Drive, 4 Way - 3 Position |
| SV1 | Spool Valve, Lift, 3 Way |
| SV2 | Spool Valve, Steer, 4 Way - 3 Position |
| SV3 | Spool Valve, Series Parallel, 4 Way - 2 Position |
| SV4 | Spool Valve, High Speed, 3 Way - 2 Position |
| SV5 | Proportional Valve - 12V |
| SP1 | Proportional Valve - 12V |
| RV1 | Relief Valve, Lift - 2500 PSI |
| RV2 | Relief Valve, Steer - 1500 PSI |
| RV3 | Relief Valve, Front Drive Motors - 2800 PSI |
| RV4 | Relief Valve, Rear Drive Motors - 2800 PSI |
| PD1 - PD2 | Piloted Spool Valve, 4 Way - 3 Position |
| EP1-EP2-EP3 | Piloted Poppet Valve, Flow Divider Bypass |
| LS1-LS2-LS3 | Load Sense Shuttle Check Valve |
| CBV1 - CBV2 | Counter Balance Valve |
| CL1 | Coil, Series 8 - 12V |
| CL2 | Coil, Series 10 - 12V |
| CL3 | Coil, Series 10 E-Coil - 12V |
| FD1 - FD2 | Flow Divider / Combiner |
| EC1 | Pressure Compensator |
| CV1 - CV2 | Check Valve, Load Sense |
| CV3 - CV7 | Check Valve, Anti Cavitation |
| CV8 | Check Valve, Tank Return |
| OPL5 | Orifice Plug, Brake - 0.035 |
| OPL1 | Orifice Plug, Steer - 0.080 |
| OPL2 - OPL3 | Orifice Plug, Flow Divider Bleed - 0.040 |
| OPL4 | Orifice Plug, Compensator Bleed - 0.093 |

Figure 6-1: Hydraulic Schematic



MEC
ILLUSTRATION No.
ART_2076



Figure 6-2: Hydraulic Manifold





Figure 6-3: Hydraulic Components



ELECTRIC SCHEMATICS





ILLUSTRATION No.
ART_2079

Figure 6-4: Main Wiring Harness




ILLUSTRATION No. ART_2784



CIRCUIT BOARD SCHEMATIC

The Circuit Board schematic is broken into two pages for clarity. The cable connections are shown on this page. Match the numbers to line-up the traces.

Figure 6-5: Circuit Board Schematic, Part 1




Figure 6-6: Circuit Board Schematic, Part 2




ILLUSTRATION No.
ART_2082

Figure 6-7: Upper Control Box Schematic




ILLUSTRATION No. ART_2785



Figure 6-8: Upper Control Box with Outrigger Controls





ILLUSTRATION NO.
ART_2786




Figure 6-9: Lower Control Box



MEC
ILLUSTRATION No.
ART_2085



Figure 6-10: Engine Schematic



MEC
ILLUSTRATION No.
ART_2086



Figure 6-11: Outriggers Schematic (option)






ILLUSTRATION No.
ART_2088

Figure 6-12: Generator Schematic (option)



NOTES:






SECTION A

CONTROLS

| CONTENTS | PAGE |
|--|------|
| Upper Control Box | A-3 |
| Upper Control Box Cover Assembly | A-5 |
| Upper Controls Joystick | A-7 |
| Base Control Box | A-9 |





MEC
 ILLUSTRATION No.
 ART_2132 R1

X72RT and X91RT

Control Box, Upper

Upper Control Box

| ITEM | PART NO. | QTY | DESCRIPTION |
|-------------------------|----------|-------|------------------------------------|
| | 91139 | | Control Box Assembly, Ce |
| 1 | 16242 | 1 | Weldment, Control Box |
| 2 | 13865 | 1 | Bracket, Control Box Holder |
| 3 | 6350 | .5 FT | Tape, Foam |
| 4 | 6234 | 1 | Switch, Toggle, Lift/drive |
| 5 | 9183 | 1 | Lens, Red, Overload Indicator |
| | 9188 | 1 | Light, Bayonet, 14 Volt |
| | 9179 | 1 | Socket, Indicator Light |
| 6 | 6905 | 1 | Switch, Toggle, Speed/torque |
| 7 | 7800 | 1 | Switch, Emergency Stop |
| 8 | 91159 | 1 | Keyswitch |
| | 8082 | 1 | Contact Block, No |
| | 8083 | 1 | Contact Block, Nc |
| 9 | 8044 | 1 | Switch, Horn Button |
| 10 | 5630 | 1 | Switch, Toggle, Generator (Option) |
| 11 | 7423 | 1 | Switch, Toggle, Preheat |
| 12 | 91186 | 1 | Relay, Time Delay |
| 13 | 91184 | 1 | Wire Harness, Control Box |
| 14 | 91375 | 1 | Relay, Power |
| 15 | 91027 | 1 | Diode Block, 2 Position |
| 16 | 7553 | 1 | Alarm, Overload Warning |
| 17 | 91107 | 1 | PWM Card |
| 18 | 90814 | 2 | Spacer |
| 19 | 90833 | 2 | Screw, 6-32 X 3/4" |
| 20 | 5364 | 2 | Nut, 6-32 |
| 21 | 91028 | 1 | Diode Block, 4 Position |
| OUTRIGGER OPTION | | | |
| 22 | 91294 | 1 | Harness, Outrigger Control |
| 23 | 8638 | 1 | Switch, Toggle |
| 24 | 90789 | 1 | Led, Green, Drive Enabled |
| 25 | 16312 | 1 | Plate, Mounting, Outrigger Plug |
| 26 | 90833 | 2 | Screw, 6-32 X 3/4" |
| 27 | 5364 | 2 | Nut, 6-32 |
| 28 | 91028 | 1 | Diode Block, 4 Position |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Upper Control Box Cover Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-----------------------------|
| 1 | 13647 | 1 | Control Arm Cover |
| 2 | 3772 | 1 | Cover |
| 3 | 7875 | 1 | Gasket |
| 4 | 7882 | 1 | O-ring, 7/8" Id X 1 1/8" Od |
| 5 | HDW3768 | 1 | Washer, Flat |
| 6 | 7819 | 1 | Bearing, Bronze, Flanged |
| 7 | 8435 | 1 | Spring, Joystick, Centering |
| 8 | 1008348 | 1 | Pin, Hold Down |
| 9 | HDW7887 | 1 | Screw, #6-32, 1/2" Lg |
| 10 | 13502 | 1 | Bracket, Centering |
| 11 | 3763 | 1 | Spacer, Step |
| 12 | 13402 | 1 | Gear, Large |
| 13 | HDW8531 | 2 | Washer, Flat |
| 14 | HDW7881 | 1 | Washer, Bevel |
| 15 | 3782 | 1 | Cam. Directional |
| 16 | 13403 | 1 | Plate, Bottom |
| 17 | 6917 | 1 | Clamp, Cable 1/4 Inch |
| 18 | 7818 | 1 | Bearing, Bronze, Flanged |
| 19 | HDW3771 | 1 | Washer, Flat |
| 20 | 5736 | 1 | Ring, Retaining, 1/2 Inch |
| 21 | HDW8399 | 4 | Screw, #4 - 40, 5/8 Lg |
| 22 | HDW8567 | 2 | Washer, Flat |
| 23 | 8389 | 1 | Gear, Spur |
| 24 | 91522 | 1 | Potentiometer |
| 25 | HDW7888 | 12 | Screw, #10 - 32, 1/2" Lg |
| 26 | 3764 | 2 | Plate, Spacer |
| 27 | 8696 | 2 | Switch, Limit, Micro V7 |
| 28 | 3765 | 2 | Plate, Strap |
| 29 | 3766 | 1 | Plate, Top |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Upper Controls Joystick

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|------|--------------------------------------|
| | 13647 | | Control Arm Assembly, Joystick |
| 1 | 8750 | 1 | Pin (Service Only) |
| 2 | 8453 | 1 | Switch Actuator (Service Only) |
| 3 | HDW8455 | 4 | Screw, 6-1/2" Lg (Service Only) |
| 4 | 8752 | 1 | Grip-top Half (Service Only) |
| 5 | 8751 | 1 | Grip-bottom Half (Service Only) |
| 6 | 13638 | 1 | Control Arm Without Wire |
| 7 | 8748 | 1 | Trigger (Service Only) |
| 8 | 8456 | 1 | Rocker Boot (Service Only) |
| | 7476 | 5 | Amp Pins |
| | 8630 | 1 | Handle, Grip |
| | 8761 | 1 | Switch Assembly (Not Shown) |
| | 8089 | 1 ft | Wire, Blk 18ga 300 V |
| | 7777 | 2 | Terminal, Push On, 3/16" |
| 9 | 8447 | 1 | Switch Separator (Service Only) |
| 10 | 8753 | 1 | Motion Switch, On-off (Service Only) |
| 11 | 8448 | 2 | Switch (Service Only) |





ILLUSTRATION No.
ART_2774

X72RT and X91RT

Base Control Box: CE Models

Base Control Box

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---------------------------|
| | 91169 | | Base Control Box Assembly |
| 1 | 7800 | 1 | Switch, Emergency Stop |
| 2 | 7909 | 1 | Hour Meter |
| 3 | 91533 | 4 | Switch, Button, Green |
| 4 | 91534 | 1 | Switch, Button, Black |
| 5 | 91535 | 1 | Switch, Button, Red |
| 6 | 91329 | 1 | Plug |
| 7 | 91369 | 1 | Keyswitch, 2-position |
| 8 | | 1 | Key |
| 9 | 7235 | 2 | Circuit Breaker, 15 Amp |
| 10 | 91537 | 6 | Block, Contact, N.O. |
| 11 | 91538 | 2 | Block, Contact, N.C. |
| 12 | 91539 | 1 | Alarm, 107dB |
| 13 | 91370 | 1 | Circuit Board |
| 14 | 90714 | 1 | Mounting Plate, Keyswitch |
| 15 | 8082 | 2 | Contact Block, N.O. |

• as req: as required

• INCL: Included with assembly


• NS: Not a Stock item

• REF: Reference only



NOTES:





SECTION B

PLATFORM AND RAILS

| CONTENTS | PAGE |
|---|------|
| Platform Assembly | B-3 |
| Roll-out Deck Lock Pin Assembly | B-5 |
| Roll-out Deck Roller Assembly | B-7 |
| Entry Gate | B-9 |
| Control Cable and Horn Installation | B-11 |
| Power to Platform and Airline to Platform | B-13 |
| Lanyard Anchorage Points | B-15 |








 ILLUSTRATION No.

 ART_2094

2591RT - 3391RT - 4191RT

Platform and Rails

Platform Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 16436 | 1 | Rear Rail Weldment |
| 2 | 7805 | 1 | Padding, Rail (Optional) |
| 3 | 7048 | 1 | Cover, Rail Padding (Optional) |
| 4 | HDW7119 | 2 | Screw, 5/16" - 18, 2 1/4" LG, GR 5 |
| 5 | HDW5217 | 4 | Flat Washer, .343 ID x .688 OD x .063 THK |
| 6 | HDW8304 | 6 | Nut, 5/16" - 18 |
| 7 | HDW7593 | 6 | Pin, Wire Lock, Square, 3/8" x 2 1/4" LG |
| 8 | 16433 | 1 | Side Rail Weldment, LH |
| 9 | 14301 | 1 | Side Rail Weldment - Extension |
| 10 | 16435 | 1 | Front Rail Weldment |
| 11 | 8909 | 1 | Manual Enclosure |
| 12 | HDW5723 | 8 | Screw, 1/4" - 20, 1/2" LG |
| 13 | HDW8294 | 4 | Flat Washer, .328 ID x 1.000 OD x .100 THK |
| 14 | HDW8267 | 4 | Nut, 1/4" - 20 |
| 15 | 14415 | 2 | Bracket, Extension Stop |
| 16 | HDW5724 | 20 | Screw, 5/16" - 18, 3/4" LG, GR 5 |
| 17 | 14152 | 2 | Channel, Extension |
| 18 | 16429 | 1 | Extension Platform Weldment |
| 19 | 16437 | 1 | Main Platform Weldment |
| 20 | HDW8856 | 2 | Screw, 1/2"-13, 5" LG |
| 21 | HDW8457 | 2 | Nut, 1/2" - 13 |
| 22 | 14313 | 1 | Right Side Rail Weldment - Extension |
| 23 | HDW8974 | 1 | Pin, Wire Lock, Square, 3/8" x 3" LG |
| 24 | 6823 | 2 | Cap Plug, 1 1/4" |
| 25 | 16434 | 1 | Side Rail Weldment, RH |
| 26 | HDW8279 | 10 | Screw, 3/8-16, 2 1/2" LG |
| 27 | HDW8268 | 10 | Nut, 3/8-16 |
| 28 | 20552 | 1 | Cover, Platform Cord |
| 29 | 91284 | 1 | Pin Hitch 3/8" x 4 |
| 30 | HDW5355 | 20 | Washer, Flat, .438 IDx1.00 ODx.078 THK |
| 31 | HDW6434 | 3 | Screw, 3/8-16x2" LG |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only







 ILLUSTRATION No.
 ART_2133

Roll-out Deck Lock Pin Assembly

Roll-out Deck Lock Pin Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|--------|--------------------------------|
| 1 | 13737 | 1 | Pin, Extension Lock |
| 2 | 7184 | 3.7 FT | Cable, Coated and Rolled |
| 3 | 8814 | 2 | Sleeve, Aluminum Oval |
| 4 | 20235 | 1 | Handle |
| 5 | HDW8303 | 1 | Screw, 5/16" - 18, 2" LG |
| 6 | HDW8304 | 1 | Locknut, 5/16" - 18 |
| 7 | 7408 | 1 | Spring, Deck Lock |
| 8 | HDW7031 | 1 | Washer, Flat, 1/2" ID 7/8" OD |
| 9 | HDW8513 | 1 | Pin, Spring, 1/8" Dia. 3/4" LG |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2095

Reference: ART_687

Roll-out Deck Roller

Roll-out Deck Roller Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 5918 | 1 | Retaining Ring, Heavy Duty 1" |
| 2 | HDW8370 | 1 | Washer, Flat, 1.015 Id x 1.375 Od x .062 Thk |
| 3 | 13230 | 1 | Roller |
| 4 | 14062 | 1 | Roller Plate Weldment |
| 5 | HDW5724 | 4 | Screw, 5/16" - 18, 3/4" LG |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2097

Gate

Entry Gate

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---------------------------------------|
| 1 | 40003 | 1 | Latch Pin, Rear Gate |
| 2 | 7055 | 1 | Spring, Latch, .480 DIA. OD x 1.5" LG |
| 3 | 40006 | 1 | Rod, Latch Lever, Rear Gate |
| 4 | HDW6434 | 1 | Screw, 3/8-16 x 2" LG |
| 5 | 8187 | 2 | Bearing, Nyliner, 5/8" ID x 5/8" LG |
| 6 | 40014 | 1 | Mounting Bracket, Upper |
| 7 | HDW8294 | 6 | Washer, .328" ID x 1" OD x .100" THK |
| 8 | HDW8486 | 4 | Screw, 5/16" - 18, 1 7/8" LG, GR 5 |
| 9 | 6823 | 1 | Cap Plug, 1 1/4" Square |
| 10 | 8300 | 1 | Spring, Torsion, 1" DIA. OD x 4" LG |
| 11 | 13272 | 1 | Block, Pivot, Rear Gate |
| 12 | 40015 | 1 | Mounting Bracket, Lower |
| 13 | 40017 | 1 | Swing Gate Weldment |
| 14 | 30814 | 1 | Strike Plate |
| 15 | HDW8303 | 2 | Screw, 5/6"-18, 2" LG, GR 5 |
| 16 | HDW7120 | 2 | Nut, 5/16"-18, GR 5 |
| 17 | HDW8268 | 1 | Nut, 3/8-16 |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only







ILLUSTRATION No.
ART_2098 R1

2591RT - 3391RT - 4191RT

Control Cable / Horn Installation

Control Cable and Horn Installation

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 9716 | 1 | Horn, 12-48Vdc |
| 2 | HDW5217 | 2 | Washer, Flat, .343 ID x .688 OD x .063 THK |
| 3 | HDW6455 | 5 | Screw, ¼"-20, ½" LG, GR 5 |
| 4 | HDW5363 | 3 | Screw, #6-32, 1" LG, GR 5 |
| 5 | HDW5364 | 3 | Nut, Keps, #6-32, GR 5 |
| 6 | 6947 | 1 | Terminal Strip |
| 7 | 6964 | 4 | Clamp, Cable, 1" DIA. |
| 8 | REF | | Cable, Upper Control |
| 9 | 16485 | 1 | Cover, Terminal Strip |
| 0 | 5863 | 1 | Grommet, 1.5 ID x 1.75 OD x .187 THK |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2099

Power to Platform

Power to Platform and Airline to Platform

| ITEM | PART NO. | QTY | DESCRIPTION |
|---|----------|-----|---|
| Power to Platform | | | |
| 1 | 90827 | 1 | Box, Receptacle |
| 2 | 90828 | 1 | Duplex Receptacle Cover |
| 3 | HDW5636 | 1 | Screw #6 - 32 x 0.25" |
| 4 | HDW6455 | 2 | Screw, 1/4" - 20, 1/2" LG |
| 5 | HDW8267 | 2 | Locknut 1/4" - 20 |
| 6 | 5381 | 1 | Receptacle, Duplex |
| 7 | 8208 | 1 | Conduit, 3/8" Flexible |
| 8 | 8209 | 1 | Ferrule, 3/8" |
| 9 | 8479 | 1 | Bushing, 3/4" ID |
| 10 | 8833 | 1 | Connector, Outlet Box 3/8" Conduit |
| 11 | 16221 | 1 | Bracket |
| 12 | HDW5724 | 2 | Screw, 5/16-18 x 3/4" |
| 13 | HDW8304 | 2 | Nut, 5/16-18 |
| | HDW8501 | 2 | Clip, Self Retaining (Not Shown) |
| | 9441 | * | Wire, 14 GA (Not Shown) *2591RT = 50 FT. *3391RT = 58 FT. *4191RT = 68 FT. |
| | HDW5217 | 2 | Flat Washer 11/32" ID (Not Shown) |
| Airline to Platform (Option) (Not Shown) | | | |
| | 5351 | | |
| | 91399 | * | Hose, 3/8" Airline *2591RT = 49 FT. *3391RT = 57 FT. *4191RT = 67 FT. |
| | 8559 | 2 | Clamp, Hose |
| | HDW91500 | 2 | Fitting, 1/4" Male, Male Hose Barb |
| | 5882 | 2 | Cable Clamp |



2 8606

WARNING

- LANYARD ANCHORAGE POINTS ARE RECOMMENDED FOR WORK POSITIONING RESTRAINTS ONLY.

USE OF FALL ARREST SYSTEMS ATTACHED TO ANCHORAGE POINTS ON MOBILE EQUIPMENT MAY CAUSE MACHINE TO TIP, RESULTING IN SERIOUS INJURY OR DEATH.

8606



MEC
ILLUSTRATION No.
ART_2775

2591RT - 3391RT - 4191RT


Lanyard Anchorage Points

Lanyard Anchorage Points

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--------------------------------|
| | 14583 | | Add-on Lanyard Attachment |
| 1 | HDW6433 | 8 | Screw, 3/8" - 16, 1" LG, GR 5 |
| 2 | HDW8268 | 8 | NUT, 3/8" - 16, GR 5 |
| 3 | 8605 | 4 | Decal, Lanyard Attach Point |
| 4 | 3923 | 4 | Bracket, Attach Point |
| 5 | 8606 | 1 | Decal, Warning, Pos Restraints |



NOTES:






SECTION C

SCISSORS

| CONTENTS | PAGE |
|---------------------------------------|------|
| Scissor Assembly, 2591RT | C-3 |
| Scissor Assembly, 3391RT | C-5 |
| Scissor Assembly, 4191RT | C-7 |
| Cable Routing, Scissor Assembly | C-9 |
| Limit Switch Installation | C-11 |
| Scissor Guards | C-13 |





meccano
ILLUSTRATION No. 2591RT
ART_2101-R1

Scissor Assembly

Scissor Assembly, 2591RT

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-----------------------------|
| 1 | 20141 | 2 | Block, Slide - Platform |
| 2 | 16468 | 1 | Beam, Single Cylinder Mount |
| 3 | HDW6455 | 14 | Screw, 1/4" - 20, 1/2" LG |
| 4 | 20913 | 1 | Guard, Control Cord, Short |
| 5 | 20948 | 2 | Beam Weldment, 3 X 6 |
| 6 | HDW7783 | 8 | Washer, Split, Lock, 3/8" |
| 7 | HDW8277 | 8 | Screw, 3/8" - 16, 1 3/4" LG |
| 8 | 20365 | 2 | Scissors Mount Assembly |
| 9 | 8340 | 1 | Pin, Roller - Platform |
| 10 | HDW5724 | 8 | Screw, 5/16"-18, 3/4" LG |
| 11 | 20223 | 4 | Plate, Cylinder Pin Lock |
| 12 | 20224 | 2 | Pin, Cylinder |
| 13 | 20932 | 4 | Beam, Outer, 3 X 8 |
| 14 | 20839 | 1 | Guard, Control Cord |
| 15 | 20778 | 1 | Lock, Maintenance |
| 16 | 21133 | 2 | Bracket, Maintenance Lock |
| 17 | 6688 | 4 | Clip Ring, 2" Shaft |
| 18 | 20429 | 2 | Block, Fixed - Base |
| 19 | HDW8856 | 4 | Screw, 1/2" -13, 5" LG |
| 20 | HDW6463 | 4 | Nut, 1/2" - 13, Nylon |
| 21 | 16460 | 1 | Beam, Single Cylinder Mount |
| 22 | 20142 | 2 | Block, Slide - Base |
| 23 | 6701 | 18 | Ring, Retaining, 2" Shaft |
| 24 | 91403 | 1 | Cylinder, Lift |
| 25 | 20937 | 1 | Beam, Inner, Center |
| 26 | 6669 | 38 | Bearing |
| 27 | 20413 | 1 | Pin-slide, Base |
| 28 | 25429 | 16 | Spacer Block |
| 29 | 6670 | 2 | Bearing |




• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





mec
ILLUSTRATION No.
ART_2102-R1 3391RT

Scissor Assembly

Scissor Assembly, 3391RT

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-----------------------------|
| 1 | 20141 | 2 | Block, Slide - Platform |
| 2 | 20957 | 1 | Beam, Inner, 3 X 6 |
| 3 | 20939 | 2 | Beam, Outer, 3 X 6 |
| 4 | 8340 | 1 | Pin, Roller - Platform |
| 5 | 20365 | 2 | Scissors Mount Assembly |
| 6 | HDW7783 | 8 | Washer, Split, Lock, 3/8" |
| 7 | HDW8277 | 8 | Screw, 3/8"-16, 1 3/4" LG |
| 8 | 20932 | 6 | Beam, 3 X 8 |
| 9 | HDW5724 | 8 | Screw, 5/16"-18, 3/4" LG |
| 10 | 20223 | 4 | Plate, Cylinder Pin Lock |
| 11 | 6669 | 50 | Bearing |
| 12 | 20224 | 2 | Pin, Cylinder |
| 13 | 16469 | 1 | Beam, Inner, Cylinder Mount |
| 14 | 20778 | 1 | Lock, Maintenance |
| 15 | HDW6455 | 4 | Screw, 1/4"- 20, 1/2" LG |
| 16 | 21133 | 2 | Bracket, Maintenance Lock |
| 17 | 6688 | 4 | Clip Ring, 2" Shaft |
| 18 | 20429 | 2 | Clip Ring, 2" Shaft |
| 19 | HDW8856 | 4 | Block, Fixed - Base |
| 20 | HDW6463 | 4 | Nut, 1/2" - 13, Nylon |
| 21 | 20937 | 1 | Beam, Inner, Center |
| 22 | 16460 | 1 | Beam, Single Cylinder Mount |
| 23 | 20142 | 2 | Cylinder, Lift |
| 24 | 91403 | 1 | Ring, Retaining, 2" Shaft |
| 25 | 6701 | 24 | Ring, Retaining, 2" Shaft |
| 26 | 6670 | 2 | Bearing |
| 27 | 20413 | 1 | Pin, Slide, Base |
| 28 | 25429 | 24 | Spacer Block |




• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





mecc
ILLUSTRATION No.
ART_2103-R1 4191RT

Scissor Assembly

Scissor Assembly, 4191RT

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-----------------------------------|
| 1 | 20141 | 2 | Block, Slide - Platform |
| 2 | 20935 | 1 | Beam, Single Cylinder Mount |
| 3 | 20939 | 2 | Beam, Outer, 3 X 6 |
| 4 | 8340 | 1 | Pin, Roller - Platform |
| 5 | 20365 | 2 | Scissors Mount Assembly |
| 6 | HDW7783 | 8 | Washer, Split, Lock, 3/8" |
| 7 | HDW8277 | 8 | Screw, 3/8" - 16, 1 3/4" LG |
| 8 | HDW5724 | 16 | Screw, 5/16"-18, 3/4" LG |
| 9 | 20223 | 8 | Plate, Cylinder Pin Lock |
| 10 | 20938 | 4 | Beam, Outer, 3 X 8 |
| 11 | 20224 | 4 | Pin, Cylinder |
| 12 | 16467 | 1 | Beam, Inner, Center |
| 13 | 20932 | 4 | Beam Weldment |
| 14 | 20933 | 1 | Beam, Double Cylinder Mount |
| 15 | 20778 | 1 | Lock, Maintenance |
| 16 | HDW6455 | 14 | Screw, 1/4" - 20, 1/2" LG |
| 17 | 21133 | 2 | Bracket, Maintenance Lock |
| 18 | 6688 | 4 | Clip Ring, 2" Shaft |
| 19 | 20429 | 2 | Block, Fixed - Base |
| 20 | HDW8856 | 4 | Screw, 1/2" - 13, 5" LG |
| 21 | HDW6463 | 4 | Nut, 1/2" - 13, Nylon |
| 22 | 16460 | 1 | Beam, 1/4", Single Cylinder Mount |
| 23 | 20937 | 1 | Beam Weldment |
| 24 | 20142 | 2 | Block, Slide - Base |
| 25 | 91404 | 1 | Cylinder, Lift - Lower |
| 26 | 6701 | 30 | Ring, Retaining, 2" Shaft |
| 27 | 91405 | 1 | Cylinder, Lift - Upper |
| 28 | 20913 | 1 | Guard, Control Cord, Short |
| 29 | 20839 | 1 | Guard, Control Cord |
| 30 | 20413 | 1 | Pin, Slide, Base |
| 31 | 25429 | 32 | Spacer Block |
| 32 | 6669 | 62 | Bearing |
| 33 | 6670 | 2 | Bearing |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item


• REF: Reference only






1

2591RT



2

3391RT



3

4191RT



ILLUSTRATION No.
ART_2062 R1

2591RT - 3391RT - 4191RT

Cable Routing, Scissor Assembly

Cable Routing, Scissor Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-----------------------|
| 1 | 91185 | | Control Cable, 2591RT |
| 2 | 91321 | | Control Cable, 3391RT |
| 3 | 91439 | | Control Cable, 4191Rt |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2787

2591RT - 3391RT - 4191RT: CE

Limit Switch Installation

Limit Switch Installation

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--------------------------|
| 1 | 20924 | 1 | Cover, Limit Switch |
| 2 | HDW6455 | 4 | Screw, 1/4"- 20, 1/2" LG |
| 3 | HDW8482 | 2 | Screw, #8-32, 1 1/2" LG |
| 4 | HDW5251 | 2 | Nut, #8-32 |
| 5 | 90996 | 1 | Switch, Limit, 3-pole |
| 6 | 7594 | 1 | Connector, Cord |
| 7 | 20838 | 1 | Cam, Slow Speed |
| 8 | 90844 | 1 | Height Sensor |
| 9 | HDW6831 | 2 | Screw, 1/4"-20, 2" LG |



• as req: as required


• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





 ILLUSTRATION No. 2591RT - 3391RT - 4191RT: CE MODELS
ART_2776

Scissor Guards

Scissor Guards

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---|
| 1 | 16816 | 2 | Scissor Guard – Front Panel, Rear Panel |
| 2 | 16817 | 1 | Scissor Guard – Right Front Panel |
| 3 | 16818 | 1 | Scissor Guard – Left Front Panel |
| 4 | 16819 | 1 | Scissor Guard – Right Rear Panel |
| 5 | 16820 | 1 | Scissor Guard – Left Rear Panel |

• as req: as required

• INCL: Included with assembly


• NS: Not a Stock item

• REF: Reference only



NOTES:






SECTION D

AXLES

| CONTENTS | PAGE |
|----------------------------------|------|
| Rear Axle Assembly | D-3 |
| Front Axle Assembly | D-5 |
| Drive Hub with Brake, Rear | D-7 |
| Drive Hub, Front | D-9 |





MEC
ILLUSTRATION No.
ART_2105 R1

2591RT - 3391RT - 4191RT

Rear Axle Assembly

Rear Axle Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 10423 | 1 | Pivot Pin Weldment |
| 2 | HDW5204 | 2 | Screw, 5/16-18 × 1" |
| 3 | 6984 | 2 | Bearing, 1 3/8 × 1 5/8" LG |
| 4 | HDW13339 | 3 | Washer, Flat Nylon, 1 3/8 ID × 2 1/4 OD × .030 THK |
| 5 | 10424 | 2 | Axle Guide, Nylon |
| 6 | 90531 | 1 | Limit Switch, Axle Center Position |
| 7 | HDW8482 | 2 | Screw, #8-32 × 1.5" LG |
| 8 | HDW5251 | 2 | Nut, #8-32 |
| 9 | 91406 | 2 | Axle Lock Cylinder |
| 10 | 16478 | 2 | Clevis Pin Weldment, 5/8" × 5 1/4" |
| 11 | HDW8273 | 2 | Screw, 1/4-20 |
| 12 | HDW8267 | 6 | Nut, 1/4-20 |
| 13 | 16479 | 2 | Clevis Pin Weldment, 5/8" × 2 1/8" |
| 14 | HDW5723 | 2 | Screw, 1/4-20 × 3/4" |
| 15 | 16482 | 2 | Cover, Rear Axle |
| 16 | 16484 | 2 | Bracket, Axle Cover |
| 17 | 91402 | 2 | Motor, Hydraulic Drive |
| | 91560 | | Seal Kit |
| 18 | 91400 | 2 | Drive Hub w/Brake |
| 19 | HDW8283 | 4 | Screw, 1/2-13 × 1 1/2" GR8 |
| 20 | HDW5012 | 4 | Lock Washer, 1/2" |
| 21 | HDW90784 | 4 | Washer, Flat, .531 ID × 1.063 OD × .104 THK |
| 22 | HDW91407 | 12 | Screw, 5/8-11 × 1 1/2 Socket Head GR8 |
| 23 | HDW5994 | 12 | Washer, Lock, 5/8" |
| 24 | HDW91420 | 18 | Nut, Lug, 5/8-18 |
| 25 | 91411 | 1 | Wheel Tire Assy, RH, Air Filled |
| | 91413 | 1 | Wheel Tire Assy, RH, Foam Filled Option |
| | 91432 | 1 | Wheel Tire Assy, RH, Non-Marking Air Option |
| | 91445 | 1 | Wheel Tire Assy, RH, Non-Marking Foam Option |
| 26 | 91412 | 1 | Wheel Tire Assy, LH, Air Filled |
| | 91414 | 1 | Wheel Tire Assy, LH, Foam Filled Option |
| | 91433 | 1 | Wheel Tire Assy, LH, Non-Marking Air Option |
| | 91446 | 1 | Wheel Tire Assy, LH, Non-Marking Foam Option |
| 27 | HDW8984 | 2 | Fitting, MB-MJ-12-8 |
| 28 | HDW8081 | 1 | Fitting, MB-MJ90-8-6 |
| 29 | HDW91428 | 1 | Fitting, MB-MJ45-4-4 |
| 30 | HDW8881 | 1 | Fitting, MB-MJ-4-4 |
| 31 | 91419 | 2 | O-Ring (not shown) |

• as req: as required

• INCL: Included with assembly


• NS: Not a Stock item

• REF: Reference only




TORQUE TABLE


| Part # | Desc | Ft-lbs | Nm |
|--------|---------|---------|-----------|
| 27 | Fitting | 80 - 85 | 110 - 118 |
| 28 | Fitting | 25 - 30 | 34 - 41 |
| 29 | Fitting | 5 - 10 | 9 - 12 |



RIGHT MOTOR



LEFT MOTOR



Front Axle Assembly

ILLUSTRATION No. 2591RT - 3391RT - 4191RT
 ART_2106 R1

Front Axle Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---|
| 1 | HDW5920 | 2 | Pin, Cotter, .12 x 1" |
| 2 | HDW90770 | 2 | Pin, Clevis, 1/2 x 1 3/8" |
| 3 | 91019 | 1 | Cylinder, Steering |
| | 90990 | | Seal Kit, Steering Cylinder (not shown) |
| 4 | 16407 | 1 | Bar, Steering |
| 5 | HDW7326 | 2 | Screw, 5/8-11 x 4" GR5 |
| 6 | HDW9219 | 4 | Washer, .656 ID x 1.312 OD x .093 THK |
| 7 | 7292 | 2 | Bearing, Bronze |
| 8 | HDW6633 | 2 | Nut, 5/8-11 Lock |
| 9 | 16408 | 4 | King Pin Weldment |
| 10 | HDW6211 | 16 | Screw, 1/2-13 x 1 1/4" GR5 |
| 11 | HDW5012 | 16 | Lock Washer, 1/2" |
| 12 | HDW8283 | 4 | Screw, 1/2-13 x 1 1/2" GR8 |
| 13 | HDW90784 | 4 | Washer, Flat, .531 ID x 1.063 OD x .104 THK |
| 14 | HDW5994 | 12 | Washer, Lock, 5/8 |
| 15 | HDW91047 | 12 | Screw, 5/8-11 x 1 1/2 Socket Head GR8 |
| 16 | 91408 | 4 | Thrust Bearing, 1 3/4 ID x 2 5/8 OD x 1/8 THK |
| 17 | 7896 | 4 | Bearing, 1 3/4 ID x 1" LG |
| 18 | 16425 | 2 | Steering Knuckle Weldment |
| 19 | HDW8457 | 4 | Lock Nut, 1/2-13 |
| 20 | 16471 | 1 | Hose Guard Weldment, LH |
| 21 | 16470 | 1 | Hose Guard Weldment, RH |
| 22 | 91402 | 2 | Motor, Hydraulic Drive |
| | 91560 | | Seal Kit |
| 23 | 91401 | 2 | Drive Hub |
| 24 | HDW91420 | 18 | Nut, Lug, 5/8-18 |
| 25 | 91411 | 1 | Wheel Tire Assy, RH, Air Filled |
| | 91413 | 1 | Wheel Tire Assy, RH, Foam Filled Option |
| | 91432 | 1 | Wheel Tire Assy, RH, Non-Marking Air Option |
| | 91445 | 1 | Wheel Tire Assy, RH, Non-Marking Foam Option |
| 26 | 91412 | 1 | Wheel Tire Assy, LH, Air Filled |
| | 91414 | 1 | Wheel Tire Assy, LH, Foam Filled Option |
| | 91433 | 1 | Wheel Tire Assy, LH, Non-Marking Air Option |
| | 91446 | 1 | Wheel Tire Assy, LH, Non-Marking Foam Option |
| 27 | HDW8984 | 2 | Fitting, MB-MJ-12-8 |
| 28 | HDW8081 | 1 | Fitting, MB-MJ90-8-6 |
| 29 | HDW91428 | 1 | Fitting, MB-MJ45-4-4 |
| 30 | 91419 | 2 | O-Ring (not shown) |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Drive Motor with Brake


 ILLUSTRATION No.
 ART_2107 R1

Drive Hub with Brake, Rear

| ITEM | PART NO. | QTY | DESCRIPTION |
|----------|--------------|-----|---|
| | 91400 | | Drive Hub, Rear |
| 1 | 91562 | | Seal Kit |
| 1A | INCL | 1 | Seal, Lip |
| 1B | INCL | 2 | Screw, Set-Socket |
| 1C | INCL | 3 | Bolt, Flat Head - Hex Socket |
| 1D | INCL | 1 | O-ring |
| 1E | INCL | 1 | O-ring, End Cover (available separate from kit) |
| 1F | INCL | 1 | Nut, Bearing |
| 2 | 91563 | | Brake Seal Kit |
| 2A | INCL | 1 | Retainer, Ring - Internal |
| 2B | INCL | 1 | O-ring |
| 2C | INCL | 1 | O-ring, Back-up |
| 2D | INCL | 1 | O-ring, Back-up |
| 2E | INCL | 1 | O-ring |
| 3 | 91564 | | Brake Lining Kit (Includes Seal Kit 91563) |
| 3A | INCL | 8 | Reaction Disc, Brake Rotor |
| 3B | INCL | 9 | Friction Disc, Brake, Stator |
| 4 | 91565 | 2 | Bearing Assembly |
| 5 | 91566 | 9 | Wheel Stud |
| 6 | 91567 | 1 | Disengage Rod |
| 7 | 91568 | 1 | Disengage Cap |
| 8 | 91569 | 1 | End Cover O-ring |
| 9 | 91571 | 2 | End Cover plug |
| 10 | HDW5633 | 2 | Screw ¼-20 × ½" LG |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Drive Motor


MEC
 ILLUSTRATION No.
 ART_2108 R1

Drive Hub, Front

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---|
| | 91400 | | Drive Hub, Rear |
| 1 | 91562 | | Seal Kit |
| 1A | INCL | 1 | Seal, Lip |
| 1B | INCL | 2 | Screw, Set-Socket |
| 1C | INCL | 3 | Bolt, Flat Head - Hex Socket |
| 1D | INCL | 1 | O-ring |
| 1E | INCL | 1 | O-ring, End Cover (available separate from kit) |
| 1F | INCL | 1 | Nut, Bearing |
| 2 | 91565 | 2 | Bearing Assembly |
| 3 | 91566 | 9 | Wheel Stud |
| 4 | 91567 | 1 | Disengage Rod |
| 5 | 91568 | 1 | Disengage Cap |
| 6 | 91569 | 1 | End Cover O-ring |
| 7 | 91571 | 2 | End Cover plug |
| 8 | HDW5633 | 2 | Screw 1/4-20 x 1/2" LG |

NOTES:





SECTION E

HYDRAULICS

| CONTENTS | PAGE |
|--|------|
| Manifold Assembly | E-3 |
| Manifold Assembly – Hardware | E-5 |
| Manifold – Outrigger Option | E-7 |
| Hydraulic Hoses – Drive – Lift | E-9 |
| Hydraulic Hoses – Brake and Oscillating Axle – Pump and Tank Return | E-11 |
| Hydraulic Hoses – Steering –Wheek Motor Case Drain | E-13 |
| Hydraulic Hoses – Outrigger Option | E-15 |
| Hydraulic Hoses – Generator Option | E-17 |
| Cylinder, Lift – 2591RT and 3391RT | E-19 |
| Cylinder, Lift – 4191RT (Lower) | E-21 |
| Cylinder, Lift – 4191RT (Upper) | E-23 |
| Cylinder, Steering | E-25 |
| Cylinder, Floating Axle Lock | E-27 |
| Cylinder, Outrigger (option) | E-29 |



TORQUE TABLE

| Part # | Desc | Ft-lbs | Nm |
|--------|-----------------------|--------|-----------|
| 1 | Coil, SV08 | 4-5 | 4.5-6.8 |
| 2 | Coil, SV10 | 5-7 | 6.8-9.5 |
| 3 | E-Coil, SV10 | 7-10 | 9.5-13.6 |
| 4 | Valve, SVD03 | 6-8 | 8.5-10.5 |
| 5 | Valve, SV10 | 25-27 | 34.0-36.7 |
| 6 | Valve, SV08 | 18-20 | 24.5-27.2 |
| 7 | Valve, SV08 | 18-20 | 24.5-27.2 |
| 8 | Valve, SP10 | 25-27 | 34.0-36.7 |
| 9 | Valve, RV08 | 18-20 | 24.5-27.2 |
| 10 | Valve, RV08 | 18-20 | 24.5-27.2 |
| 11 | Valve, PD12 | 33-37 | 44.9-50.3 |
| 12 | Valve, EP10 | 25-27 | 34.0-36.7 |
| 13 | Valve, LS08 | 18-20 | 24.5-27.2 |
| 14 | Valve, RV08 | 18-20 | 24.5-27.2 |
| 15 | Valve, Counterbalance | 18-20 | 24.5-27.2 |
| 16 | Valve, CV08 | 12-14 | 16.3-19.0 |
| 17 | Plug | 10-20 | 13.5-27.2 |
| 18 | Plug | 10-20 | 13.5-27.2 |
| 19 | Flow Div, FD10 | 25-27 | 34.0-36.7 |
| 20 | Orifice | — | — |
| 21 | Orifice | — | — |
| 22 | Orifice | — | — |
| 23 | Orifice | — | — |
| 24 | Comp, EC10 | 25-27 | 34.0-36.7 |
| 25 | Valve, SV07 | 18-20 | 24.5-27.2 |
| 26 | Valve, CV12 | 33-37 | 44.9-50.3 |






 ILLUSTRATION No. 2591RT - 3391RT - 4191RT
 ART_2109 R1

Hydraulic Manifold

Manifold Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| | 91410 | | Manifold Assembly |
| 1 | 91141 | 4 | Coil, Series 8, 12V |
| 2 | 91142 | 1 | Coil, Series 10, 12V |
| 3 | 91143 | 1 | Coil, Series 10 E-coil, 12V |
| 4 | 91144 | 1 | Valve, Drive, 4 way 3 Position |
| 5 | 91145 | 1 | Valve, Lift Spool, 3 Way 2 Position |
| 6 | 91146 | 1 | Valve, Steer, 4 Way 3 Position |
| 7 | 91147 | 1 | Valve, Torque, Spool, 4 Way 2 Position |
| 8 | 91148 | 1 | Valve, Proportional, 12 V |
| 9 | 91149 | 1 | Valve, Relief, Lift |
| 10 | 91150 | 1 | Valve, Relief, Steer |
| 11 | 91151 | 2 | Valve, Piloted Spool 4 Way 3 Position |
| 12 | 91152 | 3 | Valve, Piloted Poppet |
| 13 | 91153 | 3 | Valve, Load Shuttle Check |
| 14 | 91476 | 2 | Valve, Relief, Drive |
| 15 | 91350 | 2 | Valve, Counterbalance |
| 16 | 91477 | 7 | Valve, Check |
| 17 | HDW7314 | 12 | Port Plug M 1/4", O-Ring, RBG-4 |
| 18 | 7484 | 2 | Port Plug M 0.38" O-Ring, RBG-6 |
| 19 | 91351 | 2 | Flow Divider / Combiner |
| 20 | 91355 | 1 | Orifice Plug, Steer |
| 21 | 91356 | 2 | Orifice Plug, Flow Divider Bleed |
| 22 | 91474 | 1 | Orifice Plug, Brake |
| 23 | 91475 | 1 | Orifice Plug, Compensator |
| 24 | 91352 | 1 | Pressure Compensator |
| 25 | 91472 | 1 | Valve, Speed Spool 3 Way 2 Position |
| 26 | 91473 | 1 | Check Valve, Tank Return |





LEFT

FRONT

TORQUE TABLE

| Part # | Desc | Ft-lbs | Nm |
|--------|---------------|--------|----------|
| 1 | Elbow, 1/2" | 25-30 | 34-41 |
| 2 | Elbow, 1/2" | 25-30 | 34-41 |
| 3 | Elbow, 1/4" | 5-10 | 6.8-13.6 |
| 4 | Elbow, 1/4" | 5-10 | 6.8-13.6 |
| 5 | Elbow, 3/4" | 85-90 | 115-122 |
| 6 | Elbow, 3/4" | 85-90 | 115-122 |
| 7 | Adapter, 3/8" | 10-20 | 14-27 |
| 8 | Fitting, 1/4" | 5-10 | 6.8-13.6 |
| 9 | Adapter, 1/4" | N/A | N/A |
| 10 | Adapter, 1/4" | 5-10 | 6.8-13.6 |
| 11 | Elbow, 3/8" | 10-20 | 14-27 |
| 12 | Plug | 10-20 | 14-27 |
| 13 | Plug | 10-20 | 14-27 |



MEC
ILLUSTRATION No.
ART_2110 R1

2591RT - 3391RT - 4191RT

Hydraulic Manifold – Hardware

Manifold Assembly – Hardware

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| | 91410 | | Manifold Assembly |
| 1 | HDW91248 | 4 | Elbow, 90°, Male, ½", O-Ring, Male, ½", MB-MJ90LL-8-8 |
| 2 | HDW90764 | 4 | Elbow, 90°, Male, ½", O-Ring, Male, ½", MB-MJ90-8-8 |
| 3 | HDW8877 | 2 | ELBOW, 90°, MALE ¼" O-RING, MALE ¼", MB-MJ90-4-4 |
| 4 | HDW91081 | 1 | ELBOW, 90°, MALE ¼" O-RING, MALE ¼", MB-MJ90LL-4-4 |
| 5 | HDW91244 | 1 | ELBOW, 90°, MALE ¾" O-RING, MALE ¾", MB-MJ90-12-12 |
| 6 | HDW91245 | 1 | ELBOW, 90°, M ¾" O-RING, M ¾", MB-MJ90LL-12-12 |
| 7 | HDW7438 | 1 | Adapter, Male 3/8 O-ring, Male 3/8 JIC, MB-MJ-6-6 |
| 8 | HDW7971 | 1 | Fitting, Male Disconnect, ¼" NPT |
| 9 | HDW91243 | 1 | adapter Male ¼" orng M ¼" NTP, MP-MB-4-4 |
| 10 | HDW8881 | 3 | ADAPTER, MALE ¼", O-RING, MALE ¼" 37° MB-MJ-4-4 |
| 11 | HDW7601 | 2 | Elbow, 90°, Male 3/8 O-ring, Male 3/8 JIC, MB-MJ90-6-6 |
| 12 | 7484 | 2 | Plug (without outrigger option) |
| 13 | HDW7314 | 1 | Plug (without outrigger option) |



• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





TORQUE TABLE

| Part # | Desc | Ft-lbs | Nm |
|--------|---------------|--------|-----------|
| 1 | Manifold | N/A | N/A |
| 2 | Elbow, 3/8" | 10-20 | 14-27 |
| 3 | Adapter, 1/4" | 5-10 | 6.8-14 |
| 4 | Adapter, 3/8" | 10-20 | 14-27 |
| 5 | Coil, SV10 | 5-7 | 6.8-9.5 |
| 6 | Valve, SV10 | 25-27 | 34.0-36.7 |



ILLUSTRATION No.
ART_2111 R1

2591RT - 3391RT - 4191RT

Outrigger Manifold

Manifold – Outrigger Option

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 91268 | 1 | Outrigger Manifold Assembly |
| 2 | HDW7601 | 3 | Elbow 90° Male 3/8" O-ring - Male 3/8" JIC |
| 3 | HDW8881 | 1 | Adapter Male 1/4" O-ring - Male 1/4" Jic |
| 4 | HDW7438 | 1 | Adapter Male 3/8" O-ring - Male 3/8" JIC |
| 5 | 91142 | 2 | Coil |
| 6 | 91008 | 1 | Valve Spool 4-way 3-position |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only



POWER MODULE

CONTROL MODULE




ILLUSTRATION No.
ART_2112 R1

2591RT - 3391RT - 4191RT

Hydraulic Hose Routing – Drive – Lift

Hydraulic Hoses – Drive – Lift

| ITEM | PART NO. | QTY | DESCRIPTION |
|--------------|----------|-----|---|
| Drive | | | |
| 1 | 91425 | 2 | Hose Assy, ½"×74", 8M3K-8FJX-8FJX45-74" |
| 2 | 91426 | 4 | Hose Assy, ½"×116", 8M3K-8FJX-8FJX45-116" |
| 3 | 91427 | 2 | Hose Assy, ½"×148", 8M3K-8FJX-8FJX45-148" |
| 4 | HDW9557 | 4 | TEE, Male ¼ JIC m ¼ JIC |
| 5 | HDW90332 | 1 | TEE, Female ¼ JIC × Male ¼ JIC |
| 6 | 90275 | 1 | Hose Assy, ¼" × 17", 4G1-4FJX-4FJX-17 |
| 7 | 9393 | 1 | Hose Assy, ¼" × 48", 4G1-4FJX-4FJX-48 |
| 8 | 9847 | 2 | Hose Assy, ¼" × 76", 4G1-4FJX-4FJX |
| 9 | 8884 | 3 | Hose Assy, ¼" × 106", 4G1-4FJX-4FJX-106 |
| 10 | 91256 | 3 | Hose Assy, ¼"×42", 4G1-4FJX-4FJX90S |
| Lift | | | |
| 11 | REF | – | See appropriate Lift Cylinder art for Hose number |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





mecc
ILLUSTRATION No.
ART_2113 R1

2591RT - 3391RT - 4191RT Hydraulic Hose Routing – Brakes – Oscillating Axle – Pump and Tank Return

Hydraulic Hoses – Brake and Oscillating Axle – Pump and Tank Return

| ITEM | PART NO. | QTY | DESCRIPTION |
|-----------------------------------|----------|------|--|
| Brake and Oscillating Axle | | | |
| 1 | HDW9557 | 4 | TEE, M ¼ JIC m ¼ JIC |
| 2 | 91256 | 3 | Hose Assy, ¼"×42", 4G1-4FJX-4FJX90S |
| 3 | 9227 | 4 | Hose Assy, ¼"×83", 4G1-4FJX-4FJX90S |
| Pump and Tank Return | | | |
| 4 | 9847 | 2 | Hose Assy, ¼" × 76", 4G1-4FJX-4FJX |
| 5 | HDW91246 | 2 | Fitting Female ¾" JIC Male ¾" Hose Barb |
| 6 | 91247 | 8 FT | Hose Assy, ¾", 12LOLA bulk |
| 7 | 91423 | 1 | Hose Assy, ¾" × 82", 12M3K-12FJX-12FJX45 |
| 8 | 91265 | 1 | Hose Assy, 1" × 22", 16GMV-16FJX-16FJX-22" |
| 9 | 90276 | 1 | Hose Assy, ¼"×24", 4G1-4FJX-6FJX-24 |
| 10 | 91161 | 1 | Flange Kit #16 |
| 11 | 91162 | 1 | Flange Kit #12 |
| 12 | 91163 | 1 | Adapter ¾" Flange, Male ¾" JIC 90° |
| 13 | HDW91176 | 1 | Adapter 1" Flange, Male 1" JIC |
| 14 | HDW8877 | 2 | Elbow, 90°, Male ¼" O-Ring, Male ¼" JIC |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Hydraulic Hoses – Steering –Wheek Motor Case Drain

| ITEM | PART NO. | QTY | DESCRIPTION |
|-------------------------------|----------|-------|---|
| Steering | | | |
| 1 | 8884 | 3 | Hose Assy, 1/4" x 106", 4G1-4FJX-4FJX-106 |
| 2 | 9755 | 1 | Hose Assy, 1/4" x 84", 4G1-4FJX-4FJX-84 |
| 3 | 91421 | 2 | Hose Assy, 1/4" x 25", 4G1-4FJX90S-4FJX90S-25 |
| Wheel Motor Case Drain | | | |
| 4 | HDW7391 | 2 | TEE, male 3/8 JIC |
| 5 | HDW91436 | 12 | Adapter, Female 3/8 JIC x Male 3/8 Hose Barb |
| 6 | 91435 | 41 FT | Hose, Case Drain 3/8" |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Hydraulic Hoses – Outrigger Option

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | HDW9557 | 4 | Tee, Male 1/4" JIC |
| 2 | HDW7391 | 2 | Tee, Male 3/8" jic |
| 3 | 91422 | 4 | Hose Assy, 1/4"x74", 4G1-4FJX-6FJX |
| 4 | 91459 | 4 | Hose Assy, 1/4"x44", 4G1-4FJX-4FJX90 S |
| 5 | 90281 | 4 | Hose Assy, 1/4"x73", 4G1-4FJX-4FJX90 S |
| 6 | 91424 | 1 | Hose Assy, 1/4"x26", 4G1-4FJX-4FJX |
| 7 | 9038 | 2 | Hose Assy, 3/8"x46", 6M3K-6FJX-6FJX |
| 8 | 8318 | 2 | Hose Assy 3/8"x24", 6M3K-6FJX-6FJX90 |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Hydraulic Hoses – Generator Option

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---|
| 1 | 91346 | 1 | Hose Assy, 1/4" x 35", 4GI-4FJX-4FJX90S |
| 2 | 90315 | 1 | Hose Assy, 1/2" x 21", 8M3K-8FJX-8FJX90S |
| 3 | 91259 | 1 | Hose Assy, 1/2" x 84", 8M3K-8FJX-8FJX45 |
| 4 | HDW91467 | 1 | Adapter, TEE, 3/4" W/Swivel Female |
| 5 | HDW91466 | 1 | Adapter, TEE, 3/4" Male O-ring, 3/4" Male JIC |
| 6 | HDW8877 | 1 | Adapter, Male 1/4" O-ring, Male 1/4" JIC 90° |
| 7 | HDW90764 | 1 | Adapter, Male 1/2" O-ring, Male 1/2" JIC 90° |
| 8 | HDW90967 | 1 | Adapter, Male 5/8" O-ring, Male 1/4" JIC 90° |
| 9 | HDW91468 | 2 | Adapter, FEMale 3/4" JIC, Male 1/2" JIC |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only



14 Seal Kit





ILLUSTRATION No.
ART_2790

2591RT - 3391RT CE

91403 Lift Cylinder

Cylinder, Lift – 2591RT and 3391RT

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-------|---------------------------------------|
| 1 | 91403 | 1 | Cylinder, Lift |
| 2 | 91437 | 1 | Hose Assembly, 3/8"× 320" |
| 3 | HDW7601 | 1 | Fitting, Elbow Adaptor |
| 4 | 91732 | 1 | Orifice |
| 5 | 6669 | 4 | Bearing |
| 6 | 91051 | 1 | Valve, 2 Way, N.C. Cable Attach |
| 7 | 91141 | 1 | Coil, 12 Volt, Deutsch |
| 8 | HDW6727 | 1 | Fitting, Pipe 90°, Male Barb |
| 9 | 6458 | 21 FT | Hose, Return Line |
| 10 | 7788 | 1 | Clamp, Hose |
| 11 | 91442 | 1 | Cable, E-Down |
| 12 | HDW91240 | 1 | Nut, Coupling 10-32 × 3/4" |
| 13 | 90845 | 1 | Pressure Sensor |
| 14 | 91461 | – | Kit, Seal-Lift Cylinder (service) |
| REF | 91448 | 1 | Harness, Wire Down, Valve (Not Shown) |

• as req: as required



• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only




17 Seal Kit



To Hydraulic Manifold
Lift Port

To Upper Lift Cylinder

To Hydraulic Reservoir

 ILLUSTRATION No.
ART_2789 4191RT CE

91404 Lower Lift Cylinder

Cylinder, Lift – 4191RT (Lower)

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-------|---|
| 1 | 91404 | 1 | Cylinder, Lower lift |
| 2 | 91437 | 1 | Hose Assembly, Lift Cylinder 3/8"×320" |
| 3 | HDW7601 | 1 | Fitting, Elbow 90° Adaptor |
| 4 | 91732 | 1 | Orifice |
| 5 | 6669 | 4 | Bearing, 2" ID × 2" LG |
| 6 | 91462 | 1 | Valve, 2 Way, N.C. Poppet Dual Coil |
| 7 | 91438 | 1 | Hose Assembly, 3/8"×352" |
| 8 | HDW6727 | 1 | Fitting, Pipe 90°, Male Barb |
| 9 | HDW8699 | 1 | Fitting, TEE 3/8" JIC |
| 10 | 6458 | 21 FT | Hose, Return Line |
| 11 | 7788 | 1 | Clamp, Hose |
| 12 | 90969 | 1 | Relief Valve |
| 13 | 91141 | 2 | Coil, 12 Volt, Deutsch Connector W/diode |
| 14 | HDW90943 | 1 | Fitting, TEE Adaptor |
| 15 | HDW90945 | 2 | Fitting, Female Swivel |
| 16 | 90845 | 1 | Pressure Sensor |
| 17 | 91449 | – | Kit, Seal-lift Cylinder - Lower (Service) |
| REF | 91440 | 1 | Harness, Wire Down, Valve (Not Shown) |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Cylinder, Lift – 4191RT (Upper)

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-------|--|
| 1 | 91405 | 1 | Cylinder, Upper Lift |
| 2 | 91438 | 1 | Hose Assembly, Lift Cylinder 3/8" x 352" |
| 3 | HDW7601 | 1 | Fitting, Elbow Adaptor |
| 4 | 91733 | 1 | Orifice |
| 5 | 6669 | 4 | Bearing, 2" ID x 2" LG |
| 6 | 91462 | 1 | Valve, 2 Way, N.C. Dual Coil |
| 7 | HDW6727 | 1 | Fitting, Pipe 90°, Male Barb |
| 8 | 6458 | 40 FT | Hose, 5/16", Return Line |
| 9 | 7788 | 1 | Clamp, Hose |
| 10 | 90969 | 1 | Relief Valve |
| 11 | 91141 | 2 | Coil, 12 Volt, Deutsch Connector W/diode |
| 12 | 91450 | – | Kit, Seal-lift Cylinder (Service) |
| REF | 91441 | 1 | Harness, Wire Down, Valve (Not Shown) |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2120 R1

2591RT - 3391RT - 4191RT

91019 Steering Cylinder

Cylinder, Steering

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---|
| | 91019 | 2 | Steering Cylinder |
| 1 | HDW8881 | 1 | Adapter Male 1/4" O-Ring-Male 1/4" JIC |
| 2 | HDW8876 | 1 | Adapter Male 1/4 O-Ring-Male 1/4" JIC TEE |
| 3 | HDW5925 | 1 | Jamnut 5/8-18 |
| 4 | 7293 | 1 | Rod End |
| 5 | 90990 | - | Seal Kit (Service) |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only



8 Seal Kit





ILLUSTRATION No.
ART_2121 R1

2591RT - 3391RT - 4191RT

91406 Axle Lock Cylinder

Cylinder, Floating Axle Lock

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|------------------------|
| 1 | 91406 | 2 | Axle Lock Cylinder |
| 2 | 91499 | 1 | Valve, Poppet |
| 3 | 91142 | 1 | Coil, 12V |
| 4 | HDW8877 | 1 | Fitting, Elbow Adaptor |
| 5 | 91498 | 3 | Bearing, 5/8 x 1 |
| 6 | 91497 | 1 | Bleeder Fitting |
| 7 | 91105 | 1 | Grease Fitting |
| 8 | 91496 | – | Seal Kit (Service) |



• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





Cylinder, Outrigger (option)

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---------------------------------------|
| 1 | 91443 | 4 | Cylinder, Outrigger |
| 2 | 91281 | 1 | Switch, Outrigger Pressure N.O. |
| 3 | 10907 | 1 | Washer Actuator |
| 4 | HDW8476 | 1 | Nut Jam 1/4-20 |
| 5 | HDW9761 | 1 | Screw, Socket Head 1/4-20 x 2 1/2 |
| 6 | 91277 | 1 | Switch, Outrigger Retract Limit N.O. |
| 7 | 91464 | 2 | Valve N.C. Poppet |
| 8 | 91141 | 2 | Coil 12V Deutsch |
| 9 | HDW91465 | 2 | Adapter 3/8 Male O-Ring, 1/4 Male JIC |
| 10 | 90439 | 1 | Orifice |
| 11 | 91451 | - | Seal Kit |

• as req: as required

• INCL: Included with assembly


• NS: Not a Stock item

• REF: Reference only



NOTES:





SECTION F

BASE

| CONTENTS | PAGE |
|---------------------------------------|------|
| Base Assembly | F-3 |
| Control Module | F-5 |
| Power Module | F-7 |
| Power Module: Engine Mount | F-9 |
| Diesel Engine | F-11 |
| Outrigger Installation (option) | F-13 |
| Generator (option) | F-15 |
| Wire Harness | F-17 |






ILLUSTRATION No.
ART_2123-R1

2591RT | 3391RT | 4191RT

Base Assembly

Base Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|---------------------------------|
| 1 | 16410 | 1 | Base Weldment |
| 2 | 16455 | 1 | Ladder Weldment, 2591RT |
| | 16454 | 1 | Ladder Weldment, 3391RT |
| | 16453 | 1 | Ladder Weldment, 4191RT |
| 3 | HDW6211 | 8 | Screw, ½-13, 1 ¼" LG, GR5 |
| 4 | HDW8498 | 4 | Screw, ¼-13, 4" LG GR5 |
| 5 | 16153 | 1 | Module Weldment, Control Module |
| 6 | 16480 | 1 | Cover, Hose Tray |
| 7 | 16213 | 1 | Module Weldment, Power Module |
| 8 | 16156 | 1 | Door Weldment, Control Module |
| 9 | 16220 | 1 | Door Weldment, Power Module |
| 10 | 8386 | 4 | Catch Trigger |
| 11 | HDW8457 | 12 | Nut, ½" - 13, GR 5 |
| 12 | HDW5723 | 6 | Screw, ¼-20 × ¾" |
| 13 | 16834 | 1 | Bracket, Power to Platform |
| 14 | 90749 | 1 | Receptical, Power to Platform |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only








 ILLUSTRATION No.

 ART_2134

2591RT - 3391RT - 4191RT CE Models

Control Module

Control Module

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-------|--|
| 1 | 16153 | 1 | Control Module Weldment |
| 2 | 14896 | 4 | Block, Slide, Door |
| 3 | HDW8273 | 4 | Screw, ¼-20, 1" LG |
| 4 | HDW5217 | 4 | Washer, .343 ID × .680 OD × .063 THK |
| 5 | HDW8267 | 18 | Nut, ¼-20, GR 5 |
| 6 | 16154 | 1 | Bracket, Cross Support |
| 7 | HDW5724 | 4 | Screw, 5/16-18, ¾" LG, GR 5 |
| 8 | 25429 | 2 | Pad |
| 9 | 91140 | 1 | Hydraulic Manifold |
| 10 | HDW6433 | 4 | Screw, 3/8 × 1" |
| 11 | HDW7783 | 4 | Lock Washer, 3/8 |
| 12 | 16225 | 1 | Bracket, Fuel Tank |
| 13 | HDW5723 | 18 | Screw, ¼-20 × ¾" |
| 14 | 16152 | 1 | Bulkhead |
| 15 | HDW8268 | 5 | Nut, 3/8 |
| 16 | 91023 | 1 | Fuel Tank, Plastic |
| 17 | 91091 | 1 | Fuel Tank Cap |
| | 6919 | 1 | Fuel Shutoff (not shown) |
| | HDW91279 | 1 | Adapter, Male 1/8 Npt, 5/16 Hose Barb (not shown) |
| | 7788 | 1 | Clamp (not shown) |
| | 6458 | 72 FT | Hose, Fuel Line (not shown) |
| | HDW91320 | 1 | Adapter (not shown) |
| 18 | 16226 | 2 | Bracket, Control Box |
| 19 | HDW7888 | 4 | Screw, 10-32 × ½" |
| 20 | 91169 | 1 | Lower Control Box |
| 21 | 91375 | 1 | Relay, Speed/torque, Drive |
| 22 | 16229 | 1 | Battery Disconnect Bracket |
| 23 | 8841 | 1 | Battery Disconnect |
| 24 | 6854 | 1 | Battery, 12vdc |
| 25 | 2987 | 1 | Hold Down Rod |
| 26 | HDW6110 | 2 | Wing Nut |
| 27 | 3436 | 1 | Hold Down Bar |
| 28 | 91280 | 1 | Control Module – <i>Outrigger Option</i> |
| 29 | HDW90880 | 8 | Screw, 10-32 × 1" – <i>Outrigger Option</i> |
| 30 | HDW90803 | 8 | Nut, 10-32 Nylock – <i>Outrigger Option</i> |
| 31 | 91375 | 1 | Relay – <i>Outrigger Option</i> |
| 32 | 91268 | 1 | Outrigger Manifold – <i>Outrigger Option</i> |
| 33 | HDW91332 | 2 | Screw, 5/16-18 × 3½" – <i>Outrigger Option</i> |
| 34 | HDW8304 | 2 | Nut, 5/15-18 – <i>Outrigger Option</i> |
| 35 | 16620 | 1 | Battery Shelf – <i>Emergency Lowering: 4191RT</i> |
| 36 | 16619 | 1 | Battery Bracket – <i>Emergency Lowering: 4191RT</i> |
| 37 | 90898 | 1 | Battery, 12vdc – <i>Emergency Lowering: 4191RT</i> |
| 38 | 25480 | 1 | Bracket, Emergency Down Switch – <i>Emergency Lowering: 4191RT</i> |
| 39 | HDW90833 | 2 | Screw, 6-32 × ¾" Lg – <i>Emergency Lowering</i> |
| 40 | HDW5364 | 2 | Nut, 6-32 – <i>Emergency Lowering</i> |
| 41 | 7423 | 1 | Switch, Toggle, 1 Pole 2 Pos – <i>Emergency Lowering</i> |
| 42 | 90843 | 1 | Load Sense Module – <i>Overload Alarm</i> |
| 43 | 9716 | 1 | Alarm – <i>Overload Alarm</i> |
| 44 | 91375 | 1 | Relay – <i>Overload Alarm</i> |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2125 R1

2591RT - 3391RT - 4191RT

Power Module

Power Module

| ITEM | PART NO. | QTY | DESCRIPTION |
|------------------------------------|----------|-----|--------------------------------------|
| 1 | 16213 | REF | Weldment, Power Module |
| 2 | 16247 | 1 | Guard, Engine Module |
| 3 | 25429 | 2 | Pad |
| 4 | 40620 | 2 | Spacer, Insulator, 1.59" LG |
| 5 | 14896 | 4 | Block, Slide, Door |
| 6 | 14826 | 1 | Bracket, Cross Support |
| 7 | HDW8273 | 4 | Screw, ¼-20, 1" LG |
| 8 | HDW5217 | 4 | Washer, .343 id × .680 od × .063 thk |
| 9 | HDW8267 | 4 | Nut, ¼-20, GR 5 |
| 10 | HDW5724 | 4 | Screw, 5/16-18, ¾" LG, GR 5 |
| Hydraulic tank Installation | | | |
| 11 | 9370 | 1 | Level Gauge |
| 12 | HDW9200 | 1 | Plug, ¼ NPT |
| 13 | HDW6727 | 1 | Elbow, 90° ¼ NPT – 5/16 Barb |
| 14 | HDW7500 | 3 | Elbow, 90° ¼ NPT – 3/8 JIC |
| 15 | 91164 | 1 | Elbow, 90° 1 1/8 NPT – 1 JIC |
| 16 | 91417 | 1 | Filter Assembly |
| INCL | 91418 | 1 | Filter Cartridge |
| INCL | 91570 | 1 | Filter Pressure Gauge |
| 17 | HDW9268 | 1 | Elbow, 90° ¾ NPT – ¾ JIC |
| 18 | HDW9268 | 6 | Bolt, 32 × 1.57 |
| 19 | 9367 | 1 | Filler/Strainer |
| 20 | 6655 | 1 | TEE, ¼ NPT |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






ILLUSTRATION No.
ART_2127 R1

2591RT - 3391RT - 4191RT

Diesel Engine Mount

Power Module: Engine Mount

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|------|--------------------------|
| 1 | REF | – | Power Module |
| 2 | 16209 | 2 | Engine Mount, Diesel |
| 3 | 16210 | 3 | Spacer |
| 4 | 16207 | 1 | Bracket, Solenoid Mount |
| 5 | 16345 | 2 | Radiator Mount Bracket |
| 6 | HDW6432 | 5 | Screw, 3/8 - 18 × ¾ |
| 7 | 91127 | 1 | Coolant Overflow Tank |
| 8 | HDW5723 | 4 | Screw, ¼-20 × ¾ |
| 9 | HDW8267 | 2 | Nut, ¼-20 |
| 10 | 6458 | 3 FT | Hose |
| 11 | 16295 | 1 | Air Intake Weldment |
| 12 | 7736 | 8 | Insulator Rubber |
| 13 | 40620 | 4 | Spacer Isolator |
| 14 | HDW8567 | 4 | Washer, 3/8 Flat |
| 15 | HDW8279 | 4 | Screw, 3/8-16 × 2 ½ gr8 |
| 16 | HDW8268 | 9 | Nut, 3/8-16 |
| 17 | HDW91234 | 12 | Screw, M10-1.25 × 25 8.8 |
| 18 | 91591 | 1 | Vibration Isolator |
| 19 | 16346 | 1 | Radiator Brace |
| 20 | 945407 | 1 | Nut, M6 × 1 |
| 21 | REF | – | Radiator Kit, See Engine |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only







 ILLUSTRATION No. 2591RT - 3391RT - 4191RT
 ART_2130-R1

Diesel Engine, Kubota D1105

Diesel Engine

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|----------------------------|
| | 84036 | | Engine Subassembly, Diesel |
| 1 | 91429 | | Engine Kit, D1105 |
| 2 | 91113 | | Radiator Kit |
| INCL | 9831 | | Radiator |
| 3 | 91111 | | Air Cleaner kit |
| INCL | 8667 | | Air Filter Element |
| 4 | 91115 | | Muffler Kit |
| INCL | 9830 | | Muffler |
| 5 | 91118 | | Exhaust Pipe |
| 6 | 9696 | | Muffler Hanger |
| 7 | 9868 | | Muffler Clamp |
| 8 | 40620 | | Spacer |
| 9 | HDW8279 | | Screw, 3/8-16 × 2 1/2" |
| 10 | HDW8268 | | Nut, 3/8-16 |
| 11 | 91175 | | Oil Pressure Switch |
| 12 | HDW91187 | | Fitting, 1/8 NPT, m-F |
| 13 | 91116 | | Fuel Filter Assembly |
| INCL | 91123 | | Fuel Filter Element |
| 14 | 6458 | | Hose, Fuel, 5/16 |
| 15 | 91199 | | Hose, Fuel, 3/16 |
| 16 | 91114 | | Valve, Check |
| 17 | 7788 | | Hose Clamp |
| 18 | 91589 | | Solenoid, Throttle |
| 19 | 16207 | | Bracket, Solenoid |
| 20 | 16347 | 2 | Throttle Link |
| 21 | 91117 | | Yoke |
| 22 | HDW91231 | | Jamnut, 1/4-28 |
| 23 | HDW5723 | | Screw, 1/4-20 × 3/4" |
| 24 | HDW8267 | | Nut, 1/4-20 |
| 25 | 91112 | | KTR housing Kit, D905 |
| 26 | 91375 | 2 | Relay |
| 27 | 7545 | 2 | Hose Clamp |
| 28 | 91340 | 1 | Hose, 2.00" I.D. Flex |
| 29 | 91130 | 1 | Hub |
| 30 | 91160 | 1 | Hydraulic Pump |
| 31 | HDW6433 | 2 | Screw, 3/8-16 × 1" |
| 32 | 91765 | 1 | Ring Gear |
| 33 | 91766 | 1 | Flywheel |
| 34 | 8665 | - | Oil Filter |
| 35 | 8413 | - | Starter |
| 36 | 8001 | - | Fuel Solenoid |
| 37 | 90227 | - | Alternator |
| 38 | 9832 | - | Glow Plugs |
| 39 | 91588 | 1 | Washer, 1/4" Rubber |
| 40 | HDW5217 | 1 | Washer, Flat, 5/16" |
| 41 | HDW91590 | 1 | Clevis Pin, 5/16 × 1" |
| 42 | HDW5290 | 1 | Cotter Pin, 1/8" × 1" |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only







 ILLUSTRATION No.
 ART_2131 R1

2591RT - 3391RT - 4191RT

Outrigger Installation

Outrigger Installation (option)

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|----------------------------------|
| 1 | 16490 | 1 | Weldment, Outrigger Mount, Rear |
| 2 | HDW91457 | 8 | Screw, 3/4-10 x 10" LG |
| 3 | HDW91458 | 8 | Locknut, 3/4-10 |
| 4 | 16451 | 4 | Weldment, Outer Outrigger |
| 5 | HDW7052 | 8 | Screw, 1/2-13 x 3 1/2" LG |
| 6 | HDW8457 | 16 | Nut, 1/2-13 |
| 7 | 16491 | 1 | Weldment, Outrigger Mount, Front |
| 8 | 21170 | 4 | Cover, Outrigger Cylinder |
| 9 | HDW6455 | 20 | Screw, 1/4-20 x 1/2" |
| 10 | HDW91328 | 4 | Shoulder Screw, 5/8 x 4.75" |
| 11 | 91443 | 4 | Cylinder, Outrigger |
| 12 | 90663 | 64 | Spacer |
| 13 | 16448 | 4 | Tube, Inner Outrigger |
| 14 | HDW5916 | 4 | Screw, 1/2-13 x 4.0" |
| 15 | 20998 | 4 | Bracket Pivot |
| 16 | HDW91395 | 4 | Clevis Pin, 5/8 x 5.0" |
| 17 | HDW9219 | 4 | Washer, Flat |
| 18 | HDW5920 | 4 | Pin, Cotter, 1/8 x 1" |
| 19 | 21002 | 4 | Pad Weldment |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





MEC
ILLUSTRATION No.
ART_2136R1

2591RT - 3391RT - 4191RT

Generator Option

Generator (option)

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|------|--|
| 1 | 91550 | 1 | Generator, 2000 Watt |
| 2 | 5630 | 1 | Switch, Toggle |
| 3 | 91551 | 1 | Valve, Solenoid, 2-way, n.c. |
| 4 | 91002 | 1 | coil, 12V 10 Series |
| 5 | 91546 | 1 | Needle Valve |
| 6 | 91375 | 1 | Relay, SPDT |
| 7 | 91544 | 1 | Plug, Male, 3 Prong |
| 8 | 91545 | 2 | Receptacle, Female |
| 9 | 7594 | 1 | Strain Relief |
| 10 | INCL | 1 | Locknut, ½" NPT |
| 11 | 7617 | 6 FT | Wire, 14GA, 3 conductor |
| 12 | 91556 | 1 | Label, AC Generator |
| 13 | 91119 | 1 | Solenoid, Generator-Throttle, Diesel Engine |
| 14 | 91469 | 2 FT | Chain, Sash #8 |
| 15 | 91543 | 1 | Harness, Engine Intermediate, Generator Option |
| 16 | 16369 | 1 | Bracket, Generator Mount |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only



NOTES:



Wire Harness

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| - | 91430 | - | Harness, Main [Control Module - Base & Valves] |
| - | 91185 | - | Control Cable, 2591RT [Control Module to Deck through scissor beams] |
| - | 91321 | - | Control Cable, 3391RT [Control Module to Deck through scissor beams] |
| - | 91439 | - | Control Cable, 4191RT [Control Module to Deck through scissor beams] |
| - | 91184 | - | Harness, Control Box (upper) [Inside Upper Control Box] |
| - | 91294 | - | Cable, Outtrigger Option, Upper Controls [Inside Upper Control Box] |
| - | 91295 | - | Cable, Outtrigger Option, Control, Platform [Deck to Upper Control Box] |
| - | 91296 | - | Cable, Outtrigger Option, Control, 2591RT [Control Module to Deck through scissor beams] |
| - | 91121 | - | Cable, Outtrigger Option, Control, 3391RT [Control Module to Deck through scissor beams] |
| - | 91447 | - | Cable, Outtrigger Option, Control, 4191RT [Control Module to Deck through scissor beams] |
| - | 91444 | - | Harness, Outtrigger Option [Control Module to Outriggers] |
| - | 91448 | - | Harness, Lift Cylinder Down Valve, 2591RT, 3391RT [Control Module to Lift Cylinder] |
| - | 91440 | - | Harness, Lower Lift Cylinder Down Valve, 4191RT [Control Module To Lift Cylinder] |
| - | 91441 | - | Harness, Upper Lift Cylinder Down Valve , 4191RT [Control Module to Lift Cylinder] |
| - | 91379 | - | Harness, E-Down with Diode, 4191RT |
| - | 91378 | - | Harness, E-Down to Batteries, 4191RT |
| - | 91171 | - | Harness, Engine, Intermediate [Control Module to Engine Module] |
| - | 91543 | - | Harness, Engine Intermediate, Generator Option [Control Module to Engine Module] |
| - | 91172 | - | Harness, Engine, Dual Fuel [Engine Module] |
| - | 91173 | - | Harness, Engine, Diesel [Engine Module] |
| - | 91189 | - | Cable, Upper Controls, Removable |
| - | 91557 | - | Cable, Upper Controls, Fixed |
| - | 91595 | - | Harness, Lower Controls [Inside Lower Control Box] |
| - | 9438 | - | Battery Cable, Red, 15 Inch Long [Control Module: Battery to Battery Disconnect Switch] |
| - | 9012 | - | Battery Cable, Red, 72 Inch Long [Control Module to Engine Module] |
| - | 9013 | - | Battery Cable, Black, 72 Inch Long [Control Module to Engine Module] |
| - | 7172 | - | Boot, Black [Control Module: Battery Terminal] |
| - | 7173 | - | Boot, Red [Control Module: Battery Terminal] |
| - | | - | |

• as req: as required

• INCL: Included with assembly


• NS: Not a Stock item

• REF: Reference only



NOTES:






SECTION G

DECALS

| CONTENTS | PAGE |
|--------------------------------|------|
| Decals, Controls | G-3 |
| Decals, Base | G-5 |
| Decals, Scissor Assembly | G-7 |
| Decals, Platform | G-9 |
| Decals, Options | G-11 |




90729




1

91728




2

91730 (OPTION)




3



4

91729



91109

| DIAGNOSTICS LED'S LED INDICATES FUNCTION ENABLED | |
|---|--------------|
| ○ STEER RIGHT | ○ TILT ALARM |
| ○ SPEED TURNDOWN | ○ TILT POINT |
| ○ STEER LEFT | ○ LIFT POINT |
| ○ TILT UP | ○ FORWARD |
| ○ SHOCK / LOW PLATES | ○ REVERSE |
| | ○ TILT/TILT |



ILLUSTRATION No.
ART_2138

2591RT - 3391RT - 4191RT: CE Models

Decals, Controls

Decals, Controls

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 90729 | 1 | Decal, Upper Control, Joystick Operation |
| 2 | 91728 | 1 | Decal, Upper Control Panel |
| 3 | 91730 | 1 | Decal, Outrigger Panel |
| 4 | 91729 | 1 | Decal, Lower Control Panel |
| 5 | 91109 | 1 | Decal, Diagnostic LEDs |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only








ILLUSTRATION No. ART_2141 2591RT - 3391RT - 4191RT: CE Models Decals: Base Assembly

Decals, Base

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--|
| 1 | 9378 | 1 | Decal, Diesel Only |
| 2 | 90751 | 1 | Decal, Power To Platform |
| 3 | 8519 | 4 | Decal, Warning: Tire Replacement |
| 4 | 90732 | 1 | Decal, Warning: Steam Cleaning |
| 5 | 9052 | 1 | Decal, Battery Disconnect |
| 6 | 90918EUR | 2 | Decal, Emergency Lowering, 4191RT Only |
| 7 | 91776 | 1 | Serial Plate |
| 8 | 91781 | 4 | Decal, Max Wheel Load, 2591RT |
| 9 | 91782 | 4 | Decal, Max Wheel Load, 3391RT |
| 10 | 91783 | 4 | Decal, Max Wheel Load, 4191RT |
| 11 | 91266 | 1 | Decal, Quad-Trax 4WD |
| 12 | 91388 | 1 | Decal, 86 dB |
| 13 | 91094 | 1 | Decal, Emergency Lowering, 2591RT and 3391RT |
| 14 | 6973 | 1 | Decal, Hydraulic Oil |


• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






**2591RT
Scissors**

Maintenance Lock
Stowed

2



9910




**3391RT
Scissors**

90717EUR


⚠ MAINTENANCE LOCK
ENSURE LOCK IS IN PLACE
BEFORE DOING MAINTENANCE
ON ELEVATED WORK PLATFORM

90717EUR

1



Maintenance Lock



**4191RT
Scissors**

Maintenance Lock
Engaged

Rear

Power Side

Control Side

Rear

2

mecc
ILLUSTRATION No.
ART_2144

2591RT - 3391RT - 4191RT: CE Models

Decals: Scissor Assembly

Decals, Scissor Assembly

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|--------------------------|
| 1 | 90717EUR | 1 | Decal, Maintenance Lock |
| 2 | 9910 | 4 | Decal, Hand Crush Hazard |




• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only





1

91456

WARNING

INSPECT MACHINE AND MAKE SURE THAT IT IS OPERATING PROPERLY, THAT ALL NAME PLATE AND SAFETY AND CONTROL DEVICES ARE IN PLACE AND LEGIBLE, AND THAT THE MACHINE IS IN ACCORDANCE WITH THE MANUFACTURER'S MAINTENANCE REQUIREMENTS CONTAINED IN THE OPERATION AND MAINTENANCE MANUAL AND THE DAILY SAFETY CHECKLIST. OPERATE MACHINE WITH EXTREME CAUTION, WATCH FOR OBSTRUCTIONS WHICH MAY STRIKE PLATFORM, PERSONNEL, CONTROLS, OR MACHINE. OPERATE CONTROLS SLOWLY FOR SMOOTH PLATFORM MOTION.

FOR DRIVING ON ANY GRADE OR SIDE SLOPE:

- MACHINES MUST BE FULLY CHARGED.
- DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY. EXCESSIVE LOADS MAY CAUSE DAMAGE TO THE MACHINE AND LEAD TO DEATH OR SERIOUS INJURY.
- DO NOT DRIVE ON SIDE SLOPE OR GRADE OVER 10%.
- DO NOT DRIVE UP OR DOWN A GRADE THAT IS GREATER THAN 10% WITHOUT THE USE OF THE OPERATION MANUAL FOR THE PLATFORM.

FOR DRIVING WITH PLATFORM ELEVATED:

- DRIVE ONLY ON A SMOOTH, FIRM, AND LEVEL SURFACE FREE OF OBSTRUCTIONS.
- DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- LOADS MUST BE UNIFORMLY DISTRIBUTED.
- USE EXTREME CAUTION.

OTHER HAZARDS:

- 1. DO NOT OVERLOAD THE PLATFORM. LOAD CAPACITY IS LIMITED BY THE WEIGHT OF THE PLATFORM, THE WEIGHT OF THE LOADS, AND THE WEIGHT OF THE OPERATOR.
- 2. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY. EXCESSIVE LOADS MAY CAUSE DAMAGE TO THE MACHINE AND LEAD TO DEATH OR SERIOUS INJURY.
- 3. DO NOT DRIVE ON SIDE SLOPE OR GRADE OVER 10%.
- 4. DO NOT DRIVE UP OR DOWN A GRADE THAT IS GREATER THAN 10% WITHOUT THE USE OF THE OPERATION MANUAL FOR THE PLATFORM.
- 5. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 6. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 7. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 8. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 9. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 10. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 11. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 12. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 13. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- 14. DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.

IMPROPER OPERATION OF THIS MACHINE COULD CAUSE DEATH OR SERIOUS INJURY.

2

90721

DANGER

YOU MUST NOT OPERATE THIS MACHINE UNLESS YOU HAVE BEEN TRAINED BY THE SAFE OPERATOR OF THIS MACHINE. TRAINING INCLUDES COMPLETE KNOWLEDGE OF THE SAFETY AND OPERATING INSTRUCTIONS CONTAINED IN THE OPERATION AND MAINTENANCE MANUAL, YOUR EMPLOYER'S WORK RULES AND APPLICABLE GOVERNMENTAL REGULATIONS. AN UNTRAINED OPERATOR SUBJECTS HIMSELF AND OTHERS TO SERIOUS INJURY OR DEATH.

TIP-OVER HAZARDS:


- DO NOT DRIVE NEAR OBSTRUCTIONS. OPEN ELEVATOR SHIELDS, AND LOADING DOCKS.
- DO NOT EXCEED MAXIMUM PLATFORM OR EXTENSION LOAD CAPACITY.
- DO NOT DRIVE ON SIDE SLOPE OR GRADE OVER 10%.
- DO NOT DRIVE UP OR DOWN A GRADE THAT IS GREATER THAN 10% WITHOUT THE USE OF THE OPERATION MANUAL FOR THE PLATFORM.

ELECTROCUTION HAZARD:

NEVER TAKE CLEARANCE FROM ELECTRICAL LINES AND APPARATUS. YOU MUST ALLOW FOR ADDITIONAL ROOM FOR SAFE ELECTRICAL CLEARANCE. THIS MACHINE DOES NOT PROVIDE PROTECTION FROM CONTACT WITH OR PROXIMITY TO AN ELECTRICALLY CHARGED CONDUCTOR. YOU MUST MAINTAIN A CLEARANCE OF AT LEAST 10 FEET BETWEEN ANY PART OF THE MACHINE OR THE PLATFORM AND ANY ELECTRICAL LINE OR APPARATUS. CLEARANCE IS PROVIDED FOR EVERY ELECTRICAL SOURCE YOU ENCOUNTER.

DEATH OR SERIOUS INJURY WILL RESULT FROM CONTACT OR INADEQUATE CLEARANCE.

DEATH OR SERIOUS INJURY WILL RESULT FROM IMPROPER USE OF THIS EQUIPMENT.




3

90730

WARNING

- PLATFORM EXTENSION MUST BE LOCKED IN PLACE AT ALL TIMES.
- SHEET LOADING GATE MUST BE IN LOWERED LOCKED POSITION BEFORE OPERATING FROM PLATFORM.
- PLATFORM ENTRANCE MUST BE PROPERLY CLOSED AND ALL GUARDRAILS PROPERLY IN PLACE AND SECURED BEFORE OPERATING FROM PLATFORM.

FAILURE TO FOLLOW INSTRUCTIONS COULD CAUSE DEATH, PERSONAL INJURY AND PROPERTY DAMAGE.



- 10 **MEC 2591RT**
- 11 **MEC 3391RT**
- 12 **MEC 4191RT**





ILLUSTRATION No. ART_2147 2591RT - 3391RT - 4191RT: CE Models

Decals: Platform

Decals, Platform

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-------------------------------|
| 1 | 91456 | 1 | Decal, Warning Panel |
| 2 | 90721 | 1 | Decal, Danger Panel |
| 3 | 90730 | 1 | Decal, Warning, Sheet Loading |
| 4 | 8911 | 1 | Decal, Manual Case |
| 5 | 91786 | 2 | Decal, Wind Rating, 2591RT |
| 6 | 91785 | 2 | Decal, Wind Rating, 3391RT |
| 7 | 91784 | 2 | Decal, Wind Rating, 4191RT |
| 8 | 90739 | 1 | Decal, Made in USA |
| 9 | 7982 | 3 | Decal, Safety Stripe |
| 10 | 9373 | 2 | Decal, Model, 2591RT |
| 11 | 9372 | 2 | Decal, Model, 3391RT |
| 12 | 9371 | 2 | Decal, Model, 4191RT |
| 13 | 8402 | 2 | Decal, Rail Stripe |
| 14 | 90719 | 1 | Decal, MEC Oval |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only






2 8606

WARNING

- LANYARD ANCHORAGE POINTS ARE RECOMMENDED FOR WORK POSITIONING RESTRAINTS ONLY.

USE OF FALL ARREST SYSTEMS ATTACHED TO ANCHORAGE POINTS ON MOBILE EQUIPMENT MAY CAUSE MACHINE TO TIP, RESULTING IN SERIOUS INJURY OR DEATH.

8606



Decals, Options

| ITEM | PART NO. | QTY | DESCRIPTION |
|------|----------|-----|-------------------------|
| 1 | 8605 | 4 | Decal, Anchorage Point |
| 2 | 8606 | 1 | Decal, Warning, Lanyard |
| 3 | 9465 | 4 | Decal, Crush Hazard |

• as req: as required

• INCL: Included with assembly

• NS: Not a Stock item

• REF: Reference only



NOTES:



Part Number Index

| Part Number | Page | Part Number | Page |
|-------------|---------------|-------------|-------------------------|
| 1008348 | A-5 | 16470 | D-5 |
| 10423 | D-3 | 16471 | D-5 |
| 10424 | D-3 | 16478 | D-3 |
| 10907 | E-29 | 16479 | D-3 |
| 13230 | B-7 | 16480 | F-3 |
| 13272 | B-9 | 16482 | D-3 |
| 13402 | A-5 | 16484 | D-3 |
| 13403 | A-5 | 16485 | B-11 |
| 13502 | A-5 | 16490 | F-13 |
| 13638 | A-7 | 16491 | F-13 |
| 13647 | A-5, A-7 | 16619 | F-5 |
| 13737 | B-5 | 16620 | F-5 |
| 13865 | A-3 | 16816 | C-13 |
| 14062 | B-7 | 16817 | C-13 |
| 14152 | B-3 | 16818 | C-13 |
| 14301 | B-3 | 16819 | C-13 |
| 14313 | B-3 | 16820 | C-13 |
| 14415 | B-3 | 16834 | F-3 |
| 14583 | B-15 | 20141 | C-3, C-5, C-7 |
| 14826 | F-7 | 20142 | C-3, C-5, C-7 |
| 14896 | F-5, F-7 | 20223 | C-3, C-5, C-7 |
| 16152 | F-5 | 20224 | C-3, C-5, C-7 |
| 16153 | F-3, F-5 | 20235 | B-5 |
| 16154 | F-5 | 20365 | C-3, C-5, C-7 |
| 16156 | F-3 | 20413 | C-3, C-5, C-7 |
| 16207 | F-9, F-11 | 20429 | C-3, C-5, C-7 |
| 16209 | F-9 | 20552 | B-3 |
| 16210 | F-9 | 20778 | C-3, C-5, C-7 |
| 16213 | F-3, F-7 | 20838 | C-11 |
| 16220 | F-3 | 20839 | C-3, C-7 |
| 16221 | B-13 | 20913 | C-3, C-7 |
| 16225 | F-5 | 20924 | C-11 |
| 16226 | F-5 | 20932 | C-3, C-5, C-7 |
| 16229 | F-5 | 20933 | C-7 |
| 16242 | A-3 | 20935 | C-7 |
| 16247 | F-7 | 20937 | C-3, C-5, C-7 |
| 16295 | F-9 | 20938 | C-7 |
| 16312 | A-3 | 20939 | C-5, C-7 |
| 16345 | F-9 | 20948 | C-3 |
| 16346 | F-9 | 20957 | C-5 |
| 16347 | F-11 | 20998 | F-13 |
| 16369 | F-15 | 21002 | F-13 |
| 16407 | D-5 | 21133 | C-3, C-5, C-7 |
| 16408 | D-5 | 21170 | F-13 |
| 16410 | F-3 | 25429 | C-3, C-5, C-7, F-5, F-7 |
| 16425 | D-5 | 25480 | F-5 |
| 16429 | B-3 | 2987 | F-5 |
| 16433 | B-3 | 30814 | B-9 |
| 16434 | B-3 | 3436 | F-5 |
| 16435 | B-3 | 3763 | A-5 |
| 16436 | B-3 | 3764 | A-5 |
| 16437 | B-3 | 3765 | A-5 |
| 16448 | F-13 | 3766 | A-5 |
| 16451 | F-13 | 3772 | A-5 |
| 16453 | F-3 | 3782 | A-5 |
| 16454 | F-3 | 3923 | B-15 |
| 16455 | F-3 | 40003 | B-9 |
| 16460 | C-3, C-5, C-7 | 40006 | B-9 |
| 16467 | C-7 | 40014 | B-9 |
| 16468 | C-3 | 40015 | B-9 |
| 16469 | C-5 | 40017 | B-9 |



Part Number Index

| Part Number | Page |
|-------------|----------------------------------|
| 40620 | F-7, F-9, F-11 |
| 5351 | B-13 |
| 5364 | A-3 |
| 5381 | B-13 |
| 5630 | A-3, F-15 |
| 5736 | A-5 |
| 5863 | B-11 |
| 5882 | B-13 |
| 5918 | B-7 |
| 6234 | A-3 |
| 6350 | A-3 |
| 6458 | E-19, E-21, E-23, F-5, F-9, F-11 |
| 6655 | F-7 |
| 6669 | C-3, C-5, C-7, E-19, E-21, E-23 |
| 6670 | C-3, C-5, C-7 |
| 6688 | C-3, C-5, C-7 |
| 6701 | C-3, C-5, C-7 |
| 6823 | B-3, B-9 |
| 6854 | F-5 |
| 6905 | A-3 |
| 6917 | A-5 |
| 6919 | F-5 |
| 6947 | B-11 |
| 6964 | B-11 |
| 6973 | G-5 |
| 6984 | D-3 |
| 7048 | B-3 |
| 7055 | B-9 |
| 7172 | F-17 |
| 7173 | F-17 |
| 7184 | B-5 |
| 7235 | A-9 |
| 7292 | D-5 |
| 7293 | E-25 |
| 7408 | B-5 |
| 7423 | A-3, F-5 |
| 7476 | A-7 |
| 7484 | E-3, E-5 |
| 7545 | F-11 |
| 7553 | A-3 |
| 7594 | C-11, F-15 |
| 7617 | F-15 |
| 7736 | F-9 |
| 7777 | A-7 |
| 7788 | E-19, E-21, E-23, F-5, F-11 |
| 7800 | A-3, A-9 |
| 7805 | B-3 |
| 7818 | A-5 |
| 7819 | A-5 |
| 7875 | A-5 |
| 7882 | A-5 |
| 7896 | D-5 |
| 7909 | A-9 |
| 7982 | G-9 |
| 8001 | F-11 |
| 8044 | A-3 |
| 8082 | A-3, A-9 |
| 8083 | A-3 |
| 8089 | A-7 |
| 8187 | B-9 |
| 8208 | B-13 |

| Part Number | Page |
|-------------|---------------|
| 8209 | B-13 |
| 8300 | B-9 |
| 8318 | E-15 |
| 8340 | C-3, C-5, C-7 |
| 8386 | F-3 |
| 8389 | A-5 |
| 8402 | G-9 |
| 84036 | F-11 |
| 8413 | F-11 |
| 8435 | A-5 |
| 8447 | A-7 |
| 8448 | A-7 |
| 8453 | A-7 |
| 8456 | A-7 |
| 8479 | B-13 |
| 8519 | G-5 |
| 8559 | B-13 |
| 8605 | B-15, G-11 |
| 8606 | B-15, G-11 |
| 8630 | A-7 |
| 8638 | A-3 |
| 8665 | F-11 |
| 8667 | F-11 |
| 8696 | A-5 |
| 8748 | A-7 |
| 8750 | A-7 |
| 8751 | A-7 |
| 8752 | A-7 |
| 8753 | A-7 |
| 8761 | A-7 |
| 8814 | B-5 |
| 8833 | B-13 |
| 8841 | F-5 |
| 8884 | E-9, E-13 |
| 8909 | B-3 |
| 8911 | G-9 |
| 9012 | F-17 |
| 9013 | F-17 |
| 90227 | F-11 |
| 90275 | E-9 |
| 90276 | E-11 |
| 90281 | E-15 |
| 90315 | E-17 |
| 9038 | E-15 |
| 90439 | E-29 |
| 9052 | G-5 |
| 90531 | D-3 |
| 90663 | F-13 |
| 90714 | A-9 |
| 90717EUR | G-7 |
| 90719 | G-9 |
| 90721 | G-9 |
| 90729 | G-3 |
| 90730 | G-9 |
| 90732 | G-5 |
| 90739 | G-9 |
| 90749 | F-3 |
| 90751 | G-5 |
| 90789 | A-3 |
| 90814 | A-3 |
| 90827 | B-13 |



Part Number Index

| Part Number | Page | Part Number | Page |
|-------------|-----------------------------|-------------|----------------------|
| 90828 | B-13 | 91184 | A-3, F-17 |
| 90833 | A-3 | 91185 | C-9, F-17 |
| 90843 | F-5 | 91186 | A-3 |
| 90844 | C-11 | 91189 | F-17 |
| 90845 | E-19, E-21 | 91199 | F-11 |
| 90898 | F-5 | 91247 | E-11 |
| 90918EUR | G-5 | 91256 | E-9, E-11 |
| 90969 | E-21, E-23 | 91259 | E-17 |
| 90990 | D-5, E-25 | 91265 | E-11 |
| 90996 | C-11 | 91266 | G-5 |
| 91002 | F-15 | 91268 | E-7, F-5 |
| 91008 | E-7 | 91277 | E-29 |
| 91019 | D-5, E-25 | 91280 | F-5 |
| 91023 | F-5 | 91281 | E-29 |
| 91027 | A-3 | 91284 | B-3 |
| 91028 | A-3 | 91294 | A-3, F-17 |
| 91051 | E-19 | 91295 | F-17 |
| 91091 | F-5 | 91296 | F-17 |
| 91094 | G-5 | 91321 | C-9, F-17 |
| 91105 | E-27 | 91329 | A-9 |
| 91107 | A-3 | 91340 | F-11 |
| 91109 | G-3 | 91346 | E-17 |
| 91111 | F-11 | 91350 | E-3 |
| 91112 | F-11 | 91351 | E-3 |
| 91113 | F-11 | 91352 | E-3 |
| 91114 | F-11 | 91355 | E-3 |
| 91115 | F-11 | 91356 | E-3 |
| 91116 | F-11 | 91369 | A-9 |
| 91117 | F-11 | 91370 | A-9 |
| 91118 | F-11 | 91375 | A-3, F-5, F-11, F-15 |
| 91119 | F-15 | 91378 | F-17 |
| 91121 | F-17 | 91379 | F-17 |
| 91123 | F-11 | 91388 | G-5 |
| 91127 | F-9 | 91399 | B-13 |
| 91130 | F-11 | 91400 | D-3, D-7, D-9 |
| 91139 | A-3 | 91401 | D-5 |
| 91140 | F-5 | 91402 | D-3, D-5 |
| 91141 | E-3, E-19, E-21, E-23, E-29 | 91403 | C-3, C-5, E-19 |
| 91142 | E-3, E-7, E-27 | 91404 | C-7, E-21 |
| 91143 | E-3 | 91405 | C-7, E-23 |
| 91144 | E-3 | 91406 | D-3, E-27 |
| 91145 | E-3 | 91408 | D-5 |
| 91146 | E-3 | 91410 | E-3, E-5 |
| 91147 | E-3 | 91411 | D-3, D-5 |
| 91148 | E-3 | 91412 | D-3, D-5 |
| 91149 | E-3 | 91413 | D-3, D-5 |
| 91150 | E-3 | 91414 | D-3, D-5 |
| 91151 | E-3 | 91417 | F-7 |
| 91152 | E-3 | 91418 | F-7 |
| 91153 | E-3 | 91419 | D-3, D-5 |
| 91159 | A-3 | 91421 | E-13 |
| 91160 | F-11 | 91422 | E-15 |
| 91161 | E-11 | 91423 | E-11 |
| 91162 | E-11 | 91424 | E-15 |
| 91163 | E-11 | 91425 | E-9 |
| 91164 | F-7 | 91426 | E-9 |
| 91169 | A-9, F-5 | 91427 | E-9 |
| 91171 | F-17 | 91429 | F-11 |
| 91172 | F-17 | 91430 | F-17 |
| 91173 | F-17 | 91432 | D-3, D-5 |
| 91175 | F-11 | 91433 | D-3, D-5 |



Part Number Index

| Part Number | Page |
|-------------|------------|
| 91435 | E-13 |
| 91437 | E-19, E-21 |
| 91438 | E-21, E-23 |
| 91439 | C-9, F-17 |
| 91440 | E-21, F-17 |
| 91441 | E-23, F-17 |
| 91442 | E-19 |
| 91443 | E-29, F-13 |
| 91444 | F-17 |
| 91445 | D-3, D-5 |
| 91446 | D-3, D-5 |
| 91447 | F-17 |
| 91448 | E-19, F-17 |
| 91449 | E-21 |
| 91450 | E-23 |
| 91451 | E-29 |
| 91456 | G-9 |
| 91459 | E-15 |
| 91461 | E-19 |
| 91462 | E-21, E-23 |
| 91464 | E-29 |
| 91469 | F-15 |
| 91472 | E-3 |
| 91473 | E-3 |
| 91474 | E-3 |
| 91475 | E-3 |
| 91476 | E-3 |
| 91477 | E-3 |
| 91496 | E-27 |
| 91497 | E-27 |
| 91498 | E-27 |
| 91499 | E-27 |
| 91522 | A-5 |
| 91533 | A-9 |
| 91534 | A-9 |
| 91535 | A-9 |
| 91537 | A-9 |
| 91538 | A-9 |
| 91539 | A-9 |
| 91543 | F-15, F-17 |
| 91544 | F-15 |
| 91545 | F-15 |
| 91546 | F-15 |
| 91550 | F-15 |
| 91551 | F-15 |
| 91556 | F-15 |
| 91557 | F-17 |
| 91560 | D-3, D-5 |
| 91562 | D-7, D-9 |
| 91563 | D-7 |

H

| | |
|----------|---------------------------------|
| HDW13339 | D-3 |
| HDW3768 | A-5 |
| HDW3771 | A-5 |
| HDW5012 | D-3, D-5 |
| HDW5204 | D-3 |
| HDW5217 | B-3, B-11, B-13, F-5, F-7, F-11 |
| HDW5251 | C-11, D-3 |
| HDW5290 | F-11 |
| HDW5355 | B-3 |

| Part Number | Page |
|-------------|------------|
| 91564 | D-7 |
| 91565 | D-7, D-9 |
| 91566 | D-7, D-9 |
| 91567 | D-7, D-9 |
| 91568 | D-7, D-9 |
| 91569 | D-7, D-9 |
| 91570 | F-7 |
| 91571 | D-7, D-9 |
| 91588 | F-11 |
| 91589 | F-11 |
| 91591 | F-9 |
| 91595 | F-17 |
| 91728 | G-3 |
| 91729 | G-3 |
| 91730 | G-3 |
| 91732 | E-19, E-21 |
| 91733 | E-23 |
| 91765 | F-11 |
| 91766 | F-11 |
| 91776 | G-5 |
| 91781 | G-5 |
| 91782 | G-5 |
| 91783 | G-5 |
| 91784 | G-9 |
| 91785 | G-9 |
| 91786 | G-9 |
| 9179 | A-3 |
| 9183 | A-3 |
| 9188 | A-3 |
| 9227 | E-11 |
| 9367 | F-7 |
| 9370 | F-7 |
| 9371 | G-9 |
| 9372 | G-9 |
| 9373 | G-9 |
| 9378 | G-5 |
| 9393 | E-9 |
| 9438 | F-17 |
| 9441 | B-13 |
| 945407 | F-9 |
| 9465 | G-11 |
| 9696 | F-11 |
| 9716 | B-11, F-5 |
| 9755 | E-13 |
| 9830 | F-11 |
| 9831 | F-11 |
| 9832 | F-11 |
| 9847 | E-9, E-11 |
| 9868 | F-11 |
| 9910 | G-7 |

| | |
|---------|---|
| HDW5363 | B-11 |
| HDW5364 | B-11, F-5 |
| HDW5633 | D-7, D-9 |
| HDW5636 | B-13 |
| HDW5723 | B-3, D-3, F-3, F-5, F-9, F-11 |
| HDW5724 | B-3, B-7, B-13, C-3, C-5, C-7, F-5, F-7 |
| HDW5916 | F-13 |
| HDW5920 | D-5, F-13 |
| HDW5925 | E-25 |



Part Number Index

| Part Number | Page | Part Number | Page |
|-------------|---------------------------------------|-------------|-----------------------|
| HDW5994 | D-3, D-5 | HDW8856 | B-3, C-3, C-5, C-7 |
| HDW6110 | F-5 | HDW8876 | E-25 |
| HDW6211 | D-5, F-3 | HDW8877 | E-5, E-11, E-17, E-27 |
| HDW6432 | F-9 | HDW8881 | D-3, E-5, E-7, E-25 |
| HDW6433 | B-15, F-5, F-11 | HDW8974 | B-3 |
| HDW6434 | B-3, B-9 | HDW8984 | D-3, D-5 |
| HDW6455 | B-11, B-13, C-3, C-5, C-7, C-11, F-13 | HDW90332 | E-9 |
| HDW6463 | C-3, C-5, C-7 | HDW90764 | E-5, E-17 |
| HDW6633 | D-5 | HDW90770 | D-5 |
| HDW6727 | E-19, E-21, E-23, F-7 | HDW90784 | D-3, D-5 |
| HDW6831 | C-11 | HDW90803 | F-5 |
| HDW7031 | B-5 | HDW90833 | F-5 |
| HDW7052 | F-13 | HDW90880 | F-5 |
| HDW7119 | B-3 | HDW90943 | E-21 |
| HDW7120 | B-9 | HDW90945 | E-21 |
| HDW7314 | E-3, E-5 | HDW90967 | E-17 |
| HDW7326 | D-5 | HDW91047 | D-5 |
| HDW7391 | E-13, E-15 | HDW91081 | E-5 |
| HDW7438 | E-5, E-7 | HDW91176 | E-11 |
| HDW7500 | F-7 | HDW91187 | F-11 |
| HDW7593 | B-3 | HDW91231 | F-11 |
| HDW7601 | E-5, E-7, E-19, E-21, E-23 | HDW91234 | F-9 |
| HDW7783 | C-3, C-5, C-7, F-5 | HDW91240 | E-19 |
| HDW7881 | A-5 | HDW91243 | E-5 |
| HDW7887 | A-5 | HDW91244 | E-5 |
| HDW7888 | A-5, F-5 | HDW91245 | E-5 |
| HDW7971 | E-5 | HDW91246 | E-11 |
| HDW8081 | D-3, D-5 | HDW91248 | E-5 |
| HDW8267 | B-3, B-13, D-3, F-5, F-7, F-9, F-11 | HDW91279 | F-5 |
| HDW8268 | B-3, B-9, B-15, F-5, F-9, F-11 | HDW91320 | F-5 |
| HDW8273 | D-3, F-5, F-7 | HDW91328 | F-13 |
| HDW8277 | C-3, C-5, C-7 | HDW91332 | F-5 |
| HDW8279 | B-3, F-9, F-11 | HDW91395 | F-13 |
| HDW8283 | D-3, D-5 | HDW91407 | D-3 |
| HDW8294 | B-3, B-9 | HDW91420 | D-3, D-5 |
| HDW8303 | B-5, B-9 | HDW91428 | D-3, D-5 |
| HDW8304 | B-3, B-5, B-13, F-5 | HDW91436 | E-13 |
| HDW8370 | B-7 | HDW91457 | F-13 |
| HDW8399 | A-5 | HDW91458 | F-13 |
| HDW8455 | A-7 | HDW91465 | E-29 |
| HDW8457 | B-3, D-5, F-3, F-13 | HDW91466 | E-17 |
| HDW8476 | E-29 | HDW91467 | E-17 |
| HDW8482 | C-11, D-3 | HDW91468 | E-17 |
| HDW8486 | B-9 | HDW91500 | B-13 |
| HDW8498 | F-3 | HDW91590 | F-11 |
| HDW8501 | B-13 | HDW9200 | F-7 |
| HDW8513 | B-5 | HDW9219 | D-5, F-13 |
| HDW8531 | A-5 | HDW9268 | F-7 |
| HDW8567 | A-5, F-9 | HDW9557 | E-9, E-11, E-15 |
| HDW8699 | E-21 | HDW9761 | E-29 |



Part Number Index

Part Number

Page

Part Number

Page



NOTES:



Limited Owner Warranty

MEC Aerial Platform Sales Corp. warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered. MEC Aerial Platform Sales Corp. further warrants the structural weldments of the main frame and scissor arms to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered. Excluded from such warranty is the battery(s) which carries a ninety (90) day warranty from described purchase date. Warranty claims within such warranty period shall be limited to repair or replacement, MEC Aerial Platform Sales Corp's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC Aerial Platform Sales Corp's then current flat rate, provided the defective part in question is shipped prepaid to MEC Aerial Platform Sales Corp. and is found upon inspection by MEC Aerial Platform Sales Corp. to be defective in material and/or workmanship. MEC Aerial Platform Sales Corp. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty. The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded. No Dealer, Sales Representative, or other person purporting to act on behalf of MEC Aerial Platform Sales Corp. is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC Aerial Platform Sales Corp. any liability or obligation which exceeds MEC Aerial Platform Sales Corp's obligations under this warranty.



Aerial Platform Sales Corp.

1775 Park Street, Suite 77 • Selma, CA 93662 USA
Ph: 1-800-387-4575 • 559-891-2488 • Fax: 559-891-2448
E-mail: info@mecawp.com • Web: www.mecawp.com