




Operator's Manual

40-AJ



MEC
ILLUSTRATION No.
ART. 6223

Meets requirements of ANSI A92.20-2020 and CSA B354.6-2019.
Serial Number Range 15300025 - Up

Part # 96822
August 2024

Revision History

Date	Reason for Update
August 2024	New Release



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA
Toll Free: 1-877-632-5438
Phone: 1-559-842-1500
Fax: 1-559-842-1520
info@MECawp.com
www.MECawp.com



Table of Contents

Section 1 - Introduction	1
<i>Introduction</i>	1
Section 2 - Safety	2
<i>Safety</i>	2
<i>Safety Alert Symbols & Fall Protection</i>	3
Section 3 - Specifications	4
<i>Specifications</i>	4
Section 4 - Hazards	5
<i>Electrocution Hazard</i>	5
<i>Tip-over Hazards</i>	8
<i>Fall and Collision Hazards</i>	9
<i>Additional Safety Hazards</i>	10
Section 5 - Controls & Components	11
<i>Component Locations</i>	11
<i>Platform Controls</i>	12
<i>Base Controls</i>	14
Section 6 - Workplace Inspection	16
<i>Workplace Inspection</i>	16
Section 7 - Operating Instructions & Pre-Operation Function Tests	17
<i>Functions Tests</i>	17
<i>Base Control Operation & Pre-Operation Functions Test</i>	20
<i>Platform Control Operation & Pre-Operation Functions Test</i>	24
<i>Drive Control Lever Operation</i>	27
<i>Auxiliary Power System & Test</i>	31
Section 8 - Maintenance	33
<i>Maintenance</i>	33
<i>Supporting Boom Assembly</i>	35
<i>Pre-Start Inspection Checklist</i>	36
<i>Frequent Inspection Checklist</i>	37
<i>Maintenance Inspection Report</i>	38
<i>Lubrication</i>	39
Section 9 - Troubleshooting	40
<i>Troubleshooting</i>	40
Section 10 - Decals	41
<i>Decals</i>	41
<i>Serial Plate Location</i>	44
Section 11 - Transport and Lifting Instructions	45
<i>Transport and Lifting Instructions</i>	45
<i>Boom Lifting Instructions</i>	48

Introduction

This Operator's Manual has been designed to provide you, the owner, user or operator, with the instructions and operating procedures essential to properly and safely operate your MEC Aerial Work Platform for positioning personnel, along with their necessary tools and materials, to overhead work locations.

This Operator's Manual and other manuals provided by MEC on the machine must be read and understood prior to operating your MEC Aerial Work Platform. The operator should not accept operating responsibility until he/she has read and understands the operator's manual as well as having operated the MEC Aerial Work Platform under supervision of an authorized, trained and qualified operator.



It is essential that the operator of the aerial work platform is not alone at the workplace during operation.

Modifications of this machine from the original design and specifications without written permission from MEC are strictly forbidden. A modification may compromise the safety of the machine, subjecting the platform occupants and personal around the machine to serious injury or death.

Your MEC Aerial Work Platform has been designed, built, and tested to provide safe, dependable service. Only authorized, trained and qualified personnel shall be allowed to operate or service the machine.

MEC, as manufacturer, has no direct control over machine application and operation. Proper safety practices are the responsibility of the owner, user and operator.

If there is a question on application and/or operation contact:



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA
Toll Free: 1-877-632-5438
Phone: 1-559-842-1500
Fax: 1-559-842-1520
info@MECawp.com
www.MECawp.com

Safety

DO NOT operate this machine until you have read and understood this manual, have performed the Workplace Inspection, Pre-Start Inspection and Routine Maintenance, and have completed all the test operations detailed in the Operating Instructions section.

Failure to read, understand and follow all safety rules, warnings, and instructions could result in serious injury or death. For your safety and the safety of those around you, you must operate your machine as instructed in this manual.

MEC designs aerial work platforms to safely and reliably position personnel, along with their necessary tools and materials, at overhead work locations. The owner/user/operator of the machine should not accept responsibility for the operation of the machine unless properly trained.

ANSI and other applicable standards identify requirements of all parties who may be involved with self-propelled elevating work platforms. The Manual of Responsibilities is considered a part of this machine and can be found in the manual compartment, located at the platform control station. To ensure safe use of machine, inspections and training specified in ANSI/SIA A92.22 & A92.24 must be performed at designated intervals as prescribed.



This product can expose you to chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.p65warnings.ca.gov.

Safety Alert Symbols & Fall Protection

MEC manuals and decals use symbols, colors and signal words to help you recognize important safety, operation and maintenance information.



RED and the word **DANGER** – Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



ORANGE and the word **WARNING** – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



YELLOW with alert symbol and the word **CAUTION** – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury.



YELLOW without alert symbol and the word **CAUTION** – Indicates a potentially hazardous situation which, if not avoided, may result in property damage.




GREEN and the word **NOTICE** – Indicates operation or maintenance information.

Fall Protection

Operators must comply with employer, job site and governmental rules regarding the use of personal protective equipment.

If required by your employer or job site, use personal fall protection equipment (PFPE) when operating this machine.



All personal fall protection equipment (PFPE) must comply with applicable governmental regulations, and must be inspected and used in accordance with the personal fall protection equipment (PFPE) manufacturer's instructions.

Fall restraint or fall arrest must be properly attached to a designated anchorage point when driving or operating the machine. Attach only one fall restraint or fall arrest to each anchorage point.

Specifications

Work Height*	40ft	12.2m	
Platform Height	40ft	12.2m	
Maximum Drive Height	Full Height		
Maximum Outreach	30ft	9.1m	
Turntable Swing	355° Non-Continuous		
Jib Range Of Motion	135°		
Platform Rotation	180° (90° Each Side)		
Machine Weight** (Unloaded)	11,500lbs	5,216kg	
Lift Capacity	600lbs	272kg	
Maximum Occupants	2 Person		
Stowed Height	95in	2.4m	
Overall Length	20ft	6.1m	
Overall Width	92in	2.34m	
Tailswing	23in	0.6m	
Platform Details	Width	72in	1.83m
	Depth	40in	1m
	Entry	1 End Swing Gate, 2 Slide Bar Entries	
Turning Radius, Inside	6ft 6in	2m	
Ground Clearance	8in	20cm	
Lift Speed	45 sec		
Extend Speed	15 sec		
Jib Lift Speed	15 sec		
Drive Speed (Proportional)	Stowed	0-4.0mph	0-6.4km/h
	Raised/Extended	0-0.5mph	0-0.8km/h
Gradeability, Stowed	Downhill	40% (22°)	
	Uphill	40% (22°)	
Breakover Angle	40% (22°)		
Axle Oscillation	10° (5° Each Side)		
Maximum Wind Speed	28mph	12.5m/sec (45km/h)	
Engine	Kubota D1105 - Tier 4 Final		
Fuel Type	Diesel		
Fuel Capacity	16 gal	60 liter	
Hydraulic Fluid Capacity	26 gal	100 liter	
Ambient Operating Range	-20°F to 120°F	-29°C to 49°C	
Wheel Lug Nut Torque	150lb-ft	203Nm	
<p>Meets applicable requirements of ANSI A92.20-2020 and CSA B354.6-2019. Allowable ambient temperature range: -20°F to 120°F (-29°C to 49°C). Consult with MEC for operation outside of this range. *Working Height adds 6 feet (2 meters) to platform height. **Weight may increase with certain options.</p>			

Electrocution Hazard

ELECTROCUTION HAZARD! THIS MACHINE IS NOT INSULATED!

DEATH OR SERIOUS INJURY will result from contact with or inadequate clearance from any electrically charged conductor.



You must maintain a **CLEARANCE OF AT LEAST 10 FEET (3.05 meters)** between any part of the machine, or its load, and any electrical line or apparatus carrying over 300 Volts up to 50,000 Volts. One foot (30.5 centimeters) additional clearance is required for every additional 30,000 Volts.

Observe Minimum Safe Approach Distance.

This machine is not electrically insulated and will not provide protection from contact with or proximity to electrical current.

Maintain safe distances from electrical power lines and apparatus in accordance with applicable government regulations and the following chart:


Voltage	Minimum Safe Approach Distance	
	Feet	Meters
Phase to Phase		
0 Volts to 300 Volts	Avoid Contact	
Over 300V to 50kv	10ft	3.1m
Over 50KV to 200KV	15ft	4.6m
Over 200KV to 350KV	20ft	6.1m
Over 350KV to 500KV	25ft	7.6m
Over 500KV to 750KV	35ft	10.7m
Over 750KV to 1000KV	45ft	13.7m




Allow for platform movement, electrical line sway or sag and beware of strong or gusty winds.

Keep away from the machine if it contacts energized power lines. Personnel on the ground or in the platform must not touch or operate the machine until energized power lines are shut off.


Do not use the machine as a ground for welding.



CLEARANCES FROM LIVE AERIAL CONDUCTORS



(a) Distribution lines up to and including 133 kV



(b) Transmission lines greater than 133 kV

LEGEND

- = No shading, in the front views, indicates no proximity requirements
- = Light shading indicates spotter is required
- = Heavy shading indicates the NO GO ZONE

When working in the area of energized conductors the user shall direct and the operator shall comply with the requirements to:

- 1) Stay at least 10 feet (3.05 meters) away from power lines with any part of their body, conductive object or any part of the MEWP (Mobile Elevating Work Platform).
- 2) If work requires working nearer than 10 feet (3.05 meters), stop and consult a qualified person with respect to electrical transmission and distribution to have appropriate measures taken (such as de-energizing and grounding).
- 3) If there is a question that the power lines may carry more than 50kV, consult a qualified person with respect to electrical transmission and distribution before proceeding.
- 4) If working or approaching closer than explained above, it shall only be done by a qualified person with respect to electrical transmission and distribution. Only qualified persons may work on electric circuit parts or equipment that has not been de-energized. Such persons shall be capable of working safely on energized circuits and shall be familiar with the proper use of special precautionary techniques, personal protective equipment, insulating and shielding materials and insulated tools.

Tip-over Hazards

DO NOT exceed the maximum platform capacity. The weight of options and accessories will reduce the rated platform capacity and must be factored into the total platform load. Refer to the decals on the options or contact MEC.

Driving: DO NOT drive the machine on a slope that exceeds the maximum uphill or downhill slope rating. Slope rating applies to machines in the stowed position.

Driving in stowed position: Use extreme care and reduce speed when driving across uneven terrain, debris, unstable or slippery surfaces, and near holes or drop-offs.

Driving with the platform elevated: DO NOT drive on or near uneven terrain, unstable surfaces, curbs, drop-offs or other hazardous conditions.

Ensure that all tires are in good condition and lug nuts are properly torqued.

DO NOT push off or pull toward any object outside the platform.

Maximum Allowable Side Force: 100lbs (445N).

DO NOT elevate the platform when the machine is on a surface that is soft and / or on a slope.

STOP ALL MOVEMENT if the alarm sounds and the red Tilt Indicator Light illuminates when the platform is raised – see Tilt Indicator Light on page 22 for instructions.

NEVER transport tools and materials unless they are firmly secured. Secure all tools and loose materials. DO NOT carry materials or tools on the guardrails. DO NOT allow tools, supplies or any items to extend outside the platform.

DO NOT elevate the platform when wind speeds are in excess of 28mph (12.5m/s). If wind speeds exceed 28mph (12.5m/s) when the platform is elevated, carefully lower the platform and discontinue operation.

DO NOT increase the surface area of the platform (i.e. cover the rails with tarp or plywood). Increased surface area exposed to the wind will decrease machine stability.

NEVER modify or alter the work platform without written permission from MEC.

DO NOT attach overhanging loads or use the machine as a crane. Do not allow anything (hoses, cords, wires, ropes, etc.) to hang from the platform.

NEVER alter or disable any machine components.

DO NOT replace any part of the machine with anything except MEC-supplied or MEC-approved parts.

NEVER use ladders or scaffolds in the platform or allow them to touch any part of the machine.

NEVER use the machine on a moving or mobile surface or vehicle.



Fall and Collision Hazards

Fall Hazards

DO NOT sit, stand or climb on the platform guard rails. Maintain a firm footing on the platform floor at all times.

Keep the platform floor clear of debris.

DO NOT fasten a fall restraint lanyard to an adjacent structure.

Ensure that all gates are properly closed and secured before operating the machine.

Operators must comply with employer and job site rules and governmental regulations regarding the use of Personal Fall Protective Equipment.

DO NOT exit the platform when elevated



Collision Hazards

ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

Check path before moving for equipment, materials or other obstructions.

Check for overhead obstructions before moving.

DO NOT place the boom or platform against another structure.

Check path before moving for crushing hazards when holding the platform rail.

Reduce travel speed when moving the machine on slopes, when near personnel and obstacles, or when surface conditions are wet, slippery or otherwise limiting.

DO NOT operate in the path of any crane unless the controls of the crane have been locked out and/or precautions have been taken to prevent any possible collision.

Stunt driving and horseplay are PROHIBITED.

Check for personnel and obstructions below the platform when lowering the platform.



Additional Safety Hazards

Explosion and Fire Hazards

- DO NOT operate the machine in hazardous locations or locations where potentially flammable or explosive gases or particles may be present.

Damaged Machine Hazards

- Conduct a thorough pre-start inspection of the machine and test all functions before each work shift to check for damage, malfunction and unauthorized modification. Tag and remove a damaged, malfunctioning or modified machine from service. DO NOT use a damaged, malfunctioning or modified machine.
- Routine maintenance must be performed by the operator before each work shift. Scheduled maintenance must be performed by a qualified service technician at scheduled intervals. Tag and remove from service any machine that has not had scheduled preventative maintenance performed.
- Check that all safety and instructional decals are in place and undamaged.
- Check that the operator's, safety and responsibilities manuals are present in the storage container located in the platform. All manuals must be complete, undamaged and readable.

Bodily Injury Hazards

- DO NOT operate the machine when there is a hydraulic fluid or air leak. Hydraulic fluid or air under pressure can penetrate and burn skin, damage eyes, and may cause serious injury, blindness, and death. Repair leaks immediately. Fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.
- All compartments must remain closed and secure during machine operation. Improper contact with components under any cover will cause serious injury. Only trained maintenance personnel should access compartments. The operator should only access a compartment when performing pre-operation inspection.

Weld Line to Platform Safety (If Equipped)

- Read, understand and follow all warnings and instructions provided with the welding power unit.
- DO NOT connect weld leads or cables unless the welding power unit is turned off at the platform controls.
- DO NOT operate unless the weld cables are properly connected.
- DO NOT connect the ground lead to the platform. Do not use any part of the machine as a ground for welding.
- DO NOT hang wires or cables over guardrails or suspend from the platform.

Battery Safety - Burn Hazards

- Batteries contain acid. Always wear protective clothing and eye wear when working with batteries. Avoid spilling or contacting battery acid. Neutralize battery acid spills with baking soda and water.

Battery Safety - Explosion Hazard

- Keep sparks, flame and lighted tobacco away from batteries. Batteries emit explosive gas.

Battery Safety - Electrocutation Hazard

- Avoid contact with electrical terminals.

Component Locations






ILLUSTRATION No.
ART_6231



Platform Controls



ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

#	Controls	Description
1	Horn Button	Press to sound warning horn.
2	Auxiliary Power	If normal power fails, press and hold while using Boom Retract and Boom Lower functions.
3	Engine Start/Stop Switch	Push this switch up to start engine. Push this switch down to stop engine.
4	Glow Switch	Push this switch up to activate glow plugs prior to cold starting the engine.
5	Emergency Stop Switch	Press the Emergency Stop switch at any time to stop all machine functions. Turn the switch clockwise to reset it and resume machine operation.
6	Generator Switch (Optional)	Push this switch up to activate the optional AC generator. Generator switches off when any other function is enabled.
7	Engine Speed Select Switch	Use this switch to set the engine speed when functions are enabled. Setting this switch to low idle speed allows the operator to move the machine slowly and precisely. Push this switch up for high idle speed and fast function speed. Push this switch down for low idle speed and slow function speed.
8	Speed/Torque Switch	Push this switch to the left for high speed drive. Push this switch to the right for high torque drive.

9	PPSS Switch	Warn Only	When the PPSS first senses an object overhead it activates an intermittent audible alarm. The frequency of this alarm increases as the object comes closer to the sensors. Pay careful attention to the object the sensors have detected.
		Warn & Stop	If selected, the machine will stop when the warning alarm becomes continuous. Boom functions that elevate the platform are disabled; drive functions are disabled. Boom functions that lower the platform are allowed.
10	Drive/Steer Control Lever	Depending on the position of the turntable, the machine may move in unexpected directions when the Drive and Steer functions are activated. The color- and shape-coded arrows on the joystick decal correspond to similar arrow decals on the machine chassis. Be sure to check the arrows on the chassis before using the Drive or Steer functions.	
		Drive Function	Depress the enable bar on front of the control lever, then push the control lever forward or backward to drive the machine.
		Steer Function	Depress the enable bar on front of the control lever, then press the thumb switch on top of the control lever to steer left or right.
11	Overload Indicator Light	Light on indicates too much weight on the platform. An audible alarm will sound and all machine function will stop. Remove weight from the platform to restore function and continue.	
12	Tilt Indicator Light	This light illuminates and an alarm sounds when the machine is not level. Follow the instructions on page 26 to safely lower the platform.	
13	Jib/Platform Control Lever	Jib Lift/Lower Function	Depress the enable bar on front of the control lever, then push the control lever forward to lift the jib. Depress the enable bar on front of the control lever, then pull the control lever backward to lower the jib.
		Platform Rotate Function	Depress the enable bar on front of the control lever, then push the control lever right to rotate the platform counterclockwise. Depress the enable bar on front of the control lever, then push the control lever left to rotate the platform clockwise.
		Riser Lift/Lower Function	Depress the enable bar on front of the control lever, then push the thumb switch on top of control lever forward to lift the riser boom. Depress the enable bar on front of the control lever, then push the thumb switch back to lower the riser boom.
14	Platform Level Switch	Press the enable bar on front of a control lever, then press this switch up to manually level the platform upward or down to manually level the platform downward.	
15	Boom/Turntable Control Lever	Turntable Rotate Function	Depress the enable bar on front of the control lever, then push the control lever to the left to rotate the turntable clockwise or right to rotate the turntable counterclockwise.
		Boom Lift/Lower Function	Depress the enable bar on front of the control lever, then push the control lever forward to lift the main boom. Depress the enable bar on front of the control lever, then pull the control lever back to lower the main boom.
		Boom Extend/Retract Function	Depress the enable bar on front of the control lever, then push the thumb switch on top of control lever forward to extend the main boom. Depress the enable bar on front of the control lever, then push the thumb switch on top of control lever backward to retract the main boom.

Base Controls




ILLUSTRATION No. ART_6225



ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

#	Controls	Description
1	Hour Meter	Indicates total elapsed time of machine operation.
2	Selector Switch	Platform Select to operate from the platform control panel.
		Base Select to operate from the base control panel.
		Off Select to stop operation from either control panel.
3	Engine Start/Stop Switch	Push this switch up to start engine. Push this switch down to stop engine.
4	Glow Switch	Push this switch up to activate glow plugs prior to starting.



5	Starter Time-out Indicator	When this red light is illuminated, the starter circuit is temporarily disabled. The starter circuit times out if the starter is run continuously for 20 seconds without the engine starting. The starter functions resets after approximately 30 seconds.
6	Emergency Stop Switch	Press the Emergency Stop switch at any time to stop all machine functions. Turn the switch clockwise to reset it and resume machine operation.
7	Platform Rotate Switch	Press and hold the Function Enable Switch, then move this switch left to rotate the platform clockwise. Press and hold the Function Enable Switch, then move this switch right to rotate the platform counterclockwise.
8	Platform Level Switch	Press and hold the Function Enable Switch, then move this switch up to manually level the rear of the platform upward. Press and hold the Function Enable Switch, then move this switch down to manually level the rear of the platform downward.
9	Overload Indicator Light	Light on indicates too much weight on the platform. An audible alarm will sound and all machine function will stop. Remove weight from the platform to restore function and continue.
10	Tilt Indicator Light	This light illuminates and an alarm sounds when the machine is not level. Follow the instructions on page 22 to safely lower the platform.
11	Function Enable Switch	Press and hold this switch to enable boom, turntable and platform operations. Press down to operate the controls at slow speed. Press up to operate the controls at higher speed.
12	Main Boom Extend/Retract	Press and hold the Function Enable Switch, then move this switch right to extend the main boom. Press and hold the Function Enable Switch, then move this switch left to retract the main boom.
13	Main Boom Lift/Lower	Press and hold the Function Enable Switch, then move this switch up to lift the main boom. Press and hold the Function Enable Switch, then move this switch down to lower the main boom.
14	Riser Lift/Lower Switch	Press and hold the Function Enable Switch, then move this switch up to lift the riser boom. Press and hold the Function Enable Switch, then move this switch down to lower the riser boom.
15	Turntable Rotate	Press and hold the Function Enable Switch, then move this switch left to rotate the turntable clockwise. Press and hold the Function Enable Switch, then move this switch right to rotate the turntable counterclockwise.
16	Jib Lift/Lower	Press and hold the Function Enable Switch, then move this switch up to lift the jib. Press and hold the Function Enable Switch, then move this switch down to lower the jib.
17	Circuit Breaker	Trips when there is excessive electrical load. Push to reset.
18	Auxiliary Power Switch	If normal power fails, press and hold while using boom retract and boom lower functions.

Workplace Inspection

DO NOT operate this machine until you have read and understood this manual, have performed the **Workplace Inspection, Pre-Start Inspection and Routine Maintenance**, and have completed all the test operations detailed in the **Operating Instructions** section.

Inspect the workplace and determine whether the workplace is suitable for safe machine operation. Do this before moving the machine to the workplace.

Be sure the lift is the correct machine for the job.

Be aware of workplace conditions, and continue to watch for hazards while operating the machine.

ELECTROCUTION HAZARD! THIS MACHINE IS NOT INSULATED!

DEATH OR SERIOUS INJURY will result from contact with or inadequate clearance from any electrically charged conductor.



You must maintain a **CLEARANCE OF AT LEAST 10 FEET (3.05 meters)** between any part of the machine, or its load, and any electrical line or apparatus carrying over 300 Volts up to 50,000 Volts. One foot (30.5 centimeters) additional clearance is required for every additional 30,000 Volts.

Observe Minimum Safe Approach Distance.

Workplace Inspection

Before operating the machine, check the workplace for all possible hazards, including but not limited to:

- Drop-offs or holes, including those concealed by water, ice, mud, etc.
- Sloped, unstable or slippery surfaces
- Bumps, surface obstructions and debris
- Overhead obstructions and electrical conductors
- Other objects or equipment
- Hazardous locations and atmospheres
- Inadequate surface and support to withstand all load forces imposed by the machine
- Wind and weather conditions
- The presence of unauthorized personnel
- Other possible unsafe conditions

Functions Tests

DO NOT operate this machine until you have read and understood this manual, have performed the **Workplace Inspection, Pre-Start Inspection and Routine Maintenance**, and have completed all the test operations detailed in the **Operating Instructions** section.

This section provides instructions and tests for each function of machine operation. Follow all safety rules and instructions. The operator must conduct inspections and a Functions Test of the machine before each work shift to check that all machine systems are working properly.

Test the machine on a firm level surface with no debris, drop-offs, potholes or overhead obstructions. Perform each step outlined in this section.

This machine shall only be operated by trained and authorized personnel. If multiple operators use this machine, all must be trained, qualified and authorized to use it. New operators must perform a Pre-Start Inspection and Functions Test prior to operating the machine.

Operators must comply with all employer and job site rules and governmental regulations regarding the use of personal protective equipment.


DO NOT use a machine that is malfunctioning. If any function does not perform as described, tag the machine and remove for repair by a qualified service technician. After repairs are completed, a Pre-Start Inspection and Functions Test must be performed before using the machine.



Check the area above and around the machine for obstructions and electrical power lines before operating the machine. The machine must have space to allow full elevation of platform.

Prestart

Perform a Pre-start Inspection (see page 36). Check the red Emergency Stop buttons at both the base control and platform controls. Turn both switches clockwise to reset them and resume machine operation.




ART_3353

Starting Engine from Base Controls

Be sure that the upper and lower Emergency Stop switches are reset.

- Lower Control Box: Turn Key Switch to the Chassis.



ART_4714

Start/Stop Switch

Move the Start/Stop switch upward to start the engine. Release the switch when the engine starts. Press the switch down to stop the engine.




ART_4722

Glow Plug Switch

With the Glow switch held up, press and hold the Start/Stop switch upward until the engine starts. Release both switches once the engine starts.

- Cold Start: Move and hold the Glow Switch up as indicated in the Preheat table.

Ambient Temperature	Preheat Time
Above 50°F (10°C)	5 Seconds
50°F to 23°F (10°C to -5°C)	10 Seconds
Below 23°F (-5°C)	20 Seconds
20 Seconds = Limit of Continuous Use	




ART_4723

To protect the starter motor, power will cut off to the starter circuit when the starter motor has run continuously for 20 seconds without starting the engine. The Starter Circuit Cutout indicator light will turn on at the Base Control panel and power to the starter circuit will cut out for 30 seconds.

Starter Time-out Indicator

To protect the starter motor, power cuts off to the starter circuit when the starter motor has run continuously for 20 seconds without starting the engine. The Starter Circuit Cutout indicator light on the Lower Controls Box will turn on during this time. Power to the starter circuit reengages after 30 seconds.




ART_4724

Starting Engine from Platform Controls

Be sure that the upper and lower Emergency Stop switches are reset.


- Lower Control Box: Turn Key Switch to the Platform.



ART_4724

Start/Off Switch

Move the Start/Off switch upward to start the engine. Release the switch when the engine starts. Press the switch down to stop the engine.




ART_4725

Glow Plug Switch

With the Glow switch held up, press and hold the Start/Stop switch upward until the engine starts. Release both switches once the engine starts.

- Cold Start: Move and hold the Glow Switch up as indicated in the Preheat table.




ART_4726

Ambient Temperature	Preheat Time
Above 50°F (10°C)	5 Seconds
50°F to 23°F (10°C to -5°C)	10 Seconds
Below 23°F (-5°C)	20 Seconds
20 Seconds = Limit of Continuous Use	

To protect the starter motor, power will cut off to the starter circuit when the starter motor has run continuously for 20 seconds without starting the engine. The Starter Circuit Cutout indicator light will turn on at the Base Control panel and power to the starter circuit will cut out for 30 seconds.

Base Control Operation & Pre-Operation Functions Test



96393 R0

mec
ILLUSTRATION No.
ART_6225



ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

Emergency Stop

Press the Emergency Stop switch at any time to stop all machine functions. Turn the switch clockwise to reset it and resume machine operation. Press the Emergency Stop switch whenever the machine is not in operation.




ART_3353

Selecting Base Operation

Be sure that the upper and lower Emergency Stop switches are reset.

- Lower Control Box: Turn Key Switch to the Chassis.




ART_4714

Function Enable

Press and hold this switch to enable and operate machine functions from the base controls. Releasing this switch will disable machine functions.

- Press down to operate the controls at slow speed.
- Press up to operate the controls at higher speed.



ART_4715



Do not elevate the platform if the machine is not on a firm level surface.

Base Control Boom/Platform Functions

Telescopic Boom Extend/Retract

Move and hold the Extend/Retract switch on the base control panel to extend or retract the boom.

Test Operation

- Press and hold the Function Enable switch.
- Extend boom until it stops. Boom should extend to maximum length.
- Retract the boom until it stops. Boom should retract to minimum length.
- Releasing the switch will stop boom extension or retraction.
- Pressing the Emergency Stop Switch will stop boom extension or retraction.




ART_4717

Main Boom Lift/Lower

Press and hold the Boom Lift/Lower switch on the base control panel to lift or lower the boom.

Test Operation

- Press and hold the Function Enable switch.
- Raise the boom until it stops.
- Lower the boom until it stops. Boom should rest on the turntable pad.
- Releasing the switch will stop Boom Lift/Lower function.
- Pressing the Emergency Stop Switch will stop boom lift/lower function.




ART_4718

Jib Lift/Lower

Press and hold the Jib Lift/Lower switch on the base control panel to lift or lower the jib.

Test Operation

- Press and hold the Function Enable switch.
- Raise the jib until it stops.
- Lower the jib until it stops.
- Releasing the switch will stop Jib Lift/Lower function.
- Pressing the Emergency Stop Switch will stop jib lift/lower function.



ART_4720


Platform Level

The platform will automatically level as the boom is lifted or lowered. The Platform Level function allows manual level adjustment of the platform. Manual leveling may be used to adjust the platform within 5° of level.

- Press and hold the Platform Level switch on the base control panel to manually adjust the level of the platform.

Test Operation

- Press and hold the Function Enable switch.
- Push the switch up and down.
- The platform level should change accordingly. Releasing the switch will stop platform level function.
- Pressing the Emergency Stop Switch will stop platform level function.




Platform Rotate

Press and hold the Platform Rotate switch on the base control panel to rotate the platform.

Test Operation

- Press and hold the Function Enable switch.
- Push the switch left and right. The platform should rotate accordingly.
- Releasing the switch will stop platform rotate function.
- Pressing the Emergency Stop Switch will stop platform rotate function.





Tilt Indicator Light



STOP ALL MOVEMENT if Tilt Alarm sounds.

Light On and alarm sounding indicates an unsafe condition.


- STOP ALL MOVEMENT. The machine is not level.
- Look at the diagram to determine the condition of the counterweight as it relates to the slope, then use extreme caution while following the instructions. DO NOT rotate the turntable while lowering.



- If the Tilt Alarm sounds while the counterweight is uphill, first retract the boom, then lower the boom.
- If the Tilt Alarm sounds while the counterweight is downhill, first lower the boom, then retract the boom.
- Move the machine to a firm, level surface before continuing operation.


Overload Light and Alarm

- Light on indicates too much weight on the platform.
- An audible alarm will sound and all machine function will stop.
- Remove weight from the platform to restore function and continue.



ART_3528


Platform Control Operation & Pre-Operation Functions Test



ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

Platform Control Function Enable Switch


Note: If any Function Enable trigger or button is depressed for seven (7) seconds without any function being activated, the Enable System times out and deactivates. Release the trigger or button and reengage to activate the Function Enable System.



The Drive function and most boom functions are enabled by squeezing the trigger at the front of the appropriate control handle.

Emergency Stop

Press the Emergency Stop switch at any time to stop all machine functions. Turn the switch clockwise to reset it and resume machine operation. Press the Emergency Stop switch whenever the machine is not in operation.



Activation of the Emergency Stop switch will apply brakes immediately.




This will cause sudden platform movement as the machine comes to an abrupt stop.

Brace yourself and secure objects on the platform during operation of machine.

Selecting Platform Operation

Be sure that the upper and lower Emergency Stop switches are reset.

- Lower Control Box: Turn Key Switch to the Platform.




ART_4724

Entering the Platform

Personnel shall enter and exit the platform only at the Personnel Entry Gates, and only when the boom is fully retracted and lowered.

Ensure that all Personnel Entry Gates are properly closed and that the Swing Gate is latched in the closed position before operating the machine.

Personnel Entry Gates




ART_4726

Fall Protection

Personal fall protection equipment (PFPE) is required when operating this machine.

All personal fall protection equipment (PFPE) must comply with employer and job site rules and applicable governmental regulations, and must be inspected and used in accordance with the personal fall protection equipment (PFPE) manufacturer's instructions.



ART_4713


ALWAYS wear approved fall protection, properly attached to a designated anchor point, when operating the machine.

DO NOT attach more than one lanyard per anchor point.

Operate from Platform

Start/Off Switch


Move the Start/Off switch upward to start the engine. Release the switch when the engine starts. Press the switch down to stop the engine.



ART_4725

Horn Button

Press the Horn button to verify proper operation.



ART_3359



Tilt Indicator Light



STOP ALL MOVEMENT if Tilt Alarm sounds.

Light On and alarm sounding indicates an unsafe condition.

- STOP ALL MOVEMENT. The machine is not level.
- Look at the diagram to determine the condition of the counterweight as it relates to the slope, then use extreme caution while following the instructions. DO NOT rotate the turntable while lowering.



- If the Tilt Alarm sounds while the counterweight is uphill, first retract the boom, then lower the boom.
- If the Tilt Alarm sounds while the counterweight is downhill, first lower the boom, then retract the boom.
- Move the machine to a firm, level surface before continuing operation.

Overload Light and Alarm


- Light on indicates too much weight on the platform.
- An audible alarm will sound and all machine function will stop.
- Remove weight from the platform to restore function and continue.



Drive Control Lever Operation

Depending on the orientation of the boom and chassis, the Drive and Steer functions may move the machine in directions opposite of the motion of the control lever. The color- and shape-coded arrows on the control lever decal correspond to similar arrow decals on the machine chassis (see illustrations). Be sure to check the arrows on the chassis before activating and using the Drive or Steer functions.

- Drive Function speed is proportional and is controlled by the positional of the control lever. The further it is moved from the neutral (center) position, the faster the speed will be.
- When the boom is elevated out of the stowed position, the maximum drive speed is reduced to 0.5mph (0.8km/h). Drive function speed is still fully proportional to the position of the drive control handle.
- The control lever returns to the neutral (center) position when released.
- Steering Function is not proportional.



Note: The Steering Function **does not** automatically return the steering wheels to the centered position. Always check the position of the steering wheels before and during machine operation.


Test Operation

- Drive: Squeeze the enable trigger, then move the control lever in the desired direction of movement. The further it is moved from the neutral (center) position, the faster the speed will be.
- Stop: Return the control lever to the neutral (center) position. Releasing the control lever will also stop the machine. Releasing the trigger will result in a rapid stop.
- Extend the boom approximately 3 feet (1 meters), then drive the machine. Speed should be reduced significantly from the fully-retracted, fully-lowered speed. Retract the boom.
- Elevate the boom approximately 10°, then drive the machine. Speed should be reduced significantly from the fully-retracted, fully-lowered speed. Lower the boom.
- Steering: Squeeze the enable trigger, then press the thumb switch on top of the control lever to steer in the desired direction.



Note: The Steering Function does not automatically return the steering wheels to the centered position. Stay alert to the position of the steering wheels before and during machine operation.

Drive & Steer Directional Arrows


Pay careful attention to the Chassis Drive & Steer arrows for machine direction.



Upper Control Box



When the platform is over the steering wheels, the machine moves in the opposite direction of the Control Lever.



Platform over non-steering wheels

Platform over steering wheels





 ILLUSTRATION No.
ART_4747

Speed/Torque Switch

Move this switch to the left for high speed drive. Move this switch to the right for high torque drive.




ART_4757

Engine Speed Select

Use this switch to set the engine speed when functions are enabled. Setting this switch to low idle speed allows the operator to move the machine slowly and precisely.

- Move this switch up for high idle speed and fast function speed.
- Move this switch down for low idle speed and slow function speed.




ART_4755

Boom Functions Control Lever

This control lever controls the Main Boom Extend/Retract, Telescopic Boom Lift/Lower and Turntable Rotate functions. The control lever is fully proportional for the Boom Lift/Lower and Turntable Rotate functions.

These functions are enabled by pressing the trigger on the front of the control lever.




ART_4731

Test Operation

- 1) To test the Telescopic Boom Extend/Retract function:
 - Squeeze the enable trigger, then press and hold the thumb switch on top of the control lever forward until the telescopic boom reaches full extension.
 - Squeeze the enable trigger, then press and hold the thumb switch on top of the control lever rearward until the telescopic boom full retracts.
- 2) To test the Main Boom Lift/Lower function:
 - Squeeze the enable trigger, then push the control handle forward to lift the main boom. Lift the boom completely.
 - Squeeze the enable trigger, then pull the control handle back to lower the main boom. Lower the boom to its stowed position.
- 3) To test the Turntable Rotate function:
 - Squeeze the enable trigger, then push the control handle to the left to rotate the turntable clockwise.
 - Squeeze the enable trigger, then push the control handle to the right to rotate the turntable counterclockwise.

Platform Level Switch

The platform will automatically level as the boom is lifted or lowered. The Platform Level function allows manual level adjustment of the platform. Manual leveling may be used to adjust the platform within 5° of level.



ART_4732

Test Operation

- 1) To test the Boom Extend/Retract function:
 - Press and hold any Enable button.
 - Push the Platform Level switch up or down to adjust the position of the platform.
 - Platform Level power is disabled upon exceeding 5° out of level when out of the stowed position. Power is allowed only to the direction that returns the platform toward level.

Riser Boom/Platform/Jib Functions Control Handle

The Platform/Jib Functions control handle controls the Platform Rotate, Jib Lift/Lower functions, and Riser Boom Lift/Lower functions. The control handle is fully proportional for Jib and Platform functions.

These functions are enabled by pressing the trigger on the front of the control handle.




Test Operation

- 1) To test the Riser Lift/Lower function:
 - Squeeze the enable trigger, then press and hold the thumb switch on top of the control lever forward until the riser boom full rises.
 - Squeeze the enable trigger, then press and hold the thumb switch on top of the control lever rearward until the riser boom full lowers.
- 2) To test the Jib Lift/Lower function:
 - Squeeze the enable trigger, then push the control handle forward to raise the jib.
 - Squeeze the enable trigger, then pull the control handle backward to lower the jib.
- 3) To test the Platform Rotate function:
 - Squeeze the enable trigger, then push the control handle left to turn the platform clockwise.
 - Squeeze the enable trigger, then push the control handle right to turn the platform counter clockwise.

Shutdown Procedure

When finished with the machine, place the platform in the stowed position. Park the machine on a level surface. Carefully exit the platform using a constant three (3) point dismount/grip.

Turn the Selector Key Switch to the Off position and remove the key to prevent unauthorized use. Always put the switch in Off position when leaving the machine at the end of the work day.



ART_4734

Auxiliary Power System & Test



If primary power fails while the platform is elevated, use the Auxiliary Power System to safely lower the platform.




Do not climb down the boom assembly or exit the platform while elevated.

ALWAYS check over, under and around the machine for personnel, structures and obstructions before activating any control function and continue to watch for hazards while operating the machine.

PLATFORM CONTROL



BASE CONTROL



The Auxiliary Power System is used to lower the platform in case of primary power failure. To lower the platform, activate the Auxiliary Power Switch to run the auxiliary hydraulic pump.

This function uses battery power from the auxiliary battery to lower the platform.

- Push and hold the Auxiliary Power Switch, then use the Main Boom Extend/Retract function to retract the boom.
- Continue to hold the Auxiliary Power Switch, then use the Riser Boom Lift/Lower function to lower the riser boom.
- Continue to hold the Auxiliary Power Switch, then use the Main Boom Lift/Lower function to lower the boom.

Note: Auxiliary Power activation stops the engine.

Note: The Auxiliary Power Switch serves as an enable switch. It is not necessary to use the primary function enable switch.

Test Operation

- Test the Auxiliary Power System from both control stations.
- Test any lift function for 5-10 seconds to verify proper operation.

Maintenance

DO NOT operate this machine until you have read and understood this manual, have performed the **Workplace Inspection, Pre-Start Inspection and Routine Maintenance**, and have completed all the test operations detailed in the **Operating Instructions** section.

Tag and remove a damaged, malfunctioning or modified machine from service. **DO NOT** use a damaged, malfunctioning or modified machine.

Use the Pre-Start Inspection to determine what Routine Maintenance is required. The operator may perform only the routine maintenance items specified in this manual.

IMPORTANT: Scheduled maintenance inspection checklists are included in this manual for use only by qualified service technicians. Only qualified service technicians may perform repairs to the machine. After repairs are completed, the operator must perform a Pre-Start Inspection before proceeding to the Functions Test.



Hydraulic fluid under pressure can penetrate and burn skin, damage eyes, and may cause serious injury, blindness, and death. Repair leaks immediately. Fluid leaks under pressure may not always be visible. Check for pin hole leaks with a piece of cardboard, not your hand.

NEVER perform work under the boom assembly with the platform elevated without first supporting the boom assembly.

Failure to perform scheduled maintenance at recommended intervals may result in injury or death. Keep maintenance records current and accurate.



Immediately report any damage, defect, unauthorized modification or malfunction to your supervisor. Any defect must be repaired prior to continued use. **DO NOT** use a damaged, modified or malfunctioning machine.

DO NOT hang anything over any control handle at any time.

Never leave hydraulic components or hoses open. Plug all hoses and fitting immediately after disassembly to protect the system from outside contamination (including rain).



Never open a hydraulic system when there are contaminants in the air.

Always clean the surrounding area before opening hydraulic systems.

Use only recommended lubricants. Improper lubricants or incompatible lubricants may cause as much damage as no lubrication.

Watch for makeshift “fixes” which can jeopardize safety as well as lead to more costly repair.



Inspection and maintenance should be performed by qualified personnel familiar with the equipment.

Routine Maintenance

IMPORTANT: The operator may perform only maintenance items on the Pre-Start Inspection Checklist. Frequent and Annual maintenance must be performed by qualified service technicians.

Pre-Start Inspection

- Perform routine maintenance as identified in the Pre-Start Inspection Checklist on page 34.

Frequent and Annual Maintenance

Frequent Inspection Checklist and Maintenance Inspection Report must be completed by qualified service technicians trained and authorized to perform maintenance on this machine, and must be done in accordance with the procedures outlined in the service manual. Scheduled maintenance inspection checklists are included in this manual for use by qualified service technicians.

Machines that have been out of service for more than three months must have the Frequent Inspection Checklists completed before returning to service.

Supporting Boom Assembly

**WARNING**

NEVER perform work under the boom assembly with the platform elevated without first supporting the boom assembly.

**CAUTION**

Be careful to avoid pinching any electrical harnesses or hydraulic lines.

DO NOT work beneath the boom assembly with the platform elevated unless the boom assembly is properly supported!

Use a sling and overhead hoist rated for 3 tons (2,700 kg) or more.

Wrap a sling under the outer end of the boom as shown below. Connect it to the overhead hoist, then lift enough that the weight of the boom assembly is being supported by the hoist.





ILLUSTRATION No.
ART_4745

Pre-Start Inspection Checklist



NEVER perform work under the boom assembly with the platform elevated without first supporting the boom assembly

Refer to page 35 for instructions.

The operator must conduct a Pre-Start Inspection of the machine before each work shift.

DO NOT use a damaged or malfunctioning machine!

	Check that the operator's manual and manual of responsibilities are in the storage container located on the platform.
	Perform a visual inspection of all machine components. Look for missing parts; torn or loose hoses; hydraulic fluid leaks; loose, torn or disconnected wires; damaged tires; etc.
	Check all structural components of the machine for cracked welds, corrosion and collision damage.
	Check the security and condition of the lanyard attachment points.
	Check all controls for any damage and proper function.
	Check all hoses and the cables for worn or chafed areas.
	Check the platform rails and sliding mid-rail entries for damage or modification. Check the swing gate for proper operation and latching.
	Check that all warning and instructional decals are legible and secure.
	Check the tires for damage.
	Check the tire pressure (not required for foam filled tires).
	All structural components, pins and fasteners are present and properly tightened.
	Check for fluid leaks.
	Check hydraulic fluid level (check with platform fully lowered).
	Check engine oil level.
	Check engine coolant level at overflow bottle.
	Check fuel tank level.
	Secure all covers, panels and hoods.
	Ensure that all gates are properly closed and secured before operating the machine.

Frequent Inspection Checklist



This checklist must be used at 3-month intervals or every 150 hours of machine use, whichever occurs first. Failure to do so could result in death or serious injury.

Frequent Maintenance Inspections should be conducted by qualified service technicians only. Photocopy this page for reuse. Keep inspections records up to date. Record and report all discrepancies to your supervisor. See the Service & Parts Manual for specific instructions.

Model Number _____ Serial Number _____ Hour Meter Reading _____

Perform all checks listed on Pre-Start Inspection.
Replace engine oil and filter after the first 100 hours of service.
See Kubota engine operator's manual for other engine maintenance information.
Inspect the condition of hydraulic fluid in the reservoir. Oil should be a clear amber color.
Check battery electrolyte level and connections.
Check wheel lug nuts for proper torque (see Specifications).
Check if tires are leaning in or out.
Inspect all structure and pivot points for signs of wear and/or damage.
Check the pin joints and retaining rings for security.
Inspect the entire machine for signs of damage, broken welds, loose bolts, improper or makeshift repairs.
Check that the platform does not drift down with a full load.
Check all wire connections for tightness and corrosion.
Check the operation speeds to ensure they are within specified limits (see Specifications).
Check the Auxiliary Power System.
Clean and lubricate all push button switches with dry lubricant and ensure that the switches operate freely in all positions.
Check the tightness of the platform frame and the linkage pins.
Check the overall platform and guardrail component security.
Check the electrical mounting and hardware connections for security.
Check the steering kingpins for excessive play.

Additional maintenance requirements for severe conditions

If the machine is used in very dusty, exceptionally hot or exceptionally cold conditions, replace hydraulic filter element and air filter element (under normal conditions replace every 6 months or 300 hours, whichever comes first).

Date _____ Inspected By _____

Maintenance Inspection Report

Booms (34J, 45J, 40AJ, 60J, 65J, 85J)

Fleet Equipment Number _____ Date _____
 Inspector Name _____ Inspector Co. _____
 Model Number _____ Address _____
 Serial Number _____
 Hour Meter _____ Signature _____
 Machine Owner & address _____

Maintain all service records in accordance with ANSI A92.24-2019

- * If an inspection receives an "N", remove from service. Once repaired, place an "R" in the box.
- * Refer to the proper service manual for specific information, settings and torque specifications.

Key Y = Yes, Acceptable N = No, Remove from Service R = Repaired O = Not Applicable

QUARTERLY - Inspect only those marked "Q" **ANNUAL** - Inspect all items

	Q/A	Y/N/O	R
DECALS:			
Legible - undamaged/readable			
Capacity decal correct for model			
PLATFORM:			
No damage, all parts present			
Platform mounting fasteners secure			
Entry gates secure, close properly			
Manual box secure, Manuals inside			
Operation of secondary guarding			
PPSS System operational (if equipped)			
ELEVATING ASSEMBLY:			
Lift Hyd Cylinders: no leaks,			
Booms do not bleed down with rated cap.			
Hyd Hoses secure, no visible damage			
Beam structures: Straight, no cracks			
Welds: secure, no cracks			
Pin Retainers in place, secure			
Transport Lock: operational, lubed			
Boom section shimming correct			
ELECTRICAL:			
GFCI operates correctly			
Comm cable: no damage, secure			
Wire harnesses: good cond, secure			
Harness connections: no corrosion			
WHEELS:			
Tires: No damage, Lug nuts torqued			
King Pins lubed			
Tires are leaning in leaning in or out			
Drive motors tight, no leaks			


	Q/A	Y/N/O	R
BASE:			
Fasteners tight			
Cover panels secure			
Welds, no signs of failure or damage			
Hydraulic hoses secure, no leaks			
Torque bolts on slew ring			
Steering king pins, no excessive free play			
COMPONENT AREA:			
Hydraulic; no leaks			
Hydraulic tank: correct level , breather clean			
Hoses not damaged, Fittings tight			
Battery(ies) properly filled and cables clean			
Hydraulic tank: Oil changed per listed intervals			
Replace Hydraulic Filters			
Pressure relief valves, set correctly			
OPERATIONAL INSPECTION:			
All function speeds correct (see Specifications)			
Upper control box, operations correct, smooth			
Upper controls operate proportionally			
Emergency Down operates correctly			
Limit switche(s) slow(s) drive when elevated			
Emergency stop switches, stop everything			
Brakes operational			
**Check Platform Overload protection operation			
ENGINE:			
Engine serviced per recommendations'			
Oil and Coolant Levels correct			
Fuel lines secure, no leaks			
All shields, guards in place, secure			
Mounting secure			
** If equipped with Platform Overload Protection			



Lubrication

Operator may perform routine maintenance only. Lubrication listed as Scheduled Maintenance must be performed by a qualified service technician.

CONTROLS MODULE



#	Item	Specification	Frequency
1	Hubs	SAE 90 Multipurpose Hypoid Gear Oil API Service Classification GL5	Scheduled Maintenance <ul style="list-style-type: none"> Check every three months or 150 hours, whichever occurs first. Change yearly or every 600 hours, whichever occurs first.
2	Hydraulic Reservoir	<p>Fluid Type ISO Grade 32 Tractor Transmission Hydraulic Oil or Chevron Rando Premium MV</p> <p>Temperature Range > 30° F (0° C) < 30° F (0° C)</p> <p>Do not substitute other fluids as pump damage may result!</p> <p>Fill to the middle of the sight gauge with platform in the stowed position and stabilizers retracted.</p>	Routine Maintenance <ul style="list-style-type: none"> Check level daily Scheduled Maintenance <ul style="list-style-type: none"> Change yearly or every 600 hours, whichever occurs first
3	Hydraulic Filter	Filter Element (located inside Hydraulic Reservoir)	Scheduled Maintenance <p>Normal Conditions</p> <ul style="list-style-type: none"> Change every six months or 300 hours, whichever occurs first <p>Severe Conditions -- very dusty, exceptionally hot or exceptionally cold conditions</p> <ul style="list-style-type: none"> Change every three months or 150 hours, whichever occurs first

Troubleshooting

Should you experience erratic operation or notice any malfunction while operating this machine, discontinue use immediately.



Call for assistance and report the incident to your supervisor, and do not use the machine until it has been checked by a trained, qualified mechanic.

Machine functions will not operate

- Adequate fuel supply?
- Proper fuel blend (i.e. winter blend in cold weather)?
- Battery properly connected?
- Battery fully charged?
- Circuit Breaker tripped?
- Function toggle switch or the Enable Switch not activated?
- Selector Key Switch in proper position?
- Both Emergency Stop Switches reset?
- Hydraulic fluid level low?
- Obvious fluid leak or damaged component?
- Wires disconnected, broken, or loose?
- Error code at Onboard Diagnostic Center?
 - See Troubleshooting section in the service chapter of the Service & Parts Manual or contact MEC Customer Service.






ILLUSTRATION No.
ART_6230

Decals


CONTROL SIDE, MODULE CLOSED




CONTROL SIDE, MODULE OPEN




ENGINE SIDE, MODULE CLOSED





ENGINE SIDE, MODULE OPEN





BACK VIEW




FRONT VIEW



*On opposite side of chassis also.




*INSIDE THE MANUAL CASE

<p>1</p>  <p>91975 Qty. - 2</p>	<p>2</p>  <p>96426 Qty. - 2</p>	<p>3</p>  <p>93801 Qty. - 2</p>	<p>4</p>  <p>93807 Qty. - 2</p>
<p>5</p>  <p>93755 Qty. - 2</p>	<p>6</p>  <p>93572 Qty. - 2</p>	<p>7</p>  <p>96393 Qty. - 1</p>	<p>8</p>  <p>6873 Qty. - 1</p>
<p>9</p>  <p>90732 Qty. - 1</p>	<p>10</p>  <p>93805 Qty. - 1</p>	<p>11</p>  <p>91850 Qty. - 1</p>	<p>12</p>  <p>93804 Qty. - 2</p>
<p>13</p>  <p>95481 Qty. - 1</p>	<p>14</p>  <p>91973 Qty. - 8</p>	<p>15</p>  <p>93814 Qty. - 1</p>	<p>16</p>  <p>91971 Qty. - 2</p>
<p>17</p>  <p>91981 Qty. - 2</p>	<p>18</p>  <p>93815 Qty. - 1</p>	<p>19</p>  <p>91972 Qty. - 2</p>	<p>20</p>  <p>91982 Qty. - 2</p>
<p>21</p>  <p>93806 Qty. - 1</p>	<p>22</p>  <p>90751 Qty. - 1</p>	<p>23</p>  <p>96427 Qty. - 1</p>	<p>24</p>  <p>92416 Qty. - 1</p>
<p>25</p>  <p>93857 Qty. - 3</p>	<p>26</p>  <p>91970 Qty. - 2</p>	<p>27</p>  <p>96394 Qty. - 1</p>	<p>28</p>  <p>93754 Qty. - 1</p>
<p>29</p>  <p>93911 Qty. - 1</p>	<p>30</p>  <p>8911 Qty. - 1</p>	<p>31</p>  <p>90719 Qty. - 1</p>	<p>32</p>  <p>90718 Qty. - 1</p>
<p>33</p>  <p>8606 Qty. - 1</p>	<p>34</p>  <p>92119 Qty. - 1</p>	<p>35</p>  <p>96826 Qty. - 2</p>	

Serial Plate Location

The serial plate is attached to the machine at the time of manufacture. Important information about the machine is recorded on the serial plate. The Serial Plate is located on the side of the chassis below the Base Controls.



Serial Plate Description

MFG DATE: Month / Year of manufacture.

MODEL NUMBER: Identifies the machine.

SERIAL NUMBER: Identifies a machine with reference to its original owner. Refer to the number when requesting information or ordering parts.

MODEL YEAR: Identifies the model year of the machine.

MAX. PLATFORM UNRESTRICTED CAPACITY: The maximum safe load (material, persons + equipment) which can be correctly placed on the platform within any range of motion.

MAX. HYDRAULIC SYSTEM PRESSURE: The maximum pressure generated by the machine's hydraulic system.

MAX. WHEEL LOAD: The maximum safe weight applied to each wheel. Calculated with all available options installed. $Fw = 30\% (Wm + Wc + Wopt)$

MACHINE VOLTAGE: The electrical voltage at which the machine operates.

MAX. PLATFORM HEIGHT: The maximum attainable height measured from level ground surface to platform floor.

MAX. DRIVE HEIGHT: The maximum safe platform height at which the machine can be driven.

MAX. PLATFORM REACH: The maximum horizontal outreach of the extended boom.

STANDARD MACHINE WEIGHT: The weight of the machine with no options.

MAX. GROUND PRESSURE: The amount of pressure exerted on the surface at each wheel. Calculated with all available options installed. $Pmax = 30\% (Wm + Wc + Wopt) / \text{Contact Area}$

MAX. SIDE LOAD: The maximum safe force that the occupant can exert laterally on an object outside the platform.

Transport and Lifting Instructions

Safety Information

This section is provided for reference and does not supersede any government or company policy regarding the loading, transport or lifting of MEC machinery.

Truck drivers are responsible for loading and securing machines, and should be properly trained and authorized to operate MEC machinery. Drivers are also responsible for selecting the correct and appropriate trailer according to government regulations and company policy. Drivers must ensure that the vehicle and chains are strong enough to hold the weight of the machine (see the serial number plate for machine weight).



ONLY properly trained and qualified operators shall load and unload this machine.

Free-wheel configuration for Winching or Towing.

RUNAWAY HAZARD!



After releasing the brakes there is nothing to stop machine travel. Machine will roll freely on slopes.

ALWAYS chock the wheels before manually releasing the brakes.


Before towing or winching the machine, it is necessary to release the brakes. Reset the brakes after towing or winching. The machine can be winched or towed short distances at speeds not to exceed 5.0mph (8.0km/h).

Disengage Brakes before Towing or Winching

- Chock the wheels.
- Push and hold the black button on the Brake Release Valve.
- Press the red button on the Hand Pump valve 8-10 times until there is firm resistance and the brakes release.

Engage Brakes before Driving

- Manually by pulling the black button out on the Brake Release Valve, or
- Automatically by engaging the drive function.



Note: Brakes will reset automatically when drive function is activated.

Driving or Winching onto or off of a Transport Vehicle

Before loading the machine, orient the turntable so that the platform is over the non-steering wheels.

ONLY properly trained and qualified operators shall load and unload this machine.

Read and understand all safety, control, and operating information found on the machine and in this manual before operating the machine.



Whether winching or driving the machine on to a truck or trailer, always check the area for dangerous situations before moving the machine.

If driving the machine, always use a second person acting as a spotter to make sure the person loading the machine avoids dangerous situations.


Driving

- Turn the Base Key Switch to Platform. Check that the Emergency Stop Switch is reset by turning it clockwise.
- Enter the platform and reset the Platform Emergency Stop Switch.
- Test platform control functions.
- Raise the jib slightly for platform ground clearance.
- Carefully drive the machine off or on to the transport vehicle.
- Make sure you can see the second person giving guidance.

Note: The brakes are automatically released for driving and will automatically apply when the control lever is returned to neutral which causes the machine to stop.

Winching

- Chock the wheels, then disengage brakes (see Disengage Brakes before Towing or Winching on page 45).
- Carefully operate the winch to lower the machine down the ramp or pull the machine up the ramp.
- Chock the wheels and engage the brakes before disengaging the winch.



ART_4741

Securing to Truck or Trailer for Transport


- Turn the key Selector Key Switch to Off and remove the key before transport.
- Turn the Battery Disconnect Switch to Off before transport.
- Inspect the entire machine for loose or unsecured items.
- Secure the chassis.
- Secure the platform.

Securing the Chassis

Make sure each of your chains is rated to hold the machine's weight (see serial number plate or Specifications). Use at least 4 chains.

Do not attach chain hooks directly to the machine. Loop the chain through the tie-down point and connect the chain hook to the chain.



Be sure chains are arranged so that they do not damage the machine.



Securing the Platform

With the boom completely stowed, raise the jib slightly, then use the Platform Level function to lower the platform until the front of the platform touches the trailer surface.

Route the tie-down strap as shown through the width of the platform, over the toe boards of both side entry points. Tighten securely but do not over-tighten.



It may be necessary to turn the platform 90° when loading two machines on the same trailer. In this case, route the strap over the toeboard and through the end of the platform as shown.

Boom Lifting Instructions

Only qualified riggers should rig and lift this machine.



Ensure that the crane capacity, loading surfaces, chains, straps and slings are sufficient to withstand a machine weight of 11,500lbs (5,216kg).


Ensure that the platform is unloaded and that all material and tools have been removed!



Be careful to avoid pinching any electrical harnesses or hydraulic lines.

Center of gravity measurements are taken from the center of the non-steering wheel.

X-Axis	Y-Axis
33 inches (83.8 centimeters)	50.6 inches (128.5 centimeters)



1. Rotate the turntable so that it is parallel to the chassis center line. The counterweight should be directly over the front axle (steerable wheels).
2. Make sure that the crane hooks will fit securely in the oval openings at the rear of the turntable and not get jammed.
3. Attach straps/chains to the circular lifting points at the front of the turntable above the counterweight.
4. Carefully lift the machine making sure the straps/chains lift the machine in a substantially level condition and move to its desired place.
5. When the machine is in place, carefully remove the straps/chains and crane hooks.




ILLUSTRATION NO.
ART_6232

Notes

Notes



MEC Parts Order Form

Phone: 559-842-1523

Fax: 559-400-6723

Email: Parts@mecawp.com

Please Fill Out Completely:

Date: _____
Account: _____
Bill to: _____

Ordered By: _____
Your Fax No.: _____
Ship to: _____

Purchase Order Number _____

Ship VIA _____

*** All orders MUST have a Purchase Order Number*

***Fed Ex shipments require Fed Ex account number*

Part Number	Description	Quantity	Price

All back-ordered parts will be shipped when available via the same ship method as original order unless noted below:

- _____ Ship complete order only - No Backorders
- _____ Ship all available parts and contact customer on disposition of back-ordered parts
- _____ Other (Please specify)

Signature _____



Limited Owner Warranty

MEC Aerial Platform Sales Corp. warrants its equipment to the original purchaser against defects in material and/or workmanship under normal use and service for one (1) year from date of registered sale or date the unit left the factory if not registered. MEC Aerial Platform Sales Corp. further warrants the structural weldments of the main frame and scissor arms to be free from defects in material or workmanship for five (5) years from date of registered sale or date unit left the factory if not registered. Excluded from such warranty is the battery(s) which carries a ninety (90) day warranty from described purchase date. Warranty claims within such warranty period shall be limited to repair or replacement, MEC Aerial Platform Sales Corp's option, of the defective part in question and labor to perform the necessary repair or replacement based on MEC Aerial Platform Sales Corp's then current flat rate, provided the defective part in question is shipped prepaid to MEC Aerial Platform Sales Corp. and is found upon inspection by MEC Aerial Platform Sales Corp. to be defective in material and/or workmanship. MEC Aerial Platform Sales Corp. shall not be liable for any consequential, incidental or contingent damages whatsoever. Use of other than factory authorized parts; misuse, improper maintenance, or modification of the equipment voids this warranty. The foregoing warranty is exclusive and in lieu of all other warranties, express or implied. All such other warranties, including implied warranties of merchantability and of fitness for a particular purpose, are hereby excluded. No Dealer, Sales Representative, or other person purporting to act on behalf of MEC Aerial Platform Sales Corp. is authorized to alter the terms of this warranty, or in any manner assume on behalf of MEC Aerial Platform Sales Corp. any liability or obligation which exceeds MEC Aerial Platform Sales Corp's obligations under this warranty.



MEC Aerial Work Platforms

1401 S. Madera Avenue, Kerman, CA 93630 USA

Toll Free: 1-877-632-5438

Phone: 1-559-842-1500

Fax: 1-559-842-1520

info@MECawp.com

www.MECawp.com